
# **OPERATOR'S MANUAL**

# **BOP 1000W**

## HIGH POWER BIPOLAR POWER SUPPLY



#### **IMPORTANT NOTES:**

1) This manual is valid for the following Model and associated serial numbers:

MODEL SERIAL NO. REV. NO.

- A Change Page may be included at the end of the manual. All applicable changes and revision number changes are documented with reference to the equipment serial numbers. Before using this Instruction Manual, check your equipment serial number to identify your model. If in doubt, contact your nearest Kepco Representative, or the Kepco Documentation Office in New York, (718) 461-7000, requesting the correct revision for your particular model and serial number.
- 3) The contents of this manual are protected by copyright. Reproduction of any part can be made only with the specific written permission of Kepco, Inc.

Data subject to change without notice.

©2008, KEPCO, INC P/N 243-1027R8H



# **Declaration of Conformity**

Application of Council directives: 73/23/EEC (LVD) 93/68/EEC (CE mark) Standard to which Conformity is declared: EN61010-1:1993 (Safety requirements for electrical equipment for measurement, control and laboratory use) Manufacturer's Name and Address: **KEPCO INC.** 131-38 SANFORD AVENUE FLUSHING, N.Y. 11355 Importer's Name and Address: Type of Equipment: **Component Power Supply** Model No.: [PRODUCT MODEL NUMBER] Year of Manufacture: I, the undersigned, declare that the product specified above, when used in conjunction with the conditions of conformance set forth in the product instruction manual, complies with the requirements of the Low Voltage Directive 73/23/EEC, which forms the basis for application of the CE Mark to this product. KEPCO Inc. Place: 131-38 Sanford Ave. Flushing, N.Y.11355 USA Saul Kupferberg (Full Name) **VP OF SALES** Date: (position)

228-1348 DC-COMP/INST 022108 A

## **Conditions of Conformance**

When this product is used in applications governed by the requirements of the EEC, the following restrictions and conditions apply:

- For European applications, requiring compliance to the Low Voltage Directive, 73/23/EEC, this power supply is considered a component product, designed for "built in" applications. Because it is incomplete in construction, the end product enclosure must provide for compliance to any remaining electrical safety requirements and act as a fire enclosure. (EN61010-1 Cl. 6, Cl. 7, Cl.8, Cl. 9 and EN61010-1 annex F)
- 2. This power supply is designed for stationary installation, with mains power applied via a detachable power supply cord or via direct wiring to the source power terminal block.
- This power supply is considered a Class 1 (earthed) product, and as such depends upon proper connection to protective earth for safety from electric shock. (EN61010-1 Cl. 6.5.4)
- 4. This power supply is intended for use as part of equipment meant for test, measurement and laboratory use, and is designed to operate from single phase, three wire power systems. This equipment must be installed within a suitably wired equipment rack, utilizing a three wire (grounded) mains connection. See wiring section of this manual for complete electrical wiring instructions. (EN61010-1 Cl. 6.5.4 and Cl.6.10.1)
- 5. This power supply has secondary output circuits that are considered hazardous, and which exceed 100V d-c, able to deliver current greater than 10A d-c.
- 6. The output wiring terminals of this power supply have not been evaluated for field wiring and, therefore, must be properly configured by the end product manufacturer prior to use.
- 7. This power supply employs a supplementary circuit protector in the form of a circuit breaker mounted on the front panel. This circuit breaker protects the power supply itself from damage in the event of a fault condition. For complete circuit protection of the end product, as well as the building wiring, it is required that a primary circuit protection device be fitted to the branch circuit wiring. (EN61010-1 Cl. 9.6.2)
- 8. Hazardous voltages are present within this power supply during normal operation. All operator adjustments to the product are made via externally accessible switches, controls and signal lines as specified within the product operating instructions. There are no user or operator serviceable parts within the product enclosure. Refer all servicing to qualified and trained Kepco service technicians.

## SAFETY INSTRUCTIONS

## 1. Installation, Operation and Service Precautions

This product is designed for use in accordance with EN 61010-1 and UL 3101 for Installation Category 2, Pollution Degree 2. Hazardous voltages are present within this product during normal operation. The product should never be operated with the cover removed unless equivalent protection of the operator from accidental contact with hazardous internal voltages is provided:



There are no operator serviceable parts or adjustments within the product enclosure. Refer all servicing to trained service technician.



Source power must be removed from the product prior to performing any servicing.



This product is factory-wired for the nominal a-c mains voltage indicated on the rating nameplate located adjacent to the source power connection on the product's rear panel. To reconfigure the product input for other nominal mains voltages as listed herein, the product must be modified by a trained service technician.

## 2. Grounding

This product is a Class 1 device which utilizes protective earthing to ensure operator safety.



The PROTECTIVE EARTHING CONDUCTOR TERMINAL must be properly connected prior to application of source power to the product (see instructions on installation herein) in order to ensure safety from electric shock.



PROTECTIVE EARTHING CONDUCTOR TERMINAL - This symbol indicates the point on the product to which the protective earthing conductor must be attached.



EARTH (GROUND) TERMINAL - This symbol is used to indicate a point which is connected to the PROTECTIVE EARTHING TERMINAL. The component installer/assembler must ensure that this point is connected to the PROTECTIVE EARTHING TERMINAL.



CHASSIS TERMINAL -This symbol indicates frame (chassis) connection, which is supplied as a point of convenience for performance purposes (see instructions on grounding herein). This is not to be confused with the protective earthing point, and may not be used in place of it.

#### 3. Electric Shock Hazards

This product outputs hazardous voltage and energy levels as a function of normal operation. Operators must be trained in its use and exercise caution as well as common sense during use to prevent accidental shock.



This symbol appears adjacent to any external terminals at which hazardous voltage levels as high as 500V d-c may exist in the course of normal or single fault conditions.



This symbol appears adjacent to any external terminals at which hazardous voltage levels in excess of 500V d-c may exist in the course of normal or single fault conditions.

# OPERATOR SAFETY INSTRUCTIONS

Read these safety instructions, as well as the applicable installation and operating instructions contained in this manual before using the power supply.



Do not touch the output terminals. The output is dangerous. Electric shock can cause injury or death.

Do not remove the cover or disassemble the unit. There are no operator serviceable components or adjustments inside the unit. High voltage components inside the unit can cause serious injury even with input power disconnected.

Service must be referred to authorized personnel. Using the power supply in a manner not specified by Kepco. Inc. may impair the protection provided by the power supply. Observe all safety precautions noted throughout this manual. The following table lists symbols used on the power supply or in this manual where applicable.

The liquid in the LCD is hazardous: do not lick or swallow. Wash skin and clothes immediately and thoroughly upon exposure.

#### **SAFETY SYMBOLS**

SYMBOL	Meaning		
4	WARNING: RISK OF ELECTRIC SHOCK. INDICATES THE POSSIBILITY OF BODILY INJURY OR DEATH.		
$\triangle$	CAUTION: REFER TO REFERENCED PROCEDURE. INDICATES THE POSSIBILITY OF EQUIPMENT DAMAGE.		

## **CAUTION**

If this power supply is used in OEM equipment, the OEM equipment manufacturer is responsible for attaching appropriate warning labels on the OEM equipment.

Operating the power supply outside the specified limits for input voltage, temperature, or other environmental conditions noted in this manual can damage the power supply and void the warranty.

DO NOT: wipe the front panel with hard materials, nor apply excessive force to the surface. DO NOT expose to extended periods of bright sunshine or UV light.

# **Safety Messages**

The BOP protection circuitry is designed to protect the load against unregulated high voltages and protect the BOP from extensive damage in the event of a component failure. Refer to Table 1-2 for more information regarding the protection circuits.

D OP-SAFETY 022108

# LIST OF WARNINGS AND CAUTIONS

PAGE		WARNING/CAUTION
3-19	WARNING:	For inductive loads, and especially superconducting magnet type loads, the inherent offset of the BOP in the OFF state may generate significant current in the circuit. A properly rated switch in parallel with a resistor must be connected between the power supply and the load. The switch must be open and the BOP front panel LCD must read 0V, 0A before removing or installing connections between BOP and load.
3-19	WARNING:	For both inductive loads and constant-current-type active electronic loads when the BOP output is set to OFF, a path is provided for absorbing either the energy accumulated in the reactance of the load during the ON state, or energy delivered by an electronic load. This prevents damage to the load and power supply as well as providing safety for the user. However, In addition to the built-in safety features, constant-current-type active electronic loads must be adjusted to zero and the BOP front panel LCD must read 0V, minimum current, before handling the power supplyto-load connections.
3-19	WARNING:	Accessing the BOP after the output is disabled in BATTERY mode is hazardous because (1) high current arcing is possible and (2) either the external battery voltage, or the voltage (±Voltage Protection max) on the BOP output terminals may be dangerous. Therefore, for battery and constant-voltage-type active electronic loads it is recommended that two properly rated external switches be installed for safety: one in series with the battery, and one across the BOP output. After the unit is set to OFF, first open the switch is series with the battery, then close the switch across the BOP output to ensure safety before handling BOP connections. When connecting the battery, the switch across the output should be opened after the connections are complete and then the switch in series with the battery should be closed. If the constant-voltage-type active electronic load is adjusted to zero before handling the power supply-to-load connections, only the switch across the BOP output is required.
3-28	WARNING:	Be sure that output power is OFF (Standby indicator lit) while connecting monitoring device. Be sure that connections are secure and that terminals are not inadvertently shorted.
4-8	WARNING:	The sense resistor will be dissipating full rated current of the BOP. If it is hot to the touch, the sense resistor value, power rating and/or cooling are incorrect; refer to PAR. 4.3 and Table 4-2.
4-14	WARNING:	The sense resistor will be dissipating full rated current of the BOP. If it is hot to the touch, the sense resistor value, power rating and/or cooling are incorrect; refer to PAR. 4.4 and Table 4-2.
2-3	CAUTION:	When an external shut-down signal is sent to the unit, the shut-down condition is latched and the red FAULT indicator on the front panel is ON. To resume normal operation it is necessary to cycle power off, then on (preferred) or briefly press the RESET key on the front panel.
2-6	CAUTION:	it is recommended that source power of external equipment connected to the Analog Port be applied through an isolating transformer To avoid ground loops or possible damage to the BOP due to incorrect equipment a-c wiring (e.g., defeating of ground connection).
2-8	CAUTION:	The rack must provide support at the rear (within 6 inches of the rear panel). Optional slides can also be used (see PAR. 2.4.2).

BOP 36-28MG2/21/08

# LIST OF WARNINGS AND CAUTIONS

PAGE		WARNING/CAUTION
2-8	CAUTION:	When working with active loads, the voltage or current of the active load must not exceed the maximum voltage or current rating of the BOP. Otherwise the overvoltage or overcurrent protection will shut down the power supply.
2-10	CAUTION:	Never connect the load to the sense terminals. Monitoring instruments (e.g., DVM, etc.) are the only external equipment that may be safely connected to the sense terminals.
2-10	CAUTION:	The safety features incorporated into the BOP to handle energy from Active loads are unable to protect the power supply or the load if input power to the BOP is lost or if the BOP Malfunctions. It is recommended that the user monitor "Power OK" flag pins 3 and 4 of the external Protect Port (see Table 2-4) and implement a fast-acting means of disconnecting capacitive loads or crowbarring inductive loads to prevent damage to both the BOP and the load in the event of input power loss.
2-13	CAUTION:	For parallel configurations, Remove links between (COM S) and (COM OUT) terminals of all slaves to prevent damage to the unit and maintain system accuracy.
2-13	CAUTION:	Connecting multiple units to different a-c input sources may damage the BOP power supplies and/or the load.
2-19	CAUTION: TI	he units are now configured as slave(s) to be controlled only by the master.  Do not use the slave keypad, RS 232 port or GPIB port to try to control the slave(s).
3-3	CAUTION:	Pressing RESET will cause voltage transients to appear at the output which may damage a connected load.
3-12	CAUTION:	When the ADJUST control is rotated, the active parameter is immediately effective if the output is enabled (on = STANDBY indicator not lit). The voltage/current applied to the load changes as the ADJUST control is rotated.
3-18	CAUTION:	When working with active loads, always adjust the BOP protection limits to be above the maximum values of voltage or current expected from the load. For example, when the BOP is operating in voltage mode sinking energy from a constant current type load, set the current protection limits of the BOP above the maximum current expected from the load.
3-24	CAUTION:	Before Pressing to enter the Saved Waveform Screen from the power- up screen, perform the following steps to avoid unexpected voltages or currents from previous settings being briefly applied to the load when the waveform is first executed.
3-33	CAUTION:	Pressing RESET will cause voltage transients to appear at the output which may damage a connected load. Switch is recessed to prevent inadvertent activation.
3-50	CAUTION:	When the serial port has received an XOFF, the error message -400, QUE error will be placed in the queue to indicate the loss of transmitted information due to a received XOFF character. When XON is received, the unit will transmit all data in it's buffer followed by the exclamation character (!). This (!) character is not part of any message from the BOP and indicates the transmission buffer has been cleared and the BOP is idle.
4-12	CAUTION:	If the CALIBRATE ZERO [ function is available, perform this function first, as it affects all other output calibrations.

F BOP 36-28MG2/21/08

SECTION	l	PAGE
SECT	ION 1 - INTRODUCTION	
1.1	Scope of Manual	1-1
1.2	General Description	1-1
1.3	Specifications	1-1
1.4	Local Control	1-12
1.5	Remote Control	1-12
1.6	Features	1-12
1.6.1	Digital Calibration	1-12
1.6.2	voltage/current Protection	1-12
1.6.3	Waveforms	1-12
1.6.4	Saving and Recalling Settings	1-13
1.6.5	External Reference (Analog Control)	1-13
1.6.6	External Limits	1-13
1.6.7	User-defined Voltage/Current Maximum Values (Software Limits)	1-13
1.6.8	Parallel and Series Configurations	1-13
1.6.9	Energy Recuperation	1-13
1.7	Equipment Supplied	1-15
1.8	Accessories	1-15
1.9	Safety	1-15
SECT	ION 2 - INSTALLATION	
2.1	Unpacking and Inspection	2-1
2.2	Terminations and Controls	
2.3	Preliminary Operational Check	
2.4	Installation	
2.4.1	Rack Mounting	
2.4.2	Slide Installation	
2.5	Wiring Instructions	
2.5.1	Safety Grounding	
2.5.2	Source Power Connections	
2.5.3	D-C Output Grounding	
2.5.3.1	Grounding Network Configuration	
2.5.4	Power Supply/Load Interface	
2.5.5	Load Connection - General	
2.5.6	Load Connection Using Local Sensing	
2.5.7	Load Connection Using Remote Sensing	
2.6	Cooling	
2.7	Setting up the unit	
2.7.1	Consider the Load Type	
2.7.2	Setup for Local Operation	
2.7.3	Setup for Remote Operation via GPIB	
2.7.4	Setup for Remote Operation via RS 232C	
2.8	Multiple Unit Configurations	
2.8.1	Multiple Unit Source Power	
2.8.2	Multiple Unit Protection	
2.8.3	Configuring Parallel, Series, 2 X 2 or 3 X 2 combinations	
2.8.4	Operating Instructions for Multiple Unit Combinations	
2.8.5	Restoring a Unit to Standalone Operation	
2.8.6	Changing Multiple Unit configurations	
SECT	ION 3 - OPERATION	
3.1	General	3-1
3.2	Power Supply Basics	
3.2.1	Keypad Description	
3.2.2	LCD and Power-up Screen Description	
323	Turning the Power Supply On	3-5

SECTION		PAGE
3.2.4	How to Access the menus	3-6
3.2.4.1	Overall menu Structure	
3.2.4.2	How to Modify a Parameter	
3.2.4.3	Password Setup.	
3.2.4.4	How to Access a Password Protected Menu	
3.2.5	Operator Convenience Functions (Display Menu)	
3.2.5.1	Adjusting LCD Brightness, contrast and Background	
3.2.5.2	Enabling/Disabling Audible Beeps	
3.2.5.3	Displaying Meters or Graph (Time line)	
3.3	Local Mode Operation	
3.3.1	Setting Local Mode	
3.3.1 3.3.1.1	Keypad Lockout	
3.3.1.1	Local Password Protection at Power-up	
	·	
3.3.2	Setting Voltage or Current Mode	
3.3.3	Programming Voltage or Current and Associated Protect Limits	
3.3.3.1	Selecting Bipolar/Independent Protection Limits	
3.3.3.2	Understanding Voltage and Current Protect Limits	
3.3.3.3	Hidden Voltage and Current Protect Limits	
3.3.4	Changing Maximum or Minimum Software-controlled Limits	
3.3.4.1	Changing Maximum Accepted Voltage or Current (Main Channel Software Limits)	
3.3.4.2	Changing Maximum/Minimum Protection Software-controlled Limits	
3.3.4.3	External Limits	
3.3.5	Enabling/Disabling DC Output Power	
3.3.6	Determining How the Unit responds when Output is OFF (Load Type)	
3.3.7	Changing the Default Power up Settings	
3.3.8	Storing/Recalling Power Supply Output Settings	
3.3.8.1	Understanding Abbreviations Used for Saved Settings	
3.3.8.2	Viewing Saved Settings	
3.3.8.3	Saving Settings and Erasing or Modifying Previously Saved settings	
3.3.8.4	Copying Previously Saved settings to a New Location	
3.3.8.5	Applying Saved settings to the Output (Recall)	3-24
3.3.9	Waveform Generation	3-24
3.3.9.1	Protecting the Load When Accessing Waveforms	3-24
3.3.9.2	Waveform Overview	3-25
3.3.9.3	Understanding How Waveforms Are Generated	3-25
3.3.9.4	Waveform Specifications	3-26
3.3.9.5	Viewing Stored Waveforms	3-27
3.3.9.6	Executing a Waveform	3-27
3.3.9.7	Modifying Previously Stored Waveforms	
3.3.9.8	Creating a New Waveform	
3.3.9.9	Using Segments to Build a Waveform	
3.3.9.10	Copying a Waveform	
3.3.10	Reset	
3.3.11	Operator Testing	
3.3.12	Error Message Explanations	
3.4	Analog Remote Mode Programming	
3.4.1	Remote Output off	
3.4.1.1	Remote Shutdown	
3.4.1.2	Remote Standby	
3.4.2	Voltage/Current Mode Control	
3.4.2 3.4.3	Controlling the Output Using the BOP as a Power Amplifier	
3.4.3.1	Fixed Gain using External Reference Control	
3.4.3.1 3.4.3.2		
	Variable Gain Using External Reference Level	
3.4.4	External Protection Limits	
3.4.4.1	Using Both Local/Digital and External Protection Limits	
3.4.5	Monitoring Output Current Using an analog signal	
3.5	Digital Remote Mode Programming	3-41

3.5.1         Operating Features Available only by Remote Commands.         3-41           3.5.1.1         Expanded Waveforms and Programs.         3-41           3.5.2.1         Programming Techniques to Optimize performance.         3-41           3.5.2.1         Programming Techniques to Optimize performance.         3-41           3.5.2.1         Making Suze the Previous Command is Complete.         3-42           3.5.3.1         GPIB Port Setup.         3-43           3.5.3.1.1         Changing the GPIB Address.         3-44           3.5.3.1.3         Determining Whether "RST Command sets the Output Off or On.         3-45           3.5.3.2.2         RS 223 Seral Port Setup.         3-45           3.5.3.2.3         Select Baud Rate.         3-45           3.5.3.2.2         Configure XDN/XOFF Protocol.         3-45           3.5.3.3.3         Establish communication language.         3-46           3.5.3.4         BIT 4886 Compatibility.         3-46           3.5.3.5.5         BIT 4886 Compatibility.         3-46           3.5.4         IEEE 488 (CPIB) Bus Protocol.         3-48           3.5.6         BOP VISA Instrument driver.         3-48           3.5.6.2         RS 232-Communication.         3-49           3.5.6.2.1         XON XOFF M	SECTION		PAGE
3.5.1.1       Expanded Waveforms and Programs       3.41         3.5.2.1       Programming Voltage/Current Limit and Current/Voltage Limit.       3.41         3.5.2.2       Making Sure the Previous Command is Complete.       3.42         3.5.3.1       GPIB Port Setup.       3.43         3.5.3.1.1       Changing the GPIB Address.       3.44         3.5.3.1.2       Configure Device Clear (DCL) Control.       3.44         3.5.3.2.1       Determining Whether *FST Command sets the Output Off or On.       3.45         3.5.3.2.2       RS 232 Serial Port Setup.       3.45         3.5.3.2.1       Select Baud Rate       3.43         3.5.3.2.2       Configure XON/XOFF Protocol       3.45         3.5.3.3.1       Establish communication language       3.46         3.5.3.3       Establish communication language       3.46         3.5.3.5       BIT 4882 Compatibility       3.46         3.5.6       RS 232-C Operation       3.48         3.5.6       RS 232-C Operation       3.48         3.5.6.1       XON NOFF Method       3.50         3.5.6.2       RS 232 Implementation       3.49         3.5.6.2       RS 232 Communication       3.41         3.5.6.1       XON NOFF Method       3.50 <tr< td=""><td>3.5.1</td><td>Operating Features Available only by Remote Commands</td><td> 3-41</td></tr<>	3.5.1	Operating Features Available only by Remote Commands	3-41
3.5.2.1         Programming Techniques to Optimize performance         3-41           3.5.2.1         Programming Voltage(Current Limit and Current/Voltage Limit.         3-41           3.5.2.2         Making Sure the Previous Command is Complete         3-43           3.5.3.1         GPIB Port Setup.         3-44           3.5.3.1.1         Changing the GPIB Address.         3-44           3.5.3.1.3         Determining Whether "RST Command sets the Output Off or On.         3-44           3.5.3.1.3         Determining Whether "RST Command sets the Output Off or On.         3-45           3.5.3.2.1         Select Baud Rate.         3-45           3.5.3.2.1         Select Baud Rate.         3-45           3.5.3.2.3         Configure YON/XOFF Protocol.         3-45           3.5.3.3         Establish communication language.         3-46           3.5.3.4         BIT 4882 Compatibility.         3-46           3.5.5.5         BIT 4882 Compatibility.         3-46           3.5.6         RS 232 Coperation.         3-48           3.5.6.1         Serial INterface.         3-48           3.5.6.2.1         XON XOFF Method.         3-50           3.5.6.2.2         Echo Mode.         3-50           3.5.6.3         Sichling SCPI commands for RS 232 Communicat	3.5.1.1		
3.5.2.1       Programming Voltage/Current Limit and Current/Voltage Limit.       3-42         3.5.2.2       Making Suze the Previous Command is Complete.       3-42         3.5.3.1       GPIB Port Setup.       3-44         3.5.3.1.1       Changing the GPIB Address.       3-44         3.5.3.1.2       Configure Device Clear (DCL) Control.       3-44         3.5.3.1.2       Configure Device Clear (DCL) Control.       3-44         3.5.3.2       RS 232 Serial Port Setup.       3-45         3.5.3.2.2       Configure To Setup.       3-45         3.5.3.2.2       Configure CoNN/OFF Protocol.       3-45         3.5.3.3       Establish communication language.       3-46         3.5.3.4       BIT 4882 Compatibility.       3-46         3.5.3.5       BIT 4882 Compatibility.       3-46         3.5.4       BIT 4882 Compatibility.       3-46         3.5.6       BEZES AS 232 Implementation.       3-48         3.5.6       RS 232-C Operation.       3-48         3.5.6.1       Serial Nterface.       3-48         3.5.6.2.3       Prompt Method.       3-51         3.5.6.2.3       Prompt Method.       3-51         3.6.3.1       ABORT Subsystem.       3-52         3.6.3.1	3.5.2		
3.5.2.2       Making Sure the Previous Command is Complete       3-42         3.5.3.1       Remote Mode Setup       3-43         3.5.3.1.1       Changing the GPIB Address       3-44         3.5.3.1.2       Configure Device Clear (DCL) Control       3-44         3.5.3.1.3       Determining Whether "RST Command sets the Output Off or On       3-45         3.5.3.2       RS 232 Serial Port Setup       3-45         3.5.3.2.1       Select Baud Rale       3-45         3.5.3.2.2       Configure Prompt Mode       3-45         3.5.3.3       Establish communication language       3-46         3.5.3.4       BIT 4882 Compatibility       3-46         3.5.3.5       BIT 4886 Compatibility       3-46         3.5.4       IEEE 488 (GPIB) Bus Protocol       3-46         3.5.6       RS 232-C Operation       3-48         3.5.6.1       Serial INterface       3-48         3.5.6.2       RS 232-Implementation       3-49         3.5.6.2.2       Echo Mode       3-50         3.5.6.2.3       VSIN protected       3-50         3.5.6.3       Using SCPI commands for RS 232 Communication       3-51         3.5.6.3       Using SCPI commands for RS 232 Communication       3-51         3.6.3.1	3.5.2.1		
3.5.3   Remote Mode Setup.         3-43           3.5.3.1.1   Changing the GPIB Address.         3-44           3.5.3.1.2   Configure Device Clear (DCL) Control.         3-44           3.5.3.1.3   Determining Whether *RST Command sets the Output Off or On.         3-45           3.5.3.2   RS 232 Serial Port Setup.         3-45           3.5.3.2.1   Select Baud Rate         3-45           3.5.3.2.2   Configure NONIXOFF Protocol.         3-45           3.5.3.3   Establish communication language         3-46           3.5.3.4   BIT 4882 Compatibility.         3-46           3.5.4   BIT 4885 Compatibility.         3-46           3.5.5   BOP VISA Instrument driver.         3-48           3.5.6   RS232-C Operation         3-48           3.5.6.1   Serial Interface         3-48           3.5.6.2   RS 232 Implementation         3-49           3.5.6.3   Prompt Method.         3-51           3.5.6.2   Serial Number of driver.         3-52           3.5.6.2   Serial Interface         3-48           3.5.6.2   Serial Prompt Method.         3-50           3.5.6.2   Serial Interface         3-49           3.5.6.2   Serial Interface         3-40           3.5.6.3   Serial Interface         3-51           3.5.6.3   Serial Interface         3-52	3.5.2.2		
3.5.3.1     GPIB Port Setup     3.44       3.5.3.1.1     Changing the CPIB Address     .344       3.5.3.1.2     Configure Device Clear (DCL) Control     .3-44       3.5.3.1.3     Determining Whether *RST Command sets the Output Off or On     .3-45       3.5.3.2.1     Select Baud Rate     .3-45       3.5.3.2.2     Configure Prompt Mode     .3-45       3.5.3.3     Establish communication language     .3-46       3.5.3.4     BIT 4882 Compatibility     .3-46       3.5.3.5     BIT 4886 Compatibility     .3-46       3.5.3.5     BIT 4886 Compatibility     .3-46       3.5.5     BOP VISA Instrument driver     .3-48       3.5.6     RS232-C Operation     .3-48       3.5.6.1     Serial INterface     .3-48       3.5.6.2     RS 232 Implementation     .3-49       3.5.6.2.1     XON XOFF Method     .3-50       3.5.6.2.2     Echo Mode     .3-50       3.5.6.3     Using SCPI commands for RS 232 Communication     .3-51       3.6.1     SCPI Programming     .3-51       3.6.1     SCPI Messages     .3-52       3.6.3     SCPI Subsystem Commands/Queries     .3-52       3.6.3.1     SCPI Subsystem Commands/Queries     .3-52       3.6.3.3     INITIATE Subsystem     .3-52 <td>3.5.3</td> <td></td> <td></td>	3.5.3		
3.5.3.1.1       Changing the CPIB Address       .3.44         3.5.3.1.2       Configure Device Clear (DCL) Control       .3.44         3.5.3.1.3       Determining Whether 'RST Command sets the Output Off or On       .3.45         3.5.3.2.1       Select Baud Rate       .3.45         3.5.3.2.2       Configure NONIXOFF Protocol       .3.45         3.5.3.3       Configure Prompt Mode       .3.45         3.5.3.4       BIT 4882 Compatibility       .3.46         3.5.3.5       BIT 4886 Compatibility       .3.46         3.5.4       IEEE 488 (GPIB) Bus Protocol       .3.46         3.5.6       BO YISA Instrument driver       .3.48         3.5.6       RS232-C Operation       .3.48         3.5.6.1       Serial Interface       .3.49         3.5.6.2.1       XON XOFF Method       .3.50         3.5.6.2.2       Ech Mode       .3.50         3.5.6.2.3       Prompt Method       .3.51         3.5.6.4       Isolating RS 232 Commands for RS 232 Communication       .3.51         3.5.6.2       SCPI Programming       .3.51         3.5.6.2       SCPI Programming       .3.51         3.6.3       SCPI Subsystem       .3.52         3.6.3       SCPI Subsystem Subsystem	3.5.3.1	·	
3.5.3.1.2       Configure Device Clear (DCL) Control.       3.44         3.5.3.1.3       Determining Whether 'RST Command sets the Output Off or On.       3.45         3.5.3.2.1       Select Baud Rate.       3.45         3.5.3.2.2       Configure XONXOFF Protocol.       3.45         3.5.3.2.3       Configure Prompt Mode.       3.45         3.5.3.3       Establish communication language.       3.46         3.5.3.4       BIT 4882 Compatibility.       3.46         3.5.5.5       BIT 4886 Compatibility.       3.46         3.5.5       BOP VISA Instrument driver.       3.48         3.5.6       RS 232-C Operation.       3.48         3.5.6.1       Serial INterface.       3.48         3.5.6.2       RS 232 Implementation.       3.49         3.5.6.2.1       XON XOFF Method.       3.50         3.5.6.2.2       Echo Mode.       3.50         3.5.6.3       Using SCPI commands for RS 232 Communication.       3.51         3.5.6.4       SCPI Messages.       3.51         3.6.3       SCPI Subsystem Commands/Queries.       3.52         3.6.3       SCPI Subsystem Commands/Queries.       3.52         3.6.3.1       ABORT Subsystem.       3.52         3.6.3.2       DISPlay Subsy	3.5.3.1.1	•	
3.5.3.1.3       Determining Whether "RST Command sets the Output Off or On.       3-45         3.5.3.2       RS 232 Serial Port Setup.       3-45         3.5.3.2.1       Select Baud Rate       3-45         3.5.3.2.2       Configure XON/XOFF Protocol.       3-45         3.5.3.3       Establish communication language       3-46         3.5.3.4       BIT 4882 Compatibility.       3-46         3.5.3.5       BIT 4886 Compatibility.       3-46         3.5.4       IEEE 488 (GPIB) Bus Protocol.       3-48         3.5.5       BOP VISA Instrument driver       3-48         3.5.6       RS232-C Operation.       3-48         3.5.6.1       Senial Interface.       3-48         3.5.6.2       RS 232 Implementation.       3-49         3.5.6.2.1       XON XOFF Method.       3-50         3.5.6.2.2       Echo Mode.       3-50         3.5.6.3       Using SCPI commands for RS 232 Communication.       3-51         3.5.6.4       Isolating RS 232 Communication Problems       3-51         3.6.1       SCPI Programming       3-51         3.6.3       SCPI Insessages       3-52         3.6.3       SCPI Subsystem Command/Queries       3-52         3.6.3.1       ABORT Subsystem	3.5.3.1.2		
3.5.3.2 I       RS 232 Serial Port Setup.       3.45         3.5.3.2.1 Select Baud Rate       3.45         3.5.3.2.2 Configure XON/XOFF Protocol.       3.45         3.5.3.2.3 Configure Prompt Mode       3.45         3.5.3.3 Estabilish communication language       3.46         3.5.3.4 BIT 4882 Compatibility.       3.46         3.5.5 BIT 4886 Compatibility.       3.46         3.5.5 BOP VISA Instrument driver       3.48         3.5.6 RS 232-C Operation       3.48         3.5.6.1 Serial Interface       3.48         3.5.6.2 RS 232 Implementation       3.49         3.5.6.2.1 XON XOFF Method       3.50         3.5.6.2.2 Echo Mode       3.50         3.5.6.3 Using SCPI commands for RS 232 Communication       3.51         3.5.6.3 Using SCPI commands for RS 232 Communication       3.51         3.6.5 SCPI Programming       3.51         3.6.1 SCPI Messages       3.52         3.6.2 Common Commands/Queries       3.52         3.6.3 SCPI Subsystem Command/Cluery Structure       3.52         3.6.3.1 ABORT Subsystem       3.52         3.6.3.2 DISPlay Subsystem       3.52         3.6.3.3 NITitate Subsystem       3.52         3.6.3.6 OUTPut Subsystem       3.53         3.6.3.1 CALibrate Subsystem	3.5.3.1.3		
3,5,3,2,1       Select Baud Rate       3.45         3,5,3,2,2       Configure XON/XOFF Protocol       3.45         3,5,3,3       Establish communication language       3.46         3,5,3,4       BIT 4882 Compatibility       3.46         3,5,3,5       BIT 4882 Compatibility       3.46         3,5,4       IEEE 488 (GPIB) Bus Protocol       3.46         3,5,6       BOP VISA Instrument driver       3.48         3,5,6       RS232-C Operation       3.48         3,5,6,1       Serial INterface       3.48         3,5,6,2       RS 232 Implementation       3.49         3,5,6,2,2       Echo Mode       3.50         3,5,6,2,3       Prompt Method       3.50         3,5,6,4       Isolating RS 232 Communication       3.51         3,5,6,4       Isolating RS 232 Communication Problems       3.51         3,6,1       SCPI Programming       3.51         3,6,3       SCPI Messages       3.52         3,6,3       SCPI Subsystem Command/Queries       3.52         3,6,3,4       LIST Subsystem       3.52         3,6,3,4       LIST Subsystem       3.52         3,6,3,6       OUTPut Subsystem       3.53         3,6,3,1       AEADRY Subsyste	3.5.3.2		
3.5.3.2.3       Configure Prompt Mode.       3-46         3.5.3.3       Establish communication language       3-46         3.5.3.5       BIT 4882 Compatibility       3-46         3.5.3.5       BIT 4886 Compatibility       3-46         3.5.4       IEEE 488 (GPIB) Bus Protocol       3-48         3.5.5       BOP VISA Instrument driver       3-48         3.5.6       RS232-C Operation       3-48         3.5.6.1       Serial INterface       3-48         3.5.6.2       RS 232 Implementation       3-48         3.5.6.2.1       XON XOFF Method       3-50         3.5.6.2.2       Echo Mode       3-50         3.5.6.3       Using SCPI commands for RS 232 Communication       3-51         3.5.6.4       Isolating RS 232 Communication Problems       3-51         3.6.1       SCPI Programming       3-51         3.6.2       Common Commands/Queries       3-52         3.6.3       SCPI Insessages       3-52         3.6.3       SCPI Busbystem Command/Query Structure       3-52         3.6.3.1       ABORT Subsystem       3-52         3.6.3.2       DISPlay Subsystem       3-52         3.6.3.3       INITiate Subsystem       3-52         3.6.3.4<	3.5.3.2.1	·	
3.5.3.2.3       Configure Prompt Mode.       3-46         3.5.3.3       Establish communication language       3-46         3.5.3.5       BIT 4882 Compatibility       3-46         3.5.3.5       BIT 4886 Compatibility       3-46         3.5.4       IEEE 488 (GPIB) Bus Protocol       3-48         3.5.5       BOP VISA Instrument driver       3-48         3.5.6       RS232-C Operation       3-48         3.5.6.1       Serial INterface       3-48         3.5.6.2       RS 232 Implementation       3-48         3.5.6.2.1       XON XOFF Method       3-50         3.5.6.2.2       Echo Mode       3-50         3.5.6.3       Using SCPI commands for RS 232 Communication       3-51         3.5.6.4       Isolating RS 232 Communication Problems       3-51         3.6.1       SCPI Programming       3-51         3.6.2       Common Commands/Queries       3-52         3.6.3       SCPI Insessages       3-52         3.6.3       SCPI Busbystem Command/Query Structure       3-52         3.6.3.1       ABORT Subsystem       3-52         3.6.3.2       DISPlay Subsystem       3-52         3.6.3.3       INITiate Subsystem       3-52         3.6.3.4<	3.5.3.2.2		
3.5.3.3       Establish communication language       3-46         3.5.3.4       BIT 4882 Compatibility       3-46         3.5.3.5       BIT 4886 Compatibility       3-46         3.5.4       IEEE 488 (GPIB) Bus Protocol       3-48         3.5.5       BOP VISA Instrument driver       3-48         3.5.6       RS232-C Operation       3-48         3.5.6.1       Serial INterface       3-48         3.5.6.2       RS 232 Implementation       3-48         3.5.6.2.1       XON XOFF Method       3-50         3.5.6.2.2       Echo Mode       3-50         3.5.6.3       Using SCPI commands for RS 232 Communication       3-51         3.5.6.3       Using SCPI commands for RS 232 Communication       3-51         3.5.6.1       SCPI Programming       3-51         3.6.1       SCPI Messages       3-52         3.6.2       Common Commands/Queries       3-52         3.6.3.1       ABORT Subsystem       3-52         3.6.3.2       DISPlay Subsystem       3-52         3.6.3.3       INTitate Subsystem       3-52         3.6.3.4       LIST Subsystem       3-52         3.6.3.5       MEAsure Subsystem       3-52         3.6.3.7       MEMory Su	3.5.3.2.3		
3.5.3.4       BIT 488C Compatibility       3-46         3.5.3.5       BIT 4886 (Compatibility       3-46         3.5.4       IEEE 488 (GPIB) Bus Protocol       3-46         3.5.5       BOP VISA Instrument driver       3-48         3.5.6       RS 232-C Operation       3-48         3.5.6.1       Serial INterface       3-48         3.5.6.2       RS 232 Implementation       3-49         3.5.6.2.1       XON XOFF Method       3-50         3.5.6.2.2       Echo Mode       3-50         3.5.6.2.3       Prompt Method       3-51         3.5.6.3       Prompt Method       3-51         3.5.6.4       Isolating RS 232 Communication Problems       3-51         3.6.3       SCPI Programming       3-51         3.6.1       SCPI Messages       3-52         3.6.2       Common Commands/Queries       3-52         3.6.3.1       ABORT Subsystem Command/Query Structure       3-52         3.6.3.2       DISPlay Subsystem       3-52         3.6.3.3.1       ABORT Subsystem       3-52         3.6.3.5       MEAURITE Subsystem       3-52         3.6.3.6       DISPlay Subsystem       3-52         3.6.3.7       MEMORY Subsystem       3-5			
3.5.3.5     BIT 4886 Compatibility     3-46       3.5.4     IEEE 488 (GPIB) Bus Protocol     3-46       3.5.5     BOP VISA Instrument driver     3-48       3.5.6     RS232-C Operation     3-48       3.5.6.1     Serial Interface     3-48       3.5.6.2     RS 232 Implementation     3-49       3.5.6.2.1     XON XOFF Method     3-50       3.5.6.2.3     Prompt Method     3-51       3.5.6.3     Using SCPI commands for RS 232 Communication     3-51       3.5.6     SCPI Programming     3-51       3.6.1     SCPI Programming     3-51       3.6.2     Common Commands/Queries     3-52       3.6.3     SCPI Subsystem Command/Query Structure     3-52       3.6.3.1     ABORT Subsystem     3-52       3.6.3.2     DISPlay Subsystem     3-52       3.6.3.3     INITiate Subsystem     3-52       3.6.3.4     LIST Subsystem     3-52       3.6.3.5     MEAsure Subsystem     3-52       3.6.3.6     OUTPut Subsystem     3-53       3.6.3.7     MEMory Subsystem     3-53       3.6.3.8     STATus Subsystem     3-53       3.6.3.1     SOURce: [VOLTage and [SOURce:] CURRent Subsystems     3-55       3.6.3.12     System Subsystem     3-56	3.5.3.4		
3.5.4     IEEE 488 (GPIB) Bus Protocol     3-46       3.5.5     BOP VISA Instrument driver     3-48       3.5.6     RS232-C Operation     3-48       3.5.6.1     Serial INterface     3-48       3.5.6.2     RS 232 Implementation     3-49       3.5.6.2.1     XON XOFF Method     3-50       3.5.6.2.2     Echo Mode     3-50       3.5.6.2.3     Prompt Method     3-51       3.5.6.4     Isolating RS 232 Communication     3-51       3.5.6.4     Isolating RS 232 Communication Problems     3-51       3.6.1     SCPI Programming     3-51       3.6.2     Common Commands/Queries     3-52       3.6.3     SCPI Messages     3-52       3.6.3     SCPI Messages     3-52       3.6.3.1     ABORT Subsystem Command/Query Structure     3-52       3.6.3.2     DISPlay Subsystem Command/Query Structure     3-52       3.6.3.2     DISPlay Subsystem     3-52       3.6.3.3     INITiate Subsystem     3-52       3.6.3.4     LIST Subsystem     3-52       3.6.3.5     MEASure Subsystem     3-52       3.6.3.6     OUTPut Subsystem     3-53       3.6.3.7     MEMory Subsystem     3-53       3.6.3.8     STATus Subsystem     3-53	3.5.3.5		
3.5.5     BOP VISA Instrument driver     3-48       3.5.6     RS232-C Operation     3-48       3.5.6.1     Serial Interface     3-48       3.5.6.2     RS 232 Implementation     3-49       3.5.6.2.1     XON XOFF Method     3-50       3.5.6.2.2     Echo Mode     3-50       3.5.6.3     Using SCPI commands for RS 232 Communication     3-51       3.5.6.4     Isolating RS 232 Communication Problems     3-51       3.6.1     SCPI Programming     3-51       3.6.2     Common Commands/Queries     3-52       3.6.3     SCPI Subsystem Command/Query Structure     3-52       3.6.3.1     ABORt Subsystem     3-52       3.6.3.2     DISPlay Subsystem     3-52       3.6.3.3     INITiate Subsystem     3-52       3.6.3.4     LIST Subsystem     3-52       3.6.3.5     MEASure Subsystem     3-53       3.6.3.6     OUTPut Subsystem     3-53       3.6.3.7     MEMory Subsystem     3-53       3.6.3.8     STATus Subsystem     3-55       3.6.3.1     CALibrate Subsystem     3-55       3.6.3.1     Frogram Message Structure     3-56       3.6.4     Program Message Structure     3-57       3.6.4.2     Keyword     3-58       3.6.	3.5.4		
3.5.6       RS232-C Operation       3-48         3.5.6.1       Serial INterface       3-48         3.5.6.2       RS 232 Implementation       3-49         3.5.6.2.1       XON XOFF Method       3-50         3.5.6.2.2       Echo Mode       3-50         3.5.6.2.3       Prompt Method       3-51         3.5.6.3       Using SCPI commands for RS 232 Communication       3-51         3.5.6.4       Isolating RS 232 Communication Problems       3-51         3.6.       SCPI Programming       3-51         3.6.1       SCPI Messages       3-52         3.6.2       Common Commands/Queries       3-52         3.6.3       SCPI Subsystem Command/Query Structure       3-52         3.6.3.1       ABORI Subsystem       3-52         3.6.3.2       DISPlay Subsystem       3-52         3.6.3.3       INITiate Subsystem       3-52         3.6.3.4       LIST Subsystem       3-52         3.6.3.5       MEASure Subsystem       3-53         3.6.3.6       OUTPut Subsystem       3-53         3.6.3.7       MEMory Subsystem       3-53         3.6.3.1       ISOURce:JVOLTage and [SOURce:]CURRent Subsystems       3-55         3.6.3.1.1       CALibrate	3.5.5		
3.5.6.1       Serial INterface       3.48         3.5.6.2       RS 232 Implementation       3.49         3.5.6.2.1       XON XOFF Method       3.50         3.5.6.2.2       Echo Mode       3.50         3.5.6.3       Prompt Method       3.51         3.5.6.3       Using SCPI commands for RS 232 Communication       3.51         3.5.6.4       Isolating RS 232 Communication Problems       3.51         3.6.1       SCPI Programming       3.51         3.6.1       SCPI Messages       3.52         3.6.2       Common Commands/Queries       3.52         3.6.3       SCPI Subsystem Command/Query Structure       3.52         3.6.3.1       ABORt Subsystem       3.52         3.6.3.2       DISPIay Subsystem       3.52         3.6.3.3       INITiate Subsystem       3.52         3.6.3.4       LIST Subsystem       3.52         3.6.3.5       MEAsure Subsystem       3.53         3.6.3.6       OUTPut Subsystem       3.53         3.6.3.7       MEMory Subsystem       3.53         3.6.3.8       STATus Subsystem       3.53         3.6.3.9       TRIGger subsystem       3.55         3.6.3.10       [SOURce:]VOLTage and [SOURce:]CURRent Subs	3.5.6		
3.5.6.2       RS 232 Implementation       3-49         3.5.6.2.1       XON XOFF Method       3-50         3.5.6.2.2       Echo Mode       3-50         3.5.6.3       Prompt Method       3-51         3.5.6.4       Isolating RS 232 Communication       3-51         3.6.4       Isolating RS 232 Communication Problems       3-51         3.6.1       SCPI Programming       3-51         3.6.1       SCPI Messages       3-52         3.6.2       Common Commands/Queries       3-52         3.6.3       SCPI Subsystem Command/Query Structure       3-52         3.6.3.1       ABORT Subsystem       3-52         3.6.3.2       DISPlay Subsystem       3-52         3.6.3.3       INITiate Subsystem       3-52         3.6.3.4       LIST Subsystem       3-52         3.6.3.5       MEASure Subsystem       3-53         3.6.3.6       OUTPUT Subsystem       3-53         3.6.3.8       STATus Subsystem       3-53         3.6.3.9       TRIGger subsystem       3-53         3.6.3.1       GALibrate Subsystem       3-55         3.6.3.1       CALibrate Subsystem       3-56         3.6.3.1.1       Forgotten Passwords       3-56 </td <td></td> <td>·</td> <td></td>		·	
3.5.6.2.1       XON XOFF Method       3-50         3.5.6.2.2       Echo Mode       3-50         3.5.6.2.3       Prompt Method       3-51         3.5.6.4       Isolating RS 232 Communication Problems       3-51         3.6.1       SCPI Programming       3-51         3.6.1       SCPI Messages       3-52         3.6.2       Common Commands/Queries       3-52         3.6.3       SCPI Subsystem Command/Query Structure       3-52         3.6.3.1       ABORT Subsystem       3-52         3.6.3.2       DISPlay Subsystem       3-52         3.6.3.3       INITiate Subsystem       3-52         3.6.3.4       LIST Subsystem       3-52         3.6.3.5       MEASure Subsystem       3-53         3.6.3.6       OUTPut Subsystem       3-53         3.6.3.7       MEMory Subsystem       3-53         3.6.3.9       TRIGger subsystem       3-55         3.6.3.10       SOURce:JVOLTage and [SOURce:]CURRent Subsystems       3-55         3.6.3.12       System Subsystem       3-56         3.6.3.12.1       Forgoathe Passwords       3-56         3.6.4.4       Program Message Structure       3-57         3.6.4.5       Data Separator	3.5.6.2		
3.5.6.2.2       Echo Mode       3-50         3.5.6.2.3       Prompt Method       3-51         3.5.6.3       Using SCPI commands for RS 232 Communication       3-51         3.5.6.4       Isolating RS 232 Communication Problems       3-51         3.6.       SCPI Programming       3-51         3.6.1       SCPI Messages       3-52         3.6.2       Common Commands/Queries       3-52         3.6.3       SCPI Subsystem Command/Query Structure       3-52         3.6.3.1       ABORI Subsystem       3-52         3.6.3.2       DISPlay Subsystem       3-52         3.6.3.2       DISPlay Subsystem       3-52         3.6.3.3       INITiate Subsystem       3-52         3.6.3.4       LIST Subsystem       3-52         3.6.3.5       MEASure Subsystem       3-53         3.6.3.6       OUTPut Subsystem       3-53         3.6.3.7       MEMory Subsystem       3-53         3.6.3.8       STATus Subsystem       3-53         3.6.3.9       TRIGger subsystem       3-55         3.6.3.11       CALibrate Subsystem       3-55         3.6.3.2       System Subsystem       3-56         3.6.3.1       CALibrate Subsystem       3-56 <td>3.5.6.2.1</td> <td>·</td> <td></td>	3.5.6.2.1	·	
3.5.6.2.3       Prompt Method       3-51         3.5.6.3       Using SCPI commands for RS 232 Communication       3-51         3.5.6.4       Isolating RS 232 Communication Problems       3-51         3.6.1       SCPI Programming       3-51         3.6.1       SCPI Messages       3-52         3.6.2       Common Commands/Queries       3-52         3.6.3       SCPI Subsystem Command/Query Structure       3-52         3.6.3.1       ABORt Subsystem       3-52         3.6.3.2       DISPIay Subsystem       3-52         3.6.3.3       INITiate Subsystem       3-52         3.6.3.4       LIST Subsystem       3-52         3.6.3.5       MEASure Subsystem       3-53         3.6.3.6       OUTPut Subsystem       3-53         3.6.3.7       MEMory Subsystem       3-53         3.6.3.8       STATus Subsystem       3-53         3.6.3.9       TRIGger subsystem       3-55         3.6.3.10       ISOURce: VOLTage and [SOURce:]CURRent Subsystems       3-56         3.6.3.11       CALibrate Subsystem       3-56         3.6.3.12       Forgotten Passwords       3-56         3.6.3.1       Frogram Message Structure       3-57         3.6.4.1			
3.5.6.3       Using SCPI commands for RS 232 Communication       3-51         3.5.6.4       Isolating RS 232 Communication Problems       3-51         3.6       SCPI Programming       3-51         3.6.1       SCPI Messages       3-52         3.6.2       Common Commands/Queries       3-52         3.6.3       SCPI Subsystem Command/Query Structure       3-52         3.6.3.1       ABORI Subsystem       3-52         3.6.3.2       DISPlay Subsystem       3-52         3.6.3.3       INITiate Subsystem       3-52         3.6.3.4       LIST Subsystem       3-52         3.6.3.5       MEASure Subsystem       3-53         3.6.3.6       OUTPut Subsystem       3-53         3.6.3.7       MEMory Subsystem       3-53         3.6.3.8       STATus Subsystem       3-53         3.6.3.9       TRIGger subsystem       3-55         3.6.3.10       [SOURce:]VOLTage and [SOURce:]CURRent Subsystems       3-55         3.6.3.11       CALibrate Subsystem       3-56         3.6.3.12.1       Forgotten Passwords       3-56         3.6.3.12.1       Forgotten Passwords       3-56         3.6.4.2       Keyword Separator       3-57         3.6.4.3	3.5.6.2.3		
3.5.6.4     Isolating RS 232 Communication Problems     3-51       3.6     SCPI Programming     3-51       3.6.1     SCPI Messages     3-52       3.6.2     Common Commands/Queries     3-52       3.6.3     SCPI Subsystem Command/Query Structure     3-52       3.6.3.1     ABORT Subsystem     3-52       3.6.3.2     DISPlay Subsystem     3-52       3.6.3.3     INITiate Subsystem     3-52       3.6.3.4     LIST Subsystem     3-52       3.6.3.5     MEASure Subsystem     3-53       3.6.3.6     OUTPut Subsystem     3-53       3.6.3.7     MEMory Subsystem     3-53       3.6.3.8     STATus Subsystem     3-53       3.6.3.9     TRIGger subsystem     3-55       3.6.3.10     [SOURce:]VOLTage and [SOURce:]CURRent Subsystems     3-55       3.6.3.11     CALibrate Subsystem     3-56       3.6.3.12     System Subsystem     3-56       3.6.3.12     Forgotten Passwords     3-56       3.6.4.1     Keyword     3-57       3.6.4.2     Keyword Separator     3-57       3.6.4.3     Query Indicator     3-58       3.6.4.4     Data     3-58       3.6.4.5     Data Separator     3-58       3.6.4.6     Message Unit Sep			
3.6       SCPI Programming       3-51         3.6.1       SCPI Messages       3-52         3.6.2       Common Commands/Queries       3-52         3.6.3       SCPI Subsystem Command/Query Structure       3-52         3.6.3.1       ABORt Subsystem       3-52         3.6.3.2       DISPlay Subsystem       3-52         3.6.3.3       INITiate Subsystem       3-52         3.6.3.4       LIST Subsystem       3-53         3.6.3.5       MEASure Subsystem       3-53         3.6.3.6       OUTPut Subsystem       3-53         3.6.3.7       MEMory Subsystem       3-53         3.6.3.8       STATus Subsystem       3-55         3.6.3.9       TRIGger subsystem       3-55         3.6.3.10       [SOURce:]VOLTage and [SOURce:]CURRent Subsystems       3-55         3.6.3.11       CALibrate Subsystem       3-56         3.6.3.12       System Subsystem       3-56         3.6.3.11       Forgotten Passwords       3-56         3.6.4.1       Keyword       3-57         3.6.4.2       Keyword Separator       3-57         3.6.4.3       Query Indicator       3-58         3.6.4.4       Data       3-58         3.			
3.6.1       SCPI Messages       3-52         3.6.2       Common Commands/Queries       3-52         3.6.3       SCPI Subsystem Command/Query Structure       3-52         3.6.3.1       ABORt Subsystem       3-52         3.6.3.2       DISPlay Subsystem       3-52         3.6.3.3       INITiate Subsystem       3-52         3.6.3.4       LIST Subsystem       3-52         3.6.3.5       MEASure Subsystem       3-53         3.6.3.6       OUTPut Subsystem       3-53         3.6.3.7       MEMory Subsystem       3-53         3.6.3.8       STATus Subsystem       3-53         3.6.3.9       TRIGger subsystem       3-55         3.6.3.10       [SOURce:]VOLTage and [SOURce:]CURRent Subsystems       3-56         3.6.3.11       CALibrate Subsystem       3-56         3.6.3.12       System Subsystem       3-56         3.6.3.12.1       Forgotten Passwords       3-56         3.6.4.1       Keyword       3-57         3.6.4.2       Keyword Separator       3-57         3.6.4.3       Query Indicator       3-58         3.6.4.4       Data       3-58         3.6.4.5       Data Separator       3-58 <t< td=""><td>3.6</td><td></td><td></td></t<>	3.6		
3.6.2       Common Commands/Queries       3-52         3.6.3       SCPI Subsystem Command/Query Structure       3-52         3.6.3.1       ABORt Subsystem       3-52         3.6.3.2       DISPlay Subsystem       3-52         3.6.3.3       INITiate Subsystem       3-52         3.6.3.4       LIST Subsystem       3-52         3.6.3.5       MEASure Subsystem       3-53         3.6.3.6       OUTPut Subsystem       3-53         3.6.3.7       MEMory Subsystem       3-53         3.6.3.8       STATus Subsystem       3-53         3.6.3.9       TRIGger subsystem       3-55         3.6.3.10       [SOURce:]VOLTage and [SOURce:]CURRent Subsystems       3-55         3.6.3.11       CALibrate Subsystem       3-56         3.6.3.12.1       Forgotten Passwords       3-56         3.6.3.12.1       Forgotten Passwords       3-56         3.6.4.2       Keyword       3-57         3.6.4.3       Query Indicator       3-58         3.6.4.4       Data       3-58         3.6.4.5       Data Separator       3-58         3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58	3.6.1		
3.6.3       SCPI Subsystem Command/Query Structure.       3-52         3.6.3.1       ABORt Subsystem.       3-52         3.6.3.2       DISPlay Subsystem.       3-52         3.6.3.3       INITiate Subsystem.       3-52         3.6.3.4       LIST Subsystem.       3-52         3.6.3.5       MEASure Subsystem.       3-53         3.6.3.6       OUTPut Subsystem.       3-53         3.6.3.7       MEMory Subsystem.       3-53         3.6.3.8       STATus Subsystem.       3-53         3.6.3.9       TRIGger subsystem.       3-55         3.6.3.10       [SOURce:]VOLTage and [SOURce:]CURRent Subsystems.       3-55         3.6.3.11       CALibrate Subsystem.       3-56         3.6.3.12       System Subsystem.       3-56         3.6.3.1.1       Forgotten Passwords.       3-56         3.6.4.4       Program Message Structure.       3-57         3.6.4.2       Keyword Separator.       3-58         3.6.4.5       Data       3-58         3.6.4.6       Message Unit Separator.       3-58         3.6.4.7       Root Specifier.       3-58         3.6.4.8       Message Terminator.       3-59         3.6.5       Understanding The Command	3.6.2	· ·	
3.6.3.1       ABORt Subsystem       3-52         3.6.3.2       DISPlay Subsystem       3-52         3.6.3.3       INITiate Subsystem       3-52         3.6.3.4       LIST Subsystem       3-52         3.6.3.5       MEASure Subsystem       3-53         3.6.3.6       OUTPut Subsystem       3-53         3.6.3.7       MEMory Subsystem       3-53         3.6.3.8       STATus Subsystem       3-55         3.6.3.9       TRIGger subsystem       3-55         3.6.3.10       [SOURce:]VOLTage and [SOURce:]CURRent Subsystems       3-55         3.6.3.11       CALibrate Subsystem       3-56         3.6.3.12       System Subsystem       3-56         3.6.3.12.1       Forgotten Passwords       3-56         3.6.4.4       Program Message Structure       3-57         3.6.4.2       Keyword       3-57         3.6.4.3       Query Indicator       3-58         3.6.4.4       Data       3-58         3.6.4.5       Data Separator       3-58         3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-59         3.6.	3.6.3		
3.6.3.2       DISPlay Subsystem       3-52         3.6.3.3       INITiate Subsystem       3-52         3.6.3.4       LIST Subsystem       3-52         3.6.3.5       MEASure Subsystem       3-53         3.6.3.6       OUTPut Subsystem       3-53         3.6.3.7       MEMory Subsystem       3-53         3.6.3.8       STATus Subsystem       3-55         3.6.3.9       TRIGger subsystem       3-55         3.6.3.10       [SOURce:]VOLTage and [SOURce:]CURRent Subsystems       3-55         3.6.3.11       CALibrate Subsystem       3-56         3.6.3.12       System Subsystem       3-56         3.6.3.12.1       Forgotten Passwords       3-56         3.6.4.4       Program Message Structure       3-57         3.6.4.1       Keyword       3-57         3.6.4.2       Keyword Separator       3-58         3.6.4.3       Query Indicator       3-58         3.6.4.5       Data       3-58         3.6.4.5       Data Separator       3-58         3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-59         3.	3.6.3.1		
3.6.3.3       INITiate Subsystem			
3.6.3.4       LIST Subsystem       3-52         3.6.3.5       MEASure Subsystem       3-53         3.6.3.6       OUTPut Subsystem       3-53         3.6.3.7       MEMory Subsystem       3-53         3.6.3.8       STATus Subsystem       3-55         3.6.3.9       TRIGger subsystem       3-55         3.6.3.10       [SOURce:]VOLTage and [SOURce:]CURRent Subsystems       3-56         3.6.3.11       CALibrate Subsystem       3-56         3.6.3.12       System Subsystem       3-56         3.6.3.12.1       Forgotten Passwords       3-56         3.6.4       Program Message Structure       3-57         3.6.4.1       Keyword       3-57         3.6.4.2       Keyword Separator       3-57         3.6.4.3       Query Indicator       3-58         3.6.4.4       Data       3-58         3.6.4.5       Data Separator       3-58         3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-59         3.6.5       Understanding The Command Structure       3-59	3.6.3.3		
3.6.3.5       MEASure Subsystem       3-53         3.6.3.6       OUTPut Subsystem       3-53         3.6.3.7       MEMory Subsystem       3-53         3.6.3.8       STATus Subsystem       3-55         3.6.3.9       TRIGger subsystem       3-55         3.6.3.10       [SOURce:]VOLTage and [SOURce:]CURRent Subsystems       3-55         3.6.3.11       CALibrate Subsystem       3-56         3.6.3.12       System Subsystem       3-56         3.6.3.12.1       Forgotten Passwords       3-56         3.6.4       Program Message Structure       3-57         3.6.4.1       Keyword       3-57         3.6.4.2       Keyword Separator       3-57         3.6.4.3       Query Indicator       3-58         3.6.4.4       Data       3-58         3.6.4.5       Data Separator       3-58         3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-59         3.6.5       Understanding The Command Structure       3-59			
3.6.3.6       OUTPut Subsystem       3-53         3.6.3.7       MEMory Subsystem       3-53         3.6.3.8       STATus Subsystem       3-55         3.6.3.9       TRIGger subsystem       3-55         3.6.3.10       [SOURce:]VOLTage and [SOURce:]CURRent Subsystems       3-55         3.6.3.11       CALibrate Subsystem       3-56         3.6.3.12       System Subsystem       3-56         3.6.3.12.1       Forgotten Passwords       3-56         3.6.4       Program Message Structure       3-57         3.6.4.1       Keyword       3-57         3.6.4.2       Keyword Separator       3-57         3.6.4.3       Query Indicator       3-58         3.6.4.4       Data       3-58         3.6.4.5       Data Separator       3-58         3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-59         3.6.5       Understanding The Command Structure       3-59	3.6.3.5		
3.6.3.7       MEMory Subsystem       3-53         3.6.3.8       STATus Subsystem       3-55         3.6.3.9       TRIGger subsystem       3-55         3.6.3.10       [SOURce:]VOLTage and [SOURce:]CURRent Subsystems       3-55         3.6.3.11       CALibrate Subsystem       3-56         3.6.3.12       System Subsystem       3-56         3.6.3.12.1       Forgotten Passwords       3-56         3.6.4       Program Message Structure       3-57         3.6.4.1       Keyword       3-57         3.6.4.2       Keyword Separator       3-57         3.6.4.3       Query Indicator       3-58         3.6.4.4       Data       3-58         3.6.4.5       Data Separator       3-58         3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-59         3.6.5       Understanding The Command Structure       3-59	3.6.3.6		
3.6.3.8       STATus Subsystem       3-55         3.6.3.9       TRIGger subsystem       3-55         3.6.3.10       [SOURce:]VOLTage and [SOURce:]CURRent Subsystems       3-55         3.6.3.11       CALibrate Subsystem       3-56         3.6.3.12       System Subsystem       3-56         3.6.3.12.1       Forgotten Passwords       3-56         3.6.4       Program Message Structure       3-57         3.6.4.1       Keyword       3-57         3.6.4.2       Keyword Separator       3-57         3.6.4.3       Query Indicator       3-58         3.6.4.4       Data       3-58         3.6.4.5       Data Separator       3-58         3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-59         3.6.5       Understanding The Command Structure       3-59			
3.6.3.9       TRIGger subsystem       3-55         3.6.3.10       [SOURce:]VOLTage and [SOURce:]CURRent Subsystems       3-55         3.6.3.11       CALibrate Subsystem       3-56         3.6.3.12       System Subsystem       3-56         3.6.3.12.1       Forgotten Passwords       3-56         3.6.4       Program Message Structure       3-57         3.6.4.1       Keyword       3-57         3.6.4.2       Keyword Separator       3-57         3.6.4.3       Query Indicator       3-58         3.6.4.4       Data       3-58         3.6.4.5       Data Separator       3-58         3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-58         3.6.5       Understanding The Command Structure       3-59		, ,	
3.6.3.10       [SOURce:]VOLTage and [SOURce:]CURRent Subsystems       3-55         3.6.3.11       CALibrate Subsystem       3-56         3.6.3.12       System Subsystem       3-56         3.6.3.12.1       Forgotten Passwords       3-56         3.6.4       Program Message Structure       3-57         3.6.4.1       Keyword       3-57         3.6.4.2       Keyword Separator       3-57         3.6.4.3       Query Indicator       3-58         3.6.4.4       Data       3-58         3.6.4.5       Data Separator       3-58         3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-59         3.6.5       Understanding The Command Structure       3-59		·	
3.6.3.11       CALibrate Subsystem       3-56         3.6.3.12       System Subsystem       3-56         3.6.3.12.1       Forgotten Passwords       3-56         3.6.4       Program Message Structure       3-57         3.6.4.1       Keyword       3-57         3.6.4.2       Keyword Separator       3-57         3.6.4.3       Query Indicator       3-58         3.6.4.4       Data       3-58         3.6.4.5       Data Separator       3-58         3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-59         3.6.5       Understanding The Command Structure       3-59		•	
3.6.3.12       System Subsystem       3-56         3.6.3.12.1       Forgotten Passwords       3-56         3.6.4       Program Message Structure       3-57         3.6.4.1       Keyword       3-57         3.6.4.2       Keyword Separator       3-57         3.6.4.3       Query Indicator       3-58         3.6.4.4       Data       3-58         3.6.4.5       Data Separator       3-58         3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-59         3.6.5       Understanding The Command Structure       3-59			
3.6.3.12.1       Forgotten Passwords       3-56         3.6.4       Program Message Structure       3-57         3.6.4.1       Keyword       3-57         3.6.4.2       Keyword Separator       3-57         3.6.4.3       Query Indicator       3-58         3.6.4.4       Data       3-58         3.6.4.5       Data Separator       3-58         3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-59         3.6.5       Understanding The Command Structure       3-59		·	
3.6.4       Program Message Structure       3-57         3.6.4.1       Keyword       3-57         3.6.4.2       Keyword Separator       3-57         3.6.4.3       Query Indicator       3-58         3.6.4.4       Data       3-58         3.6.4.5       Data Separator       3-58         3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-59         3.6.5       Understanding The Command Structure       3-59			
3.6.4.1       Keyword       3-57         3.6.4.2       Keyword Separator       3-57         3.6.4.3       Query Indicator       3-58         3.6.4.4       Data       3-58         3.6.4.5       Data Separator       3-58         3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-59         3.6.5       Understanding The Command Structure       3-59		<del>z</del>	
3.6.4.2       Keyword Separator       3-57         3.6.4.3       Query Indicator       3-58         3.6.4.4       Data       3-58         3.6.4.5       Data Separator       3-58         3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-59         3.6.5       Understanding The Command Structure       3-59		· · · · · · · · · · · · · · · · · · ·	
3.6.4.3       Query Indicator       3-58         3.6.4.4       Data       3-58         3.6.4.5       Data Separator       3-58         3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-59         3.6.5       Understanding The Command Structure       3-59			
3.6.4.4       Data       3-58         3.6.4.5       Data Separator       3-58         3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-59         3.6.5       Understanding The Command Structure       3-59		· · · · · · · · · · · · · · · · · · ·	
3.6.4.5       Data Separator			
3.6.4.6       Message Unit Separator       3-58         3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-59         3.6.5       Understanding The Command Structure       3-59			
3.6.4.7       Root Specifier       3-58         3.6.4.8       Message Terminator       3-59         3.6.5       Understanding The Command Structure       3-59		•	
3.6.4.8 Message Terminator 3-59 3.6.5 Understanding The Command Structure 3-59		· ·	
3.6.5 Understanding The Command Structure		·	
		· · · · · · · · · · · · · · · · · · ·	
	3.6.6		

SECTION		PAGE
3.6.7	Status Reporting	3-60
3.6.7.1	Status Reporting Structure	
3.6.7.2	Operational Status Register	3-62
3.6.7.3	QUEStionable Status Register	
3.6.8	SCPI Program Examples	
SECTIO	ON 4 - CALIBRATION	
4.1	General	4-1
4.2	Test Equipment Requirements	4-3
4.3	Calibration using Remote SCPI commands via GPIB or RS 232 Interface	4-4
4.3.1	Calibration Procedure using SCPI Commands	4-5
4.4	Calibration Using Front Panel Keypad in Local Mode	4-10
4.4.1	Understanding the Calibration Process	4-10
4.4.2	Calibration Procedure using Local Mode	4-12
4.4.3	Calibration using VISA Driver Soft Panel	4-16
4.5	Calibration Storage	4-16
APPEN	DIX A - SCPI COMMON COMMAND/QUERY DEFINITIONS  *CLS — Clear Status Command	A-1
A.3	*ESE — Standard Event Status Enable Command	A-1
A.4	*ESE? — Standard Event Status Enable Query	A-2
A.5	*ESR? — Event Status Register Query	A-2
A.6	*IDN? — Identification Query	A-2
A.7	*OPC — Operation Complete Command	A-2
A.8	*OPC? — Operation Complete Query	
A.9	*OPT? — Options Query	
A.10	*RCL — Recall Command	A-4
A.11	*RST — Reset Command	
A.12	*SAV — Save Command	A-4
A.13	*SRE — Service Request Enable Command	
A.14	*SRE? — Service Request Enable Query	
A.15	*STB? — Status Byte Register Query	
A.16	*TRG — Trigger Command	
A.17	*TST? — Self Test Query	
A.18  APPEN	*WAI — Wait-To-Continue Command  DIX B - SCPI COMMAND/QUERY DEFINITIONS	A-0
B.1	Introduction	B-1
Б.1 В.2	Numerical Values	
B.3	ABORt Command	
B.4	CAL Commands and Queries	
B.5	INITiate[:IMMediate] Command	
B.6	INITiate:CONTinuous Command	
B.7	INITiate:CONTinuous Query	
B.8	MEASure[:SCALar]:CURRent[:DC]? Query	
B.9	MEASure[:SCALar]:VOLTage[:DC]? Query	
B.10	MEMory:RELoad Command	
B.11	MEMory:UPDate Command	
B.12	OUTPut[:STATe] Command	
B.13	OUTPut[:STATe] Query	
B.14	OUTPut:MODE Command	
B.15	OUTPut:MODE? Query	
B.16	[SOURce:]FUNCtion:MODE Command	

SECTION		PAGE
B.17	[SOURce:]FUNCtion:MODE? Query	B-5
B.18	SOURce: FUNCtion: MODE: TRIGger Command	
B.19	[SOURce:]FUNCtion:MODE:TRIGger? Query	
B.20	[SOURce:]LIST:CLEar Command	
B.21	SOURce: LIST: COUNT Command	
B.22	SOURce: LIST: COUNT? Query	
B.23	SOURce: LIST:CURRent Command	
B.24	SOURce: LIST: CURRent? Query	
B.25	[SOURce:]LIST:CURR:APPLy Command	
B.26	[SOURce:]LIST:CURRent:SWEep Command	
B.27	[SOURce:]LIST:CURRent:SWEep? Query	
B.28	SOURce: LIST:CURRent:POINts? Query	
B.29	[SOURce:]LIST:DWELI Command	
B.30	SOURce: LIST:DWELI ? Query	
B.31	[SOURce:]LIST:DWELI : Query	
B.32	[SOURce:]LIST:QUERy Command	
B.33	[SOURce:]LIST:QUERy? Query	
B.34	[SOURce:]LIST:RESolution? Query	
B.35	[SOURce:]LIST:VOLTage Command	
B.36	SOURce: LIST:VOLTage? Query	
B.37	[SOURce:]LIST:VOLT:APPLy Command	
B.38	[SOURce:]LIST:VOLTage:SWEep Command	
B.39	[SOURce:]LIST:VOLTage:SWEep Command	
B.40	[SOURce:]LIST:VOLTage:POINts? Query	
B.41	[SOURce:]CURRent[:LEVel][:IMMediate][:AMPlitude] Command	
B.42 B.43	[SOURce:]CURRent[:LEVel][:IMMediate][:AMPlitude] Query	
	[SOURce:]CURRent[:LEVel]:LIMit[:BOTH] Command	
B.44	[SOURce:]CURRent[:LEVel]:LIMit[:BOTH]? Query	
B.45	[SOURce:]CURRent[:LEVel]:LIMit::NEG Command	
B.46 B.47		
	[SOURce:]CURRent[:LEVel]:LIMit::POS Command	
B.48	[SOURce:]CURRent[:LEVel]:LIMit::POS? Query	
B.49	[SOURce:]CURRent:MODE Command	
B.50	[SOURce:]CURRent:MODe? Query	
B.51	[SOURce:]CURRent[:LEVel]:PROTect[:BOTH] Command	
B.52	[SOURce:]CURRent[:LEVel]:PROTect[:BOTH] Query	
B.53	[SOURce:]CURRent[:LEVel]:PROTect:MODE Command	
B.54	[SOURce:]CURRent[:LEVel]:PROTect:MODE? Query	
B.55	[SOURce:]CURRent[:LEVel]:PROTect:NeGative Command	
B.56	[SOURce:]CURRent[:LEVel]:PROTect:NeGative? Query	
B.57	[SOURce:]CURRent[:LEVel]:PROTect:POSitive Command	
B.58	[SOURce:]CURRent[:LEVel]:PROTect:POSitive? Query	
B.59	[SOURce:]CURRent[:LEVel]:PROTect:LIMit[:BOTH] Command	
B.60	[SOURce:]CURRent[:LEVel]:PROTect:LIMit[:BOTH]? Query	
B.61	[SOURce:]CURRent[:LEVel]:PROTect:LIMit:NeGative Command	
B.62	[SOURce:]CURRent[:LEVel]:PROTect:LIMit:NeGative? Query	
B.63	[SOURce:]CURRent[:LEVel]:PROTect:LIMit:POSitive Command	
B.64	[SOURce:]CURRent[:LEVel]:PROTect:LIMit:POSitive? Query	
B.65	[SOURce:]CURRent[:LEVel]:TRIGgered[:AMPlitude] Command	
B.66	[SOURce:]CURRent[:LEVel]:TRIGgered[:AMPlitude]? Query	
B.67	[SOURce:]VOLTage[:LEVel][:IMMediate][:AMPlitude] Command	
B.68	[SOURce:]VOLTage[:LEVel][:IMMediate][:AMPlitude]? Query	
B.69	.[SOURce:]VOLTage[:LEVel]:LIMit[:BOTH] Command	
B.70	[SOURce:]VOLTage[:LEVel]:LIMit[:BOTH]? Query	
B.71	[SOURce:]VOLTage[:LEVel]:LIMit:NEGative Command	
B.72	[SOURce:]VOLTage[:LEVel]:LIMit:NEGative? Query	
B.73	[SOURce:]VOLTage[:LEVel]:LIMit:positive Command	B-17

BOP-1K 022108

SECTION		PAGE
B.74	[SOURce:]VOLTage[:LEVel]:LIMit:positive? Query	B-17
B.75	[SOURce:]VOLTage:MODe Command	
B.76	[SOURce:]VOLTage:MODE? Query	B-17
B.77	[SOURce:]VOLTage[:LEVel]:PROTect:BOTH Command	B-17
B.78	[SOURce:]VOLTage[:LEVel]:PROTect[:BOTH]? Query	B-18
B.79	[SOURce:]VOLTage[:LEVel]:PROTect:MODE Command	
B.80	[SOURce:]VOLTage[:LEVel]:PROTect:MODE? Query	B-18
B.81	[SOURce:]VOLTage[:LEVel]:PROTect:NeGative Command	B-18
B.82	[SOURce:]VOLTage[:LEVel]:PROTect:NeGative? Query	B-18
B.83	[SOURce:]VOLTage[:LEVel]:PROTect:POSitive Command	B-18
B.84	[SOURce:]VOLTage[:LEVel]:PROTect:POSitive? Query	B-18
B.85	[SOURce:]VOLTage[:LEVel]:PROTect:LIMit:BOTH Command	B-19
B.86	[SOURce:]VOLTage[:LEVel]:PROTect:LIMit[:BOTH]? Query	B-19
B.87	[SOURce:]VOLTage[:LEVel]:PROTect:LIMit:NeGative Command	B-19
B.88	[SOURce:]VOLTage[:LEVel]:PROTect:LIMit:NeGative? Query	B-19
B.89	[SOURce:]VOLTage[:LEVel]:PROTect:LIMit:POSitive Command	B-19
B.90	[SOURce:]VOLTage[:LEVel]:PROTect:LIMit:POSitive? Query	B-19
B.91	[SOURce:]VOLTage[:LEVel]:TRIGgered[:AMPlitude] Command	B-20
B.92	[SOURce:]VOLTage[:LEVel]:TRIGgered[:AMPlitude]? Query	
B.93	STATus:OPERation:CONDition? Query	B-20
B.94	STATus:OPERation:ENABle Command	B-20
B.95	STATus:OPERation:ENABle? Query	B-20
B.96	STATus:OPERation[:EVENt] Query	B-20
B.97	STATus:PRESet Command	B-21
B.98	STATus:QUEStionable[:EVENt]? Query	B-21
B.99	STATus:QUEStionable:CONDition? Query	B-21
B.100	STATus:QUEStionable:ENABle Command	B-21
B.101	STATus:questionable:ENABle? Query	B-21
B.102	SYSTem:COMMunication:GPIB:ADDRess Command	B-21
B.103	SYSTem:COMMunication:GPIB:ADDRess? Query	B-22
B.104	SYSTem:ERRor? Query	B-22
B.105	SYSTem:ERRor:CODE? Query	B-22
B.106	SYSTem:ERRor:CODE:ALL? Query	B-22
B.107	SYSTem:KEYBoard Command	B-22
B.108	SYSTem:KEYBoard? Query	
B.109	SYSTem:PASSword:CENable Command	
B.110	SYSTem:PASSword:CDISable Command	
B.111	SYSTem:PASSword:NEW Command	B-22
B.112	SYSTem:PASSword:STATe? Query	B-23
B.113	SYSTem:REMote Command	B-23
B.114	SYSTem:REMote? Query	
B.115	SYSTem:SECurity:IMMediate Command	B-24
B.116	SYSTem:SET Command	B-24
B.117	SYSTem:SET? Query	
B.118	SYSTem:VERSion? Query	B-25
B.119	TRIGger:SOURce Command	B-25
B.120	TRIGger:SOURce? Query	B-25

## **LIST OF FIGURES**

FIGURE	TITLE	PAGE
1-1	High Power BOP Series Power Supply	x
1-1	1000W BOP Power Supply, Outline Drawing	
1-2	BOP Output Characteristics	1-14
2-1	BOP Series Rear Panel	
2-2	Load Connections, Local Sensing	
2-3	Load Connections, Remote Sensing	
2-4	Parallel Configuration, Local Sensing, Typical	
2-5	Parallel Configuration, Remote Sensing, Typical	
2-6	Series Configuration, Local Sensing, Typical	
2-7	Series Configuration, Remote Sensing, Typical	
2-8	Typical Master/Slave Protection Interconnections	
2-9	Master Power Up Screen	
2-10 2-11	Power On Default Screen for Master Unit	
2-11 2-12	Power On Default Screen for Slave Unit	
2-12 3-1	BOP Series Front Panel	
3-1	Front Panel Keypad	
3-3	Power-up Screen Showing Graphic Meters	
3-4	Power-up Screen Showing Time Line Graph	
3-5	Password Protection Menu, Factory Defaults	
3-6	General Setup Menu	
3-7	Max/Min Settings Menu	
3-8	Saved Setups Menu	
3-9	Saved Waveforms Menu	
3-10	Waveform Settings Menu	
3-11	Sample Waveform	
3-12	Remote Shutdown Using External Power, Standalone or Multiple units	
3-13	Remote Shutdown Using Internal Power, Standalone Units	
3-14	Remote Shutdown Using Internal Power, Multiple Units,	3-35
3-15	Remote Standby, Standalone or Multiple Units	3-36
3-16	Programming Example to Verify Previous Command has Completed	3-43
3-17	RS 232 Implementation	
3-18	Tree Diagram of SCPI Commands Used with BOP Power Supply	
3-19	Message Structure	
3-20	Status Reporting Structure	
3-21	Typical Example Of BOP Power Supply Program Using SCPI Commands	
4-1	Calibration Setup	
4-2	Current Shunt (Sense Resistor) Connections	
4-3	Main Calibration Screen	
A-1	GPIB Commands	
B-1	Programming the Output	
B-2	Using LIST Commands and Queries	
B-3	Setting Limits	
B-4	Using Status Commands and Queries  Setting the Unit to Remote Mode via Serial (RS 232) Port	
B-5 B-6	Using System Commands and Queries	
D-0	USING UVSICIN CONTINIANUS AND WALLES	D-ZJ

## **LIST OF TABLES**

TABLE	TITLE	PAGE
1-1	BOP 1000 Watt Model Parameters	1-1
1-2	BOP General Specifications	1-2
1-3	Equipment Supplied	1-15
1-4	Safety Symbols	1-15
1-5	Accessories	1-16
2-1	Rear Panel Connector Functions	2-2
2-2	IEEE 1118 Connector Input/Output Pin Assignments	2-3
2-3	Trigger Port Pin Assignments	2-3
2-4	External Protection Connector Input/Output Pin Assignments	
2-5	RS232C PORT Input/Output Pin Assignments	2-4
2-6	Parallel/Serial Control Out Port Pin Assignments	
2-7	Parallel/Serial Control In Port Pin Assignments	
2-8	Parallel/Serial Protect In Port Pin Assignments	
2-9	Parallel/Serial Protect Out Port Pin Assignments	
2-10	Analog I/O Port Input/Output Pin Assignments	
2-11	IEEE 488 Port Input/Output Pin Assignments	
2-12	Multiple Units Menu Functions	
2-13	Slave Status Message Definitions	
3-1	Front Panel Controls and Indicators	
3-2	Special Key Functions	
3-3	Display (Operator Convenience) Menu Functions	
3-4	Voltage and Current Parameter Definitions	
3-5	Max/Min Settings Menu	
3-6	Power Supply Behavior when Output is set to OFF	
3-7	Examples Showing How Power-up Settings Function	
3-8	Save/recall menu	
3-9	Sine, Triangle and Ramp Waveform Frequency vs. Points	
3-10	Square Waveform Frequency vs. Points	
3-11	Waveform Segment Details Menu	
3-12	New Waveform Settings Menu	
3-13	Error Message Explanations	
3-14	Revisions/test Menu	
3-15	Analog Remote Setup Menu	
3-16	Interface Settings Menu	
3-17	Operation of #RST Command	
3-18	IEEE 488 (GPIB) Bus Interface Functions	
3-19	IEEE 488 (GPIB) Bus Command Mode Messages	
3-20	IEEE 488 (GPIB) Bus Data Mode Messages	
3-21	Rules Governing Shortform Keywords	
4-1	Calibration Summary	
4-2	Suggested Sense Resistors	
4-3	Voltage Calibration Measurements and Tolerances	
4-4	Current Calibration Measurements and Tolerances	
4-5	Calibration Storage	
A-1	IEEE 488.2 Command/query Index	
A-2	Standard Event Status Enable Register and Standard Event Status Register Bits	
A-3	Service Request Enable and Status Byte Register Bits	
A-4	Built-in test Error Codes	
B-1	SCPI Subsystem Command/query Index	
B-2	List Data Table	
B-3	Operation Condition Register, Operation Enable Register,	Б-0
50	and Operation Event Register Bits	R-20
B-4	Questionable Event Register, Questionable Condition Register	5 20
D 7	and Questionable Condition Enable Register Bits	R-21
B-5	Error Messages	




FIGURE 1-1. HIGH POWER BOP SERIES POWER SUPPLY

X BOP-1K 022108

#### **SECTION 1 - INTRODUCTION**

#### 1.1 SCOPE OF MANUAL

This manual contains instructions for the installation, operation and servicing of the BOP series of 1000 Watt rack-mounted, 4-quadrant bipolar, programmable, voltage and current stabilized d-c power supplies manufactured by Kepco, Inc., Flushing, New York, U.S.A.

NOTE: This manual does not apply to units with Firmware Rev less than 2.0.

### 1.2 GENERAL DESCRIPTION

The BOP Series (Figure 1-1), hereafter referred to as BOP, are true 4-quadrant programmable voltage and current power supplies, meaning they are capable of both sourcing and sinking power. These bipolar power supplies pass smoothly through zero without switching to provide true ± voltage and ± current. These BOP power supplies use switch mode technology for low dissipation. A bi-directional, isolating, a-c input power factor correcting (PFC) circuit recuperates energy sinked from an active load and sends it back into the line to maintain low dissipation.

These BOP power supplies are controlled digitally from a menu-driven front-panel keypad or one of the standard remote digital interfaces (GPIB or RS 232) to set voltage and current and the four protection limits (+voltage, -voltage, +current and -current.) A front panel rotary adjuster allows real-time adjustment of the output. A large LCD displays the settings, mode and the actual output voltage and current. Additionally, these BOP models can be remotely controlled by an analog ±10V input for the main channel (voltage or current), and a +1 to +10V input for the limit channels.

BOP models are suitable for driving inductive loads such as large magnets or motors, and for exercising batteries. They are also suitable for characterizing solar cell arrays, and powering many electrochemical reactions.

#### 1.3 SPECIFICATIONS

Table 1-1 below indicates parameters that vary for different 1000 Watt BOP models; Table 1-2 lists general specifications that apply to all 1000 Watt BOP models.

TABLE 1-1. BOP 1000 WATT MODEL PARAMETERS

	d-c Output Range		Closed Loop Gain	
Model	E <sub>O Max</sub>	I <sub>O Max</sub>	Voltage Channel	Current Channel
1000 WATT MODELS				
BOP 10-75MG	±10V d-c	±75A d-c	1.0	7.5
BOP 20-50MG	±20V d-c	±50A d-c	2.0	5.0
BOP 36-28MG	±36V d-c	±28A d-c	3.6	2.8
BOP 50-20MG	±50V d-c	±20A d-c	5.0	2.0
BOP 72-14MG	±72V d-c	±14A d-c	7.2	1.4
BOP 100-10MG	±100V d-c	±10A d-c	10.0	1.0

NOTE: When connecting active loads, the steady-state voltage of the active load must not exceed the maximum voltage rating of the BOP. Otherwise the overvoltage protection will shut down the power supply.

**TABLE 1-2. BOP GENERAL SPECIFICATIONS** 

SPECIFICA		RATING/DESCRIPTION	CONDITION
INPUT CHARACTERIS	STICS		
a-c voltage	nominal	230 Va-c	Cinala abasa
<del>-</del>	range	176 - 264 Va-c	Single phase
Frequency	nominal	50-60 Hz	>65 Hz, leakage
_	range	47 - 65 Hz	exceeds spec
Current	176 Va-c	9.5A	maximum
_	264 Va-c	6.4A	maximum
Dower footer	Source	0.99 minimum	nominal output nouser
Power factor —	Sink	0.97 minimum	nominal output power
Efficiency		65%	minimum
Switching frequency		70 KHz	PFC Stage
EMC Compliance		EN61326-1 (1997)	Class A equipment
EMC immunity to:	ESD	EN61000-4-2	Electrostatic discharge
_	Radiated RF	EN61000-4-3	
_	EFT	EN61000-4-4	Electrical fast transient/burst
_	Surges	EN61000-4-5	
_	Conducted RF	EN61000-4-6	
EMC emissions	Conducted	EN61000-3-2	harmonics
		EN61000-3-3	fluctuation & flicker
_	Conducted	EN55011/CISPR11	0.15 to 30 MHz
_	Radiated	EN55011/CISPR11	30 to 1000 MHz
Leakage current		3.5 mA	230V a-c, 47-63 Hz
Insulation coordination	Input	Installation Category II	
		Overvoltage Category II	
_	Output	Installation Category II	
		Overvoltage Category II	
_	Pollution degree	2	
OUTPUT CHARACTE	RISTICS <sup>1</sup>		
Type of stabilizer		Voltage-current, 4-quadrant	Switch mode
Switching frequency		100KHz	Output Stage
Source adjustment range	voltage	-100% to +100% of rating	0 to 50 deg C
_	current	-100% to +100% of rating	
Sink adjustment range	voltage	-100% to +100% of rating	Recuperated energy is sent
	current	-100% to +100% of rating	back into line for reuse
Programming	Voltage	14 bits / 0.03%	2% accuracy for Ext Ref Level (see PAR.
resolution / accuracy	Current	14 bits / 0.1%	3.4.3.2). Unit gain adjustable between 0 an E <sub>ONOM</sub> (voltage) or E <sub>ONOM</sub> (current).
_	Voltage Limit	12 bits / 0.3%	GROW CO. GROWN CO. C. A.
_	Current Limit	12 bits / 0.5%	
Readback	Voltage	16 bits / 0.05%	main or limit channel
resolution / accuracy	Current	16 bits / 0.1%	main or limit channel

1-2 BOP HIPWR 022108

TABLE 1-2. BOP GENERAL SPECIFICATIONS (Continued)

SPECIFICATION		RATING/DESCRIPTION	CONDITION
OUTPUT CHARACTERISTICS (Continu		ied)	
Readback rate/array -	measurement rate	5 ms (default)	range (voltage or current): 500µsec to 500ms range (voltage + current): 1msec to 250ms
Tale/allay =	measurement array	64 samples	Voltage
		128 samples	Current
Voltage stabilization in voltage mode	source effect	0.05% of rating	min-max input voltage
_	load effect	0.1% of rating	0-100% load current
<del>-</del>	time effect (drift)	0.02 of rating	0.5 through 8 hours
<del>-</del>	temperature effect	0.02%/deg C of rating	0 to 50 deg C
_	ripple and noise	2% E <sub>0</sub> max p-p	Includes switching noise
Current stabilization in current mode	source effect	0.05% of rating	min-max input voltage
<del>-</del>	load effect	0.2% of rating	0-100% load voltage
<del>-</del>	time effect (drift)	0.02% of rating	0.5 through 8 hours
<del>-</del>	temperature effect	0.02%/deg C of rating	0 to 50 deg C
_	ripple and noise	2% I <sub>0</sub> max p-p	Includes switching noise
Error sensing		0.25V per wire	Above rated output
Transient recovery in voltage mode	maximum excursion	5% of nominal output	nominal voltage, 50% load step
_	Recovery time	200 μsec	Return within 0.1% of set voltage
Isolation	voltage	300V	Output to ground
Series operation		Master/slave	Maximum of identical 3 units, up to 300V max.
Parallel operation		Master/slave	Maximum of 5 identical units
Series-parallel Operation		2 series x 2 parallel 3 series x 2 parallel	Master/slave for both series and parallel branches of identical units
Output Protection limiting		voltage and current limited in four quadrants, adjustable between ±Internal minim E <sub>OMIN</sub> or I <sub>OMIN</sub> (box) (see Figure 1-2) and ±1.01 E <sub>ONOM</sub> or I <sub>ONOM</sub> .	
Output Stage Protection		Output overvoltage/overcurrent Heatsink overtemperature, switchers overcurrent	Triggers latched shutdown protection of the output module and PFC stage. Recover by cycling power off, then on or by pressing
Input Stage Protection (PFC)		Internal overvoltage, undervoltage, overcurrent, heat sink overtemperature, fan inoperative	RESET at the front panel.
		Input circuit breaker overcurrent	Trips circuit breaker to shut off unit
Small signal Bandwidth	voltage channel	2 KHz minimum	Into nominal resistive load 10% of rating
_	current channel	800 Hz minimum	Into short circuit, 10% of rating
Rise/Fall time	voltage channel	250/200 μSec	Into nominal resistive load, measured from 10 to 90%, from 0 to ±100% of rating
_	current channel	0.7/1.2 mSec	Into short circuit, measured from 10 to 90%, from 0 to ±100% of rating

TABLE 1-2. BOP GENERAL SPECIFICATIONS (Continued)

SPECIFIC	ATION	RATING/DESCRIPTION	CONDITION
PROGRAMMING/DISPLAY CHARACTE		RISTICS	
Analog control Main channel (voltage or current)		-10V to +10V	Full range output, 20K Ohm input impedance (see PAR. 3.4)
Protection Limit channels:	+Voltage, -Voltage +Current, -Current	+1V to +10V	10% to 100% of Nominal Range. Input voltage clamped to 12V through 1K ohms. Maximum of 0.15mA input current at1V input voltage.
External mode control		Voltage: open circuit or TTL logic 1 Current: short circuit or TTL logic 0	Available when activated only, or for Save/Recall function.
	External Shutdown (see Table 2-4)	Isolated input for shutdown of the BOP (latched status)	Pulse width: 100 microseconds min. Action delay: 100 microseconds max Restore operation by cycling input power or pressing RESET key
	External Trigger Shutdown (see Table 2-4)	Non-isolated input for setting the BOP in STANDBY (output off) (latched status)	Pulse width: 100 microseconds min. Action delay: 200 milliseconds max Restore operation by pressing <b>STANDBY</b> key. or sending OUTP ON command via remote interface.
	External Shutdown Flag (see Table 2-4)	Isolated output indicatng shutdown status)	Action delay: 100 microseconds max
	External On-Off Flag (see Table 2-4)	Isolated output indicatng output on (enabled, STANDBY off) or off (disabled, STANDBY on) status)	Action delay: 200 milliseconds max
Digital control	local	Panel-mounted keypad	Direct Entry
	remote	IEEE 488-2 (GPIB)	SCPI
	remote	RS 232	3000
	remote	RS 485 (BITBUS)	IEEE 1118
Display	front panel	4" backlit LCI	D displays all functions
remote		All parameters read back on GPIB or RS 232 buses	
FUNCTION GENERA	TOR CHARACTER	RISTICS (See PAR. 3.3.9)	
Maximum number of wave	forms	Local: 16 Remote: 1	Local: Saved for power-up Remote: Lost when the unit is turned off, must be saved on the host computer)
Maximum number of segment forms per waveform	ents or basic wave-	Local: 10 Remote: 126	Or maximum number of points (whichever comes first)
			The time interval for each segment depends on the type of waveform: period for ramp and square waveforms, period or fraction of period for sine and triangular waveforms and time interval for DC levels
			Segments that cause the waveform to exceed the maximum number of points are not executed. For local operation they are marked with a triple asterisk on the front panel. For remote operation an error mes- sage is generated.
Types of Basic waveforms		Sine (Sinusoidal waveform) Triangle (Triangular waveform) Pos. Ramp (Ramp waveform) Neg. Ramp (Sawtooth waveform) Square (50% Duty Cycle Pulse) Level (DC waveform)	

1-4 BOP HIPWR 022108

TABLE 1-2. BOP GENERAL SPECIFICATIONS (Continued)

SPECIFICATION	RATING/DESCRIPTION	CONDITION
FUNCTION GENERATOR CHARACTER	RISTICS (Continued)	
Maximum number of points per basic waveform	Local: 3933 Remote: Can be set to either 3933 (no resolution), using the LIST:RES comm	ormal resolution- default value) or 5760 (high nand.
	a different number of points, dep quency. The number of points is inv ple, a "local" sine segment of 0.01h	e, ±ramp, square and level) is constructed using ending on the basic waveform, type and freversely proportional to the frequency. For examlz uses almost the maximum number of points, f a "remote" high resolution sine segment at a ximum number of points, 5760.
	level) THD-F (Total Harmonic Dis	nts of the basic waveforms (except square and tortion relative to the fundamental frequency) vaveforms are frequency dependent. For examis 5% at 400Hz and 1.6% at 40Hz.
Count (Number of repetitions)	Range: 1 to 255 For Count = 0 the waveform is executed indefinitely until stop command is sent	<ul> <li>Local: When the count is complete or if execution is stopped using [F5], the output of the unit is set to OFF (Standby indicator lit). Output must be enabled (press STANDBY) to execute the waveform again.</li> <li>Remote: When the count is complete or the waveform is stopped using the VOLT:MODE FIX command, the output gpes to zero (main channel reference programmed to zero).</li> </ul>
Waveform Name	10 characters maximum	
Waveform Parameters	Type: Voltage or Current  Positive Protection Limit: (Vd-c or Ad-c)  Negative Protection Limit:	Type of waveform, voltage or current, can be selected only for a new waveform and consequently applies to all waveform seg- ments. Changing the type for an existing waveform is not possible, unless the wave- form is erased first.
	(Vd-c or Ad-c)  Count: number	The Limit values (positive/negative) and the count number apply to all waveform segments and can be edited at the beginning of a new waveform or later when modifying a waveform (see PAR. 3.3.9.7).
	Initial/Repeating	All segments except the last may be set to run once (Initial) or per the Count setting (Repeating).
Basic waveform parameters	Phase (°), Stop Phase (°).  Ramp (Pos. or Neg.): Frequency (Hz Offset (Vd-c or Ad-c).	e (Vp-p or Ap-p), Offset (Vd-c or Ad-c), Start ), Amplitude (Vp-p or Ap-p),
	Square: Frequency (Hz), Amplitude (VLevel: Timing (sec), Amplitude (Vd-c o	or Ad-c).
	edited by modifying the existing se	,
	gular waveform segments.	global parameters, applicable to all sine/ trian-
	• The Start/Stop points are independent 360°.	dent and can have any value between 0° and

TABLE 1-2. BOP GENERAL SPECIFICATIONS (Continued)

SPECIFICAT	TION	RATING/DESCRIPTION	CONDITION
FUNCTION GENERAT	OR CHARACTER	RISTICS (Continued)	<u>I</u>
LIST command characteristic waveform (Remote only)		Maximum number of points  • For single (global) dwell time:	Note: Dwell time list must match (balance) the amplitude list.
		5900 (high resolution)  • For <126 different dwell times: 3933	Skip feature: a number of steps can be skipped from the LIST at the first run using
		For >126 different dwell times:     2950	LIST:COUN:SKIP.
		Dwell time range: 93usec to 34msec.	
		Dwell time resolution (increment): 0.751usec	
		Skip feature	
Waveform graphics displayed Local and Remote operation	on LCD for both	Local: The LCD represents the progra voltage for voltage mode or current for	mming waveform graph of the main channel, r current mode.
		programmed Limits are not exceed	gramming and real output waveform, as long as ded and the load is resistive. The programming taking into account the interaction between set-
		Because the BOP unit is not an sometimes very sketchy, especially ing of two adjacent segments or forms.	elected for the best waveform representation. oscilloscope, the waveform representation is y if there is a large difference between the timor a reduced number of repetitions of high frezation is difficult for low frequency waveforms.
		plays the actual or real waveform grap	s for waveform creation/ execution, the LCD dis- ons of the main and limit channel, voltage & cur- and current & voltage protection limit for current phase correlated.
		erly. It is recommended that the firs	entation, the graph timing must be chosen prop- st value higher than total waveform time be cho- read from 0.04 second to 75 seconds.
Frequency:			Not applicable to Level
_	Range (Hz)	0.01 to 443	Sine, Triangle
		0.02 to 532	±Ramp
		0.02 to 1000	Square
Program Program	ming Resolution (Hz)	0.01	
	Accuracy	1.5% of Frequency	Sine, Triangle, Square, ±Ramp
Period (applicable to Level or	nly)		<u>,                                      </u>
	Range (Seconds):	0.0005 TO 1.9999	
_	Resolution:	0.0001	
	Accuracy:	1.5% of Time Duration	
Amplitude Range			
<del>-</del>	oltage (Volts p-p)	0 to 2 x E <sub>ONOM</sub>	Sine, Triangle, Square, ±Ramp
	urrent (Amperes p-p)	0 to 2 x I <sub>ONOM</sub>	Sine, Triangle, Square, ±Ramp
Protection Limit Channel .	Current, bipolar (Amperes)	0 to I <sub>ONOM</sub>	(set once for all segments)
_	Voltage, bipolar (Volts)	0 to E <sub>ONOM</sub>	
Offset	Voltage (Volts)	-E <sub>ONOM</sub> to +E <sub>ONOM</sub>	Applies to offset of sine, triangle, ±ramp, and square waveforms and to Level waveform Amplitude.
	Current (Amperes)	-I <sub>ONOM</sub> to +I <sub>ONOM</sub>	

1-6 BOP HIPWR 022108

TABLE 1-2. BOP GENERAL SPECIFICATIONS (Continued)

SPECIFICA	ATION	RATING/DESCRIPTION	CONDITION
FUNCTION GENERATOR CHARACTER		ISTICS (Continued)	
Amplitude Resolution (Progr	ramming)		
Main Channel and Offset	Voltage (millivolts a-c)	.35	Sine
	(millivolts d-c)	1	Triangle, Square, ±Ramp, Level:
Cur	rent (milliamperes a-c)	.35	Sine
	(millivolts d-c)	1	Triangle, Square, ±Ramp, Level:
Protection Limit Channel	. Current, bipolar (Amperes)	0.1	
_	Voltage, bipolar (Volts)	0.1	
Amplitude Accuracy	<u>.</u>		
Main Channel and Offset	Voltage	0.03% E <sub>ONOM</sub>	
	Current	0.1% I <sub>ONOM</sub>	
Protection Limit Channel .	Current	0.5% I <sub>ONOM</sub>	
_	Voltage	0.3% E <sub>ONOM</sub>	
Distortion (THD-F, Total Har		5% max.	Sine
tive to the fundamental com	ponent)	13% max.	Triangle
		70% max.	±Ramp
		47% max.	Square
Start/Stop Angle (Phase)	Range	0 to 360°	Sine, Triangle
Pr	ogramming Resolution	0.1°	
Accuracy	Start Angle	1°	
	Stop Angle	1° @ 0.01Hz, to 16° @ 443 Hz	Frequency dependent
SAVE/RECALL CHAR	RACTERISTICS (Se	ee PAR. 3.3.8)	
Number of Locations		99	
Parameters Saved or Recal	led		All parameters saved for power-up.
_	Mode of operation	Voltage, Current or External	For External the operating mode is determined by signal at I/O Port; no signal selects voltage mode (see PAR. 3.4.2).
_	Reference type	Internal, External or External Reference Level	Main channel
		Internal, External or Lesser Limit	Limit channel
_	Main Amplitude (Internal)	0 to E <sub>ONOM</sub> or I <sub>ONOM</sub> (internal or external)	Main Channel: Voltage (Volts) for Voltage mode, Current (Amperes) for Current mode
Prof	tection Limit Amplitude (Internal)	E <sub>OMIN</sub> or I <sub>OMIN</sub> to 1.01 E <sub>ONOM</sub> or I <sub>ONOM</sub>	Limit Channel, Positive and Negative Voltage (Volts) for Current mode, Current (Amperes) for Voltage mode
<del>-</del>	Output status	ON or OFF	

TABLE 1-2. BOP GENERAL SPECIFICATIONS (Continued)

SPECIF	ICATION	RATING/DESCRIPTION	CONDITION
MISCELLANEOUS	FEATURES		
Maximum/Minimum Setti	ngs		
	Protection Limit Type	Bipolar (default) or Independent	
	Main Channel	0 to E <sub>ONOM</sub> or I <sub>ONOM</sub> (default)	Software limit to setting of main channel Voltage (Volts) for Voltage mode, Current (Amperes) for Current mode
(	Protection Limit Channel maximum value, Internal)	E <sub>OMIN</sub> or I <sub>OMIN</sub> to 1.01 E <sub>ONOM</sub> or I <sub>ONOM</sub> (internal)	Software limit to setting of protection limit channel.  Voltage (Volts) for Current mode Current (Amperes) for Voltage mode
Load Type Settings		Active (default), Resistive, Battery, Custom	Consult factory for custom setting.
MISCELLANEOUS	FEATURES (Contin	ued)	
Self-test capabilities		Display, Keypad, Interface, Serial Interface, Analog, Output	Serial Interface test requires Loop Back Test connector (p/o KIT 219-0436, see Table 1-5).
Interface Settings	Data Format	SCPI (default), CIIL	
	GPIB Address	0 to 30 (6 = default)	
	Output Status @ Reset	ON or OFF (OFF = default)	
	Serial Baud Rate	Off, 9600, 19200 (Off = default)	
	Device Clear	SCPI (default) or MATE	
	XON/XOFF	Enable (default) or Disable	
	Prompt	Disable (default), Enable, Enable with Echo	
Calibration		Assisted by front-panel prompts	
Power-up Settings	Mode	Voltage (default) or Current	
	Main Channel Reference Type	Internal (default), External or External Reference Level (Gain Mode)	
	Protection Limit Channel Reference type	Internal (default), External or Lesser Limit	Applies to Limit channel
	Protection Limit Levels (Internal)	E <sub>OMIN</sub> or I <sub>OMIN</sub> to 1.01 E <sub>ONOM</sub> or I <sub>ONOM</sub>	Voltage (Volts) for Current mode, Current (Amperes) for Voltage mode
	Output status	On (default) or Off	
Password	Types	Main, Admin1, Admin2	Factory defaults: Main: <b>DEFAULT</b> , Admin1: <b>A</b> , Admin2: <b>KEPCO</b>
	Protection Choices	Unprotected, Main, Admin1, Admin2	Password menu always protected by Admin2
	Items Protected	Interface, max/min , Load type, Test, Calibration, Power-up, Keypad @ local, Keypad lockout at power-up, Save Display Chg (See Figure 3-5 for defaults)	Multiple unit configurations are protected by Admin2 password.  Save Display Chg choice is Enable or Disable; when set to Disable, prevents changes made to the display settings from being saved for power up.
Series, Parallel, Series x identical units	Parallel configurations of	Single, Parallel, Series, 2 X 2, 3 X 2	2 X 2 is two parallel branches of two series- connected identical units. 3 X 2 is two parallel branches of three series- connected identical units.

1-8 BOP HIPWR 022108

TABLE 1-2. BOP GENERAL SPECIFICATIONS (Continued)

SPECIFICATION		RATING/DESCRIPTION	CONDITION
GENERAL (ENVIRO	NMENTAL) CHARA	CTERISTICS	
Temperature	operating	0 to +50 deg C	Full rated load
	storage	-20 to +85 deg C	
Cooling		Two internal fans	exhaust to the rear
Humidity		0 to 95% RH	non-condensing
Shock		20g. 11msec ±50% half sine	non-operating
Vibration	5-10HZ:	10mm double amplitude	3 axes, non-operating
	10-55HZ:	2g	3 axes, non-operating
Altitude		sea level to 10,000 feet	
Safety Certification	a-c power	UL 3101-1 and EN 6101-1	Pending
PHYSICAL CHARA	CTERISTICS		
Dimensions	English	5.25' X 19" X 21.5"	HXWXD
	metric	133.3mm X 482.6mm X 546.1mm	HXWXD
Weight, 1000W models	English	53 lbs	
	metric	24.1Kg	
Connections	Source power	3-pin IEC connector	
	Load connections	Nickel-plated copper bus bars	
	Sensing Output Terminal Block	7-pin terminal block	Default: 3 links installed for local sensing and ground network connected.
	Analog I/O control port	15-pin D female	See Figure 2-1, Table 2-10
	PAR/SER CTRL IN port	8-pin mini DIN connector	See Figure 2-1, Table 2-7
	PAR/SER CTRL OUT port	4-pin mini DIN connector	See Figure 2-1, Table 2-6
	PAR/SER PROT IN port	8-pin phone jack	See Figure 2-1, Table 2-8
	PAR/SER PROT OUT port	8-pin phone jack	See Figure 2-1, Table 2-9
	EXT PROT port	6-pin phone jack	See Table 2-4
	Primary digital port	24-pin GPIB connector	IEEE 488 port - See Table 2-11
	Secondary digital	6-pin phone jack	RS 232 port - See Table 2-5
	ports	5-pin mini DIN female connector	IEEE 1118 port - See Table 2-2
	External Trigger	4-pin stereo audio phone jack	See Table 2-3




FIGURE 1-1. 1000W BOP POWER SUPPLY, OUTLINE DRAWING (SHEET 1 OF 2)

1-10 BOP HIPWR 022108




FIGURE 1-1. BOP POWER SUPPLY, OUTLINE DRAWING (SHEET 2 OF 2)

#### 1.4 LOCAL CONTROL

Either the front panel keypad or the adjust control can set and adjust output voltage and current under local control. The display provides a digital display of output voltage and current as well as a pictorial display of real-time analog voltage and current meters.

The keypad includes five function keys which provide access to the menu-driven functions of the unit. The menu screens provide access to save the unit's settings, recall previously saved settings, configure or execute a waveform, display references or configure the unit by setting GPIB address, Serial protocols, maximum acceptable voltage and current, etc. (see PAR. 3.3 for details on local control).

Context-sensitive help screens are available by pressing the HELP key. Actual output voltage and current displays are available while the help screens are displayed.

#### 1.5 REMOTE CONTROL

The BOP Power Supply can be remotely controlled directly via either the IEEE 488.2 (GPIB) bus (see PARs. 3.5 and 3.5.4) or RS232C (see PAR.3.5.6) interface using SCPI commands (see and Appendix A and B). Most features available in local mode can also be accessed remotely via the digital interface. The unit can be controlled with a VISA (Virtual Instrumentation Software Architecture) driver to facilitate remote programming of the BOP Power Supply (see PAR. 3.5.5). The VISA driver is an interface written in standard C language which adds the proper SCPI syntax to commands sent to the BOP.

The BITBUS is used to allow communication between identical BOP units that are connected in series and/or parallel to expand the voltage or current range (see PAR. 2.8).

The BOP can also be controlled remotely using analog signal applied to the Analog I/O Port (see PAR. 3.4 for details.)

#### 1.6 FEATURES

#### 1.6.1 DIGITAL CALIBRATION

The BOP Power Supply contains no internal adjustments. Calibration is done entirely via the keypad (or remotely via the GPIB or RS 232 interface) using digital entries and a calibrated DVM, a precision d-c reference voltage source and precision shunt resistor. Calibration instructions appear on the front panel after a password is entered; previous calibration values are saved and can be restored using the remote interface if desired. The original factory calibration values can also be restored using the remote interface. (Refer to Section 4.)

#### 1.6.2 VOLTAGE/CURRENT PROTECTION

Positive and negative voltage and current protection values can be individually programmed. Refer to PAR. 3.3.3.

## 1.6.3 WAVEFORMS

The BOP models have the capability to make the output follow complex waveforms. These may be generated either externally, using an analog reference voltage (see PAR. 1.6.6), or internally, using user-generated waveforms.

Up to 16 user-generated waveforms can be stored for later use. The user selects the operating mode, positive and negative protection levels, and a count (the number of times the waveform is

1-12 BOP HIPWR 022108

to be repeated). Each waveform consists of up to 10 segments; each segment is assigned one of six basic waveform types: square, sine, triangle, negative ramp, positive ramp and level. Depending on the waveform type, frequency, peak-to-peak amplitude, offset, and start and stop phase angle are then assigned by the user.

Segments at the beginning of the waveform can be programmed to be executed only once, or to be repeated as specified by the count. A graphic representation on the LCD shows the waveform as segments are added and is displayed prior to execution. This feature provides unique versatility for generating a waveform that meets user requirements. Refer to PAR. 3.3.9 for further details.

#### 1.6.4 SAVING AND RECALLING SETTINGS.

The BOP offers 99 memory locations accessible from the front panel that can be used to store a set of operating parameters for later use. For each location, the user can store operating mode, output on/off, Main channel reference type and value, and protection reference type and value. The stored settings can then be recalled to quickly program the unit to the predetermined setting. Refer to PAR. 3.3.8 for further details.

#### 1.6.5 EXTERNAL REFERENCE (ANALOG CONTROL)

An external reference, provided through the rear analog port connector (see Table 2-10), can be used to control the output of the BOP. The external reference may be applied directly or can be attenuated by the digital controls (see PAR. 3.4.3.2). The BOP will limit its output based on the user configurable limits so that, in the event of a failure in the external reference, the devices connected to the output are protected. Refer to PAR. 3.4 for further details on using external signals to control the output.

#### 1.6.6 EXTERNAL LIMITS

When the unit is controlled by an external reference, the protection limits can also be controlled by analog signals that are digitally calibrated. The BOP samples the limit channel inputs and applies the proper limit levels at a 5 millisecond rate with the positive and negative limits being sampled alternately. The external limit inputs are hardware-protected against overvoltage. Refer to PAR. 3.4.4

#### 1.6.7 USER-DEFINED VOLTAGE/CURRENT MAXIMUM VALUES (SOFTWARE LIMITS)

The BOP output can be programmed not to exceed user-defined values. For example, the BOP 36-28MG, which has a maximum capacity of  $\pm 36$ V,  $\pm 28$ A, can be limited to  $\pm 30$ V,  $\pm 10$ V


#### 1.6.8 PARALLEL AND SERIES CONFIGURATIONS

Identical BOP units may be configured in series, parallel or parallel-series (2 X 2 or 3 X 2) configurations. The 2 X 2 configurations doubles both output voltage and output current, the 3 X 2 configuration triples the output voltage and doubles the output current. If a series/parallel configuration is enabled, communication between the master BOP and those configured as slave units occurs via the BITBUS. Refer to PAR. 2.8 for further details.

#### 1.6.9 ENERGY RECUPERATION

The BOP is a four-quadrant device as shown in Figure 1-2. Operating as a source, it delivers energy into a passive load, and as a sink it operates as an electronic load, absorbing and dissi-

pating energy from an active load. To minimize energy dissipation, the BOP employs energy recuperation, where energy sinked from an active load is passed backwards through the output circuit and the bidirectional input power factor correcting circuit to the a-c power lines, where it becomes available for reuse. This technology allows high power levels using switch-mode technology while maintaining high efficiency and reduced size and weight.






FIGURE 1-2. BOP OUTPUT CHARACTERISTICS

1-14 BOP HIPWR 022108

### 1.7 EQUIPMENT SUPPLIED

Equipment supplied with the BOP power supply is listed in Table 1-3.

**TABLE 1-3. EQUIPMENT SUPPLIED** 

ITEM	FUNCTION	PART NUMBER
Source Power Entry mating connector	Mates with source power entry connector	142-0381 (Kepco) (IEC 320)
PAR/SER CONTROL - IN mating connector	Mates with PAR/SER CONTROL - IN port to allow access to pins required for calibration	142-0488 (Kepco)

#### 1.8 ACCESSORIES

Accessories for the BOP Power Supply are listed in Table 1-5.

#### 1.9 SAFETY

Service must be referred to authorized personnel. Using the power supply in a manner not specified by Kepco. Inc. may impair the protection provided by the power supply. Observe all safety precautions noted throughout this manual (see listing on page E, preceding the Table of Contents). Table 1-4 lists symbols used on the power supply or in this manual where applicable.

**TABLE 1-4. SAFETY SYMBOLS** 

SYMBOL	Meaning
A	WARNING! RISK OF ELECTRIC SHOCK!
$\triangle$	CAUTION: REFER TO REFERENCED PROCEDURE.
WARNING	INDICATES THE POSSIBILITY OF BODILY INJURY OR DEATH.
CAUTION	INDICATES THE POSSIBILITY OF EQUIPMENT DAMAGE.

## **TABLE 1-5. ACCESSORIES**

ITEM	FUNCTION	PART NUMBER
Mating Connector, Trigger	Mates with Trigger port.	142-0527 (Kepco) SP2501 (CUI Stack)
IEEE 1118 (BITBUS) Mating connector	Allows connection to IEEE 1118 (BITBUS) port.	142-0485 (Kepco) KMDLA-5P (Kycon Inc.)
IEEE 488 Cable, (1 meter long)	Connects BOP power supply to GPIB bus.	SNC 488-1
IEEE 488 Cable, (2 meter long)	Connects BOP power supply to GPIB bus.	SNC 488-2
IEEE 488 Cable, (4 meter longs)	Connects BOP power supply to GPIB bus.	SNC 488-4
Interconnection Kit for multiple identical power supplies in parallel (increase output current)	Cables required to connect multiple BOP models in parallel for increased current capability, e.g., connecting two BOP 10-75MG models in parallel to produce a virtual BOP 10-150MG.	KIT 219-0449 (2 in parallel) KIT 219-0446 (3 in parallel) KIT 219-0447 (4 in parallel) KIT 219-0448 (5 in parallel)
Interconnection Kit for multiple identical power supplies in series (increase output voltage)	Cables required to connect multiple BOP models in series for increased voltage capability, e.g., connecting two BOP 10-75MG models in series to produce a virtual BOP 20-75MG.	KIT 219-0443 (2 in series) KIT 219-0444 (3 in series)
Interconnection Kit for multiple identical power supplies connected in two parallel branches each comprised of 2 or 3 units connected in series	Cables required to connect two parallel branches of series connected power supplies.  KIT 219-0480 is used for 2 parallel connected branches of 2 series connected units. The four (total) power supplies provide double the output current and double the output voltage of a a single unit  KIT 219-0481 is used for 2 parallel connected branches of 3 series-connected units. The six (total) power supplies provide double the output current and triple the output voltage of a a single unit	
Line Cord (250V, 20A)	Provides connection to a-c mains via Nema 6-20P connector.	118-1087
Line Cord (250V, 20A)	Provides connection to a-c mains via Nema L6-20P locking type connector.	118-1088
RS 232 Cable Kit	Contains 6-pin to 8-pin Serial Patch cord, RJ 45 Patch cord, two RS 232 adapters, one with male pins to connect to DTE equipment and one with female pins to connect to a PC (personal computer), two RS 232 Loop Back test Connectors (one 6-pin and one 8-pin) to test RS 232 communication and aid in isolating RS 232 communication problems.	KIT 219-0436
RS 232 Adapter (Male pins)	Allows RS 232 port to be connected to DTE equipment. (Supplied in KIT 219-0436.)	142-0487 (L-COM RA098M)
RS 232 Adapter (Female pins)	Allows RS 232 port to be connected to a PC (personal computer). (Supplied in KIT 219-0436.)	142-0506 (L-COM RA098F)
15-pin DSUB Connector	Mating connector for Analog input connector A2A5J6 Dsub 15 pin hood Dsub 15 pin male	108-0374 (Tyco-Amp 207470-1) 142-0449 (Amphenol 17S-DA15P)
IDC 6-pin connector	Mating connector for RS-232 PORT, connector A1J5 and PROTECTION EXT. PORT, connector A2A5J7	142-0536 (Amphenol 5-555176-3)
IDC 8-pin plug	Mating connector for PAR/SER PROTECT PORT (IN and OUT) connectors.	142-0535 (Amphenol 5-555176-3)
Slides	Allows easy withdrawal of unit from rack (see Figure 1-1). (Model CS 04 includes slides, brackets, all mounting hardware and installation instructions.)	CS 04
	Provides adequate cooling for calibration sense resistors.	136-0451

1-16 BOP HIPWR 022108

### **SECTION 2 - INSTALLATION**

#### 2.1 UNPACKING AND INSPECTION

This instrument has been thoroughly inspected and tested prior to packing and is ready for operation. After careful unpacking, inspect for shipping damage before attempting to operate. Perform the preliminary operational check as outlined in PAR. 2.3. If any indication of damage is found, file an immediate claim with the responsible transport service.

#### 2.2 TERMINATIONS AND CONTROLS

a) Front Panel: Refer to Figure 3-1 and Table 3-1.

b) Rear Panel: Refer to Figure 2-1 and Table 2-1.




FIGURE 2-1. BOP SERIES REAR PANEL

TABLE 2-1. REAR PANEL CONNECTOR FUNCTIONS

NUMBER (FIGURE 2-1)	CONNECTOR/TERMINAL (REFERENCE DESIGNATOR)	FUNCTION
1	IEEE 1118 (BITBUS) PORT <sup>(1)</sup> (connector A1J4)	Used for multiple identical BOP master/slave parallel, and series and series-parallel configurations (refer to PAR. 2.8, see Table 2-2).
2	TRIGGER (connector A1J3)	May be used to initiate BOP output. (See Table 2-3.)
3	IEEE 488 (GPIB) PORT (connector A1J6)	Used for Remote control of the BOP via the IEEE 488 (GPIB) interface (See Table 2-11.)
4	ANALOG I/O PORT (connector A2A5J6)	Provides interface for analog input/output signals. (See Table 2-10.)
5	PARALLEL/SERIAL CONTROL PORT (connectors A2A5J3, IN and A2A5J4, OUT)	Provides interconnections used to control parallel or serial configurations of identical BOP's as a single power supply (see Table 2-7 for A2A5J3, IN and Table 2-6 for A2A5J4, OUT).
6	PARALLEL/SERIAL PROTECT PORT (connectors A2A5J1, IN and A2A5J2 OUT)	Provides interconnections used to control protection shutdown of power supplies connected in parallel or serial configurations (see Table 2-8 for A2A5J1, IN and Table 2-9 for A2A5J2, OUT).
7	EXT PROTECT PORT (connector A2A5J7)	Provides means for controlling protection via external circuitry and provides status flags to external circuitry. (See Table 2-4.)
8	INPUT connector (connector A7J1)	Connects source power to unit.  Pin 1 - Line (or Line 1 without Neutral connection)  Pin 2 - Neutral (or Line 2 without Neutral connection)  Pin 3 - Ground (Protective conductor terminal)
9	Monitor and Sensing terminal block (terminal block A7A1TB1)	Terminal block provides external connections as follows: OUT S: Sense line connection to load (compensate for voltage drop on connections to load.) See PAR. 2.5.6 and 2.5.7 (Terminal 2). OUT MON: Monitor connection used to monitor output voltage at power terminals and to implement local sensing (Terminal 3). GND NET: Grounding network connection (Terminal 4). See PAR. 2.5.3.1. GND: Chassis ground connection (Terminal 5). COM MON: Monitor return connection (Terminal 6). Used to monitor output voltage at power terminals and to implement local sensing. COM S: Sense line return connection from load (Terminal 7) See PAR. 2.5.6 and 2.5.7
10	terminals	Frame or chassis terminals
11	COMMON (terminal A7J3)	Power output return from load.
12	OUTPUT (terminal A7J2)	Power output connection to load.
13	RS232 PORT (connector A1J5)	Used for Remote control of the BOP via the RS 232 serial interface. (See Table 2-5 for details.)

2-2 BOP HIPWR 022108

TABLE 2-2. IEEE 1118 CONNECTOR INPUT/OUTPUT PIN ASSIGNMENTS

CONNECTOR	PIN	SIGNAL NAME	FUNCTION
JEEE 4440 (DITPUO)	1, 3 (shorted)	CONTROL BUS "A"	IEEE 1118, referenced to pins 5, 8 (2-Wire Differential Interface)
PORT (connector A1J4)	5, 8 (shorted)	CONTROL BUS "B"	IEEE 1118, referenced to pins 1, 3 (2-Wire Differential Interface)
(66111166161711617)	6	TERMINATOR	Connect to pin 5 or 8 to add an internal termination resistor to first/last unit on the daisy chain.

# **TABLE 2-3. TRIGGER PORT PIN ASSIGNMENTS**

CONNECTOR	PIN	SIGNAL NAME	FUNCTION
	1	LOGIC GND	Return for TRIGGER and SHUTDOWN signals.
TRIGGER PORT	IGGER PORT 2 nnector A1J3) 3	SHUTDOWN	Always active; Logic 0 causes unit to shut down (output disabled, standby status);
(connector A133)		NOT USED	
	4	EXT. TRIGGER INPUT	Not used; consult factory for details.

TABLE 2-4. EXTERNAL PROTECTION CONNECTOR INPUT/OUTPUT PIN ASSIGNMENTS

CONNECTOR	PIN	SIGNAL NAME	FUNCTION
	1	SD_EXT_K	Cathode of LED optocoupler (through a 510 ohm resistor) which is used for external isolated shutdown. Anode of LED is connected to (A2A5J7) pin 2. A positive voltage (3.5 to 15V) at pin 2 (referenced to pin 1) shuts down the unit (see CAUTION below).
	2	SD_EXT_A	Anode of LED optocoupler which is used for external isolated shutdown. (See pin 1 above.)
EXT. PROTECT PORT (connector A2A5J7)	3	PG_EXT_C	Collector of optocoupler-transistor which is used for external isolated "power OK" flag. Transistor emitter is connected to (A2A5J7) pin 4. When unit is operating normally, transistor is saturated. Current through transistor should not exceed 5mA and supply voltage should not exceed 15V.
	4	PG_EXT_E	Emitter of optocoupler-transistor which is used for external isolated "power OK" flag. (See pin 3 above.)
	5	EXT_C	Collector of optocoupler-transistor which is used for external isolated "Output OFF" flag. Transistor emitter is connected to (A2A5J7) pin 6. When output is OFF, transistor is saturated. Current through transistor should not exceed 3mA and supply voltage should not exceed 15V.
	6	EXT_E	Emitter of optocoupler-transistor which is used for external isolated "output OFF" flag. (See pin 5 above.)

CAUTION:When an external shut-down signal is sent to the unit, the shut-down condition is latched and the red FAULT indicator on the front panel is ON. To resume normal operation it is necessary to cycle power off, then on (preferred) or briefly press the RESET key on the front panel.

# TABLE 2-5. RS232C PORT INPUT/OUTPUT PIN ASSIGNMENTS

CONNECTOR	PIN	SIGNAL NAME	FUNCTION
	1	RTS	Request To Send (protocol not used)
	2	RXD	Receive Data
RS 232 PORT	3	TXD	Transmit Data
A1J5	4	LOGIC GND	Logic Ground
	5	LOGIC GND	Logic Ground
	6	CTS	Clear To Send (protocol not used)

# TABLE 2-6. PARALLEL/SERIAL CONTROL OUT PORT PIN ASSIGNMENTS

CONNECTOR	PIN	SIGNAL NAME	FUNCTION
	1	SGND	Local signal ground
PARALLEL/SERIAL CONTROL OUT	2	No connection	
PORT (A2A5J4)	3	S_IN_PARALLEL	Relayed signal for daisy chain connection. (See PARALLEL/SERIAL IN PORT (A2A5J3) pin 3)
, ,	4	No connection	

# TABLE 2-7. PARALLEL/SERIAL CONTROL IN PORT PIN ASSIGNMENTS

CONNECTOR	PIN	SIGNAL NAME	FUNCTION
	1	SGND	Local signal ground
	2	No connection	
	3	S_IN_PARALLEL	Input for programming output current of a parallel-connected slave. Provided by master unit.  Level: -10V to +10V controls the current between -I <sub>Onom</sub> to +I <sub>Onom</sub> .
	4	No connection	
PARALLEL/SERIAL	5	No connection	
CONTROL IN PORT (A2A5J3)	6	IOUT_M_UNIT	Output for programming slave current when the unit is a parallel-connected master  Level: -10V to +10V programs slave current to -I <sub>Onom</sub> to +I <sub>Onom</sub> .
	7	No connection	
	8	S_IN_SERIAL	Input for programming output voltage of a series-connected slave. Provided by master unit or from previous slave if multiple slaves connected. Level: $-E_{Onom}$ to $+E_{Onom}$ controls programs output voltage from $+E_{Onom}$ to $-E_{Onom}$ .

2-4 BOP HIPWR 022108

TABLE 2-8. PARALLEL/SERIAL PROTECT IN PORT PIN ASSIGNMENTS

CONNECTOR	PIN	SIGNAL NAME	FUNCTION
	1	SD_A	Anode of LED optocoupler which is part of protection circuit for parallel or series combination. Cathode of LED is connected to PARALLEL/SERIAL PROTECT OUT PORT (A2A5J2) pin 1 (see Table 2-9). When activated, the optocoupler shuts down the unit. LEDs from all units of the parallel or series combination are connected in series.
PARALLEL/SERIAL PROTECT IN PORT	2	PGOUT_C	Collector of optocoupler transistor which is part of protection circuit for parallel or series combination. Transistor emitter is connected to PAR-ALLEL/SERIAL PROTECT OUT PORT (A2A5J2) pin 2 (see Table 2-9). When unit is operating normally, transistor is saturated. Transistors from all units of the parallel or series combination are connected in series.
(A2A5J1)	3	SD_RETURN	Completes return connection for the protection circuit which receives energy from the master unit.
	4	No connection	
	5	No connection	
	6	No connection	
	7	GND	Local power ground.
	8	ALLOW EXT_ERR	Provides energy for the protection circuit (master unit only). Disabled at power up to prevent shutdown during power up.

# TABLE 2-9. PARALLEL/SERIAL PROTECT OUT PORT PIN ASSIGNMENTS

CONNECTOR	PIN	SIGNAL NAME	FUNCTION
	1	SD_K	Cathode of LED optocoupler which is part of protection circuit for parallel or series combination. (See IN port (A2A5J1) pin 1,Table 2-8.)
	2	PGOUT_E	Emitter of optocoupler transistor which is part of protection circuit for parallel or series combination. (See IN port (A2A5J1) pin 2,Table 2-8.)
PARALLEL/SERIAL PROTECT OUT	3	SD_RETURN	Relayed connection, provides return for the protection circuit which receives energy from the master unit.
PORT	4	No connection	
(A2A5J2) - -	5	No connection	
	6	No connection	
	7	No connection	
	8	No connection	

TABLE 2-10. ANALOG I/O PORT INPUT/OUTPUT PIN ASSIGNMENTS

CONNECTOR	PIN	SIGNAL NAME	FUNCTION	
		ION: IT IS RECOMMENDED THAT SOURCE POWER OF EXTERNAL EQUIPMENT CON NECTED TO THE ANALOG PORT BE APPLIED THROUGH AN ISOLATING TRANS FORMER TO AVOID GROUND LOOPS OR POSSIBLE DAMAGE TO THE BOP DUE TO INCORRECT EQUIPMENT A-C WIRING (E.G., DEFEATING OF GROUND CONNECTION).		
	1	NC		
	2	VM-/CM	External input signal, TTL logic referenced to pin 9, controls the mode of operation when using external reference (goes to the digital board that changes VM-/CM signal). Logic 0 (or pin grounded) = current mode, logic 1 (or pin not connected, the default) = voltage mode (see PAR. 3.4.2).	
	3	IOUT_DMM	Output analog signal through 2K ohm resistor referenced to pin 4 for monitoring overall output current, 0V to $\pm$ 10V corresponds to zero to $\pm$ full scale current.	
	4	SGND	Signal Ground used for IOUT_DMM (pin 3) return.	
	5	- I_LIM_EXT	Analog input signal referenced to pin 12, 0V to +10V sets the negative current limit between zero and $-I_{Omax}$ , +10V corresponds to rated maximum current (e.g., for BOP 36-28MG +10V sets negative current limit to –28A) (see PAR. 3.4.4). Open = disabled (see NOTE 1).	
ANALOG I/O PORT A2A5J6	6	- V_LIM_EXT	Analog input signal, 0V to +10V, sets the negative voltage limit between zero and $-E_{Omax}$ , +10V corresponds to rated maximum voltage (e.g., for BOP 36-28MG +10V sets negative voltage limit to -36V). Open = disabled. (See PAR. 3.4.4.) Open = disabled (see NOTE 1).	
	7	NC		
	8	NC		
	9	GND	Ground - Used for VM-/CM (pin 2) return	
	10	SGND	Signal Ground (used for EXT_REF (pin 11) return	
	11	EXT_REF	External analog reference signal referenced to pin 10, used for both voltage mode and current mode, 0V to ±10V corresponds to zero to ± rated nominal (full scale), voltage or current (see PAR. 3.4.3).	
	12	GND1	Ground (Used for pin 5, 6, 13 and 14 return)	
	13	+I_LIM_EXT	Analog input signal referenced to pin 12, 0V to +10V sets the positive current limit between zero and $I_{Omax}$ ; +10V corresponds to rated maximum current (e.g., for BOP 36-28MG +10V sets positive current limit to +28A) (see PAR. 3.4.4). Open = disabled (see NOTE 1).	
	14	+V_LIM_EXT	Analog input signal, 0V to +10V sets the positive voltage limit between zero and $E_{Omax}$ , +10V corresponds to rated maximum voltage (e.g., for BOP 36-28MG +10V sets positive current limit to +36V. Open = disabled. (See PAR. 3.4.4.) (see NOTE 1).	
	15	NC		
NOTE 1. When disabled,	DTE 1. When disabled, the external limit channels are automatically set 20% higher than BOP nominal references.			

# 2.3 PRELIMINARY OPERATIONAL CHECK

A simple operational check after unpacking and before equipment installation is advisable to ascertain whether the power supply has suffered damage resulting from shipping.

Refer to Figures 2-1 and 3-1 for location of operating controls and electrical connections. Tables 3-1 and 3-2 explain the functions of operating controls/indicators and keypad keys, respectively. Refer to PAR. 3.2 for a description of basic operating techniques.

2-6 BOP HIPWR 022108

- 1. With POWER switch set to off position, connect the power supply to source power (see PAR. 2.5.2).
- 2. With no load connected, set POWER switch to the ON position. Each time the unit is turned on an internal self-test is performed. The alphanumeric display (LCD) shows the processor firmware revision history and lists various tests performed during the internal self-test. As each test is completed, PASS or FAIL is displayed. If all tests pass, the unit goes into the default mode. If a failure occurs, the failure is displayed. Figure 3-3 shows the factory configured power on defaults displayed on the LCD.

TABLE 2-11. IEEE 488 PORT INPUT/OUTPUT PIN ASSIGNMENTS

CONNECTOR	PIN	SIGNAL NAME	FUNCTION
	1	DI01	I/O Line
	2	DI02	I/O Line
	3	DI03	I/O Line
	4	DI04	I/O Line
	5	EOI	End or Identify
	6	DAV	Data Valid
	7	NRFD	Not Ready for Data
	8	NDAC	Not Data Accepted
	9	IFC	Interface Clear
	10	SRQ	Service Request
	11	ATN	Attention
IEEE 488 PORT	12	SHIELD	Shield
J5	13	DI05	I/O Line
	14	DI06	I/O Line
	15	DI07	I/O Line
	16	DI08	I/O Line
	17	REN	Remote Enable
	18	GND	Ground (signal common)
	19	GND	Ground (signal common)
	20	GND	Ground (signal common)
	21	GND	Ground (signal common)
	22	GND	Ground (signal common)
	23	GND	Ground (signal common)
	24	LOGIC GND	Logic Ground

- 3. Connect a digital voltmeter (DVM) (resolution and accuracy of 0.01% or better) to the OUTPS and COMS terminals at the rear panel terminal block.
- 4. Use the keypad to enter the rated maximum voltage of the power supply (e.g., enter 36 for a model BOP 36-28MG) and press **ENTER**. If STANDBY indicator is lit, press **STANDBY** key.
- Verify DVM voltage reading agrees with programmed voltage within 0.03% of rated maximum voltage and agrees with displayed voltage on LCD within 0.05% of rated maximum voltage.

## 2.4 INSTALLATION

## 2.4.1 RACK MOUNTING

The unit is shipped with four feet attached to bottom of the unit which must be removed prior to installation (see Figure 1-1). The BOP is designed to be rack mounted in a standard 19-inch wide rack using the mounting ears (supplied) attached to the front panel (see Figure 1-1). CAUTION: THE RACK MUST PROVIDE SUPPORT AT THE REAR (WITHIN 6 INCHES OF THE REAR PANEL). OPTIONAL SLIDES CAN ALSO BE USED (SEE PAR. 2.4.2).

#### 2.4.2 SLIDE INSTALLATION

Optional slides are available for rack mounting (see Table 1-5 and Figure 1-1).

#### 2.5 WIRING INSTRUCTIONS

Interconnections between an a-c power source and a power supply, and between the power supply and its load are as critical as the interface between other types of electronic equipment. If optimum performance is expected, certain rules for the interconnection of source, power supply and load must be observed by the user. These rules are described in detail in the following paragraphs.

CAUTION: WHEN WORKING WITH ACTIVE LOADS, THE VOLTAGE OR CURRENT OF THE ACTIVE LOAD MUST NOT EXCEED THE MAXIMUM VOLTAGE OR CURRENT RATING OF THE BOP. OTHERWISE THE OVERVOLTAGE OR OVERCURRENT PROTECTION WILL SHUT DOWN THE POWER SUPPLY.

#### 2.5.1 SAFETY GROUNDING

Local, national and international safety rules dictate the grounding of the metal cover and case of any instrument connected to the a-c power source, when such grounding is an intrinsic part of the safety aspect of the instrument. The ground terminal of the source power connector (Figure 2-1) is connected to the chassis and the instructions below suggest wiring methods which comply with these safety requirements; however, in the event that the specific installation for the power system is different from the recommended wiring, it is the customer's responsibility to ensure that all applicable electric codes for safety grounding requirements are met. As a precaution, always connect the stud marked  $\rightarrow$  at the rear panel to proper earth ground.

## 2.5.2 SOURCE POWER CONNECTIONS

Source power is connected to the power supply via three-wire input power using the source power mating connector supplied (see Table 1-3). See Table 1-2 for source power specifications. This power supply operates from single phase a-c mains power over the specified voltage and frequency ranges (Table 1-2) without any need for range selection.

# 2.5.3 D-C OUTPUT GROUNDING

Connections between the power supply and the load and sensing connections may, despite all precautions such as shielding, twisting of wire pairs, etc., be influenced by radiated noise, or "noise pick-up". To minimize the effects of this radiated noise the user should consider grounding one side of the power supply/load circuit. The success of d-c grounding requires careful analysis of each specific application, however, this recommendation can only serve as a general guideline.

2-8 BOP HIPWR 022108

One of the most important considerations in establishing a successful grounding scheme is to avoid GROUND LOOPS. Ground loops are created when two or more points are grounded at different physical locations along the output circuit. Due to the interconnection impedance between the separated grounding points, a difference voltage and resultant current flow is superimposed on the load. The effect of this ground loop can be anything from an undesirable increase in output noise to disruption of power supply and/or load operation. The only way to avoid ground loops is to ensure that the entire output/load circuit is fully isolated from ground, and only then establish a single point along the output/load circuit as the single-wire ground point.

The exact location of the "best" d-c ground point is entirely dependent upon the specific application, and its selection requires a combination of analysis, good judgement and some amount of empirical testing. If there is a choice in selecting either the OUTPUT or COMMON output terminals of the power supply for the d-c ground point, both sides should be tried, and preference given to the ground point producing the least noise. For single, isolated loads the d-c ground point is often best located directly at one of the output terminals of the power supply; when remote error sensing is employed, d-c ground may be established at the point of sense lead attachment. In the specific case of an internally-grounded load, the d-c ground point is automatically established at the load.

The output and common terminals of BOP power supplies are d-c isolated ("floating") from the chassis in order to permit the user maximum flexibility in selecting the best single point ground location. Care must be taken in measuring the ripple and noise at the power supply: measuring devices which are a-c line operated can often introduce additional ripple and noise into the circuit.

There is, unfortunately, no "best" method for interconnecting the load and power supply. Individual applications, location and nature of the load require careful analysis in each case. Grounding a single point in the output circuit can be of great importance. It is hoped that the preceding paragraphs will be of some assistance in most cases. For help in special applications or difficult problems, consult directly with Kepco's Application Engineering Department.

## 2.5.3.1 GROUNDING NETWORK CONFIGURATION

When the output is floating there is a tendency for large changes in output voltage to affect the digital programming section, possibly resulting in an erroneous output. Decoupling capacitors from each of the two output terminals to the chassis via a terminal block link form a grounding network. The grounding network is designed to reduce high frequency noise and ensure that the digital programming section is not adversely affected by the dynamic swing of the output. The power supply is shipped with the grounding network connected: a connection between terminals TB1-4 (GND NET) and TB1-5 (GND). To disconnect the grounding network from the output, remove the connection across TB1-4 and TB1-5.

#### 2.5.4 POWER SUPPLY/LOAD INTERFACE

The general function of a voltage- or current-stabilized power supply is to deliver the rated output quantities to the connected load. The load may have any conceivable characteristic: it may be fixed or variable, it may have predominantly resistive, capacitive or inductive parameters; it may be located very close to the power supply output terminals or it may be a considerable distance away. The perfect interface between a power supply and its load would mean that the specified performance at the output terminals would be transferred without impairment to any load, regardless of electrical characteristics or proximity to each other.

The stabilized d-c power supply is definitely not an ideal voltage or current source, and practical interfaces definitely fall short of the ideal. All voltage-stabilized power supplies have a finite source impedance which increases with frequency, and all current-stabilized power supplies have a finite shunt impedance which decreases with frequency. The method of interface between the power supply output and the load must, therefore, take into account not only the size with regard to minimum voltage drop, but the configuration with regard to minimizing the impedance introduced by practical interconnection techniques (wire, bus bars, etc.). The series inductance of the load wire must be as small as possible as compared to the source inductance of the power supply: although the error sensing connection to the load compensates for the d-c voltage drop in the power leads, it cannot compensate for the undesirable output effects of the power lead inductance. These lead impedances (both power and sensing leads) are especially important if the load: is constantly modulated or step-programmed; has primarily reactive characteristics; or where the dynamic output response of the power supply is critical to load performance.

#### 2.5.5 LOAD CONNECTION - GENERAL

Load connections to the BOP power supply are achieved via the OUTPUT and COMMON bus bar-type terminals located on the rear panel. A barrier strip is provided at the rear panel for connection of the sense wires to the load (for remote sensing or multiple unit applications).

CAUTION: NEVER CONNECT THE LOAD TO THE SENSE TERMINALS. MONITORING INSTRUMENTS (E.G., DVM, ETC.) ARE THE ONLY EXTERNAL EQUIPMENT THAT MAY BE SAFELY CONNECTED TO THE SENSE TERMINALS.

NOTE REGARDLESS OF OUTPUT CONFIGURATION, EITHER LOCAL OR REMOTE OUT-PUT SENSE LINES MUST BE CONNECTED FOR OPERATION.

- 1. OBSERVE POLARITIES: The **OUT S** sensing wire must be connected to the **OUT-PUT** load wire, and the **COM S** sensing wire must be connected to the **COMMON** load wire.
- 2. IF LOCAL SENSING IS USED, INSTALL LINKS (see Figure 2-2).

CAUTION: THE SAFETY FEATURES INCORPORATED INTO THE BOP TO HANDLE ENERGY FROM ACTIVE LOADS ARE UNABLE TO PROTECT THE POWER SUPPLY OR THE LOAD IF INPUT POWER TO THE BOP IS LOST OR IF THE BOP MALFUNCTIONS. IT IS RECOMMENDED THAT THE USER MONITOR "POWER OK" FLAG PINS 3 AND 4 OF THE EXTERNAL PROTECT PORT (SEE TABLE 2-4) AND IMPLEMENT A FAST-ACTING MEANS OF DISCONNECTING CAPACITIVE LOADS OR CROWBARRING INDUCTIVE LOADS TO PREVENT DAMAGE TO BOTH THE BOP AND THE LOAD IN THE EVENT OF INPUT POWER LOSS.

## 2.5.6 LOAD CONNECTION USING LOCAL SENSING

Figure 2-2 shows a typical configuration using local sensing and a grounded load; for local sensing with an isolated ("floating") load, do not install the ground connection (see Figure. 2-2, Note 2).

## 2.5.7 LOAD CONNECTION USING REMOTE SENSING

Figure 2-3 shows a typical configuration using remote sensing and a grounded load; for remote sensing with an isolated ("floating") load, do not install the ground connection (see Figure. 2-3, Note 2).

2-10 BOP HIPWR 022108

## 2.6 COOLING

The power devices used within the power supply are maintained within their operating temperature range by means of internal heat sink assemblies and by two cooling fans. Periodic cleaning of the power supply interior is recommended. If the power supply is located within a confined space, take care that the ambient temperature, which is the temperature of the air immediately surrounding the power supply, does not rise above the specified limits (see Table 1-2).

## 2.7 SETTING UP THE UNIT

The following paragraphs describe the connections and initial BOP setup needed to operate in the desired mode.

## 2.7.1 CONSIDER THE LOAD TYPE

The BOP can be configured to respond differently to the Output OFF command, depending on whether the load is defined as Active, Resistive or Battery. Refer to PAR. 3.3.6 to configure this setting.

## 2.7.2 SETUP FOR LOCAL OPERATION

With all power off, connect the load to the BOP using either local or remote sensing (refer to PAR. 2.5). If units are to be connected in series or parallel, refer to PAR. 2.8.) Then refer to PAR. 3.2 for power supply basics and local operation. The factory default configuration allows local operation with no further setup required.




FIGURE 2-2. LOAD CONNECTIONS, LOCAL SENSING




FIGURE 2-3. LOAD CONNECTIONS, REMOTE SENSING

#### 2.7.3 SETUP FOR REMOTE OPERATION VIA GPIB

With all power off, connect the load to the BOP using either local or remote sensing. If units are to be connected in series or parallel, refer to PAR. 2.8. Connect the GPIB connector to the GPIB port (see Figure 2-1 and Table 2-1). Turn power on and refer to PAR. 3.2 for power supply basics and PAR. 3.5 for remote mode programming.

The default GPIB address is 6; to change it refer to PAR 3.5.3.1. The default configuration allows both local and remote operation; to prevent local operation once the unit is being controlled from the GPIB, see PAR. B.107. Refer to PAR. 3.5.3.1 to configure the GPIB Port.

SCPI programming is described in PAR. 3.6; Appendices A and B provide syntax for SCPI common and subsystem commands and queries implemented in this unit. All the features described for Local Mode operation can be accomplished using remote SCPI commands.

## 2.7.4 SETUP FOR REMOTE OPERATION VIA RS 232C

With all power off, connect the load to the BOP using either local or remote sensing (refer to PAR. 2.5). If units are to be connected in series or parallel, refer to PAR. 2.8. Connect the RS 232 connector to the RS 232 port (see Figure 2-1 and Table 2-1). Turn power on and refer to PAR. 3.2 power supply basics and PAR. 3.5.6 for RS 232 operation. SCPI programming is described in PAR. 3.6; Appendices A and B provide syntax for SCPI common and subsystem commands and queries implemented in this unit. Refer to PAR. 3.5.3.2 to configure the RS 232 Port.

## 2.8 MULTIPLE UNIT CONFIGURATIONS

Parallel, series and series-parallel configurations of identical BOP units increases the rated voltage and current range of the power supply. Up to five units can be connected in parallel to increase the current:  $I_{MAX (one \ unit)} \times N_P = I_{MAX (parallel \ combination)}$  where  $N_P = n_{MAX \ (one \ unit)} \times N_P = n_{MAX \ (one \ unit)}$ 

2-12 BOP HIPWR 022108

parallel. Similarly, up to three units can be connected in series to increase the voltage:  $E_{MAX \, (one \, unit)} \times N_S = E_{MAX \, (parallel \, combination)}$  where  $N_S =$  number of units in series. In addition, identical units may be connected in both series and parallel. The 2 X 2 configuration, two parallel branches of two series-connected power supplies, doubles the output voltage and doubles the output current of a single unit. The 3 X 2 configuration, two parallel branches of three series-connected power supplies, triples the output voltage and doubles the output current of a single unit. Multiple unit configurations require the appropriate Interconnection Kit (see Table 1-5).

For all multiple unit configurations the master reports the system output parameters: voltage and current; the slaves report the main channel parameter: voltage for voltage mode (series configurations) or current for current mode (parallel configurations).

Additional hex nuts are provided in the interconnection kit for sufficient cable separation so they can be oriented as needed to fit onto the terminal.

NOTE: Multiple unit configurations require that all individual units be properly calibrated. (Units shipped from Kepco have been factory-calibrated.) If not, refer to Section 4 to calibrate the individual units prior to connecting them in parallel or series. Using calibrated units ensures that the multiple unit configuration is calibrated; calibrating the multiple unit configuration is neither needed nor possible.

Before powering up the units to be configured, first connect the units in parallel or series. Figures 2-4 (local sensing) and 2-5 (remote sensing) show the connections for three parallel-connected units; Figures 2-6 (local sensing) and 2-7 (remote sensing) show the connections for three series-connected units. These figures allow other configurations, e.g., five parallel-connected units or two series connected units, etc. to be easily deduced Figure 2-12 show the connections for a typical 3 X 2 (two parallel branches each consisting of three series-connected units) configuration, as well as simplified diagrams showing required arrangements for 2 X 2 and 3 X 2 configurations to allow the user .

CAUTION: FOR PARALLEL CONFIGURATIONS, REMOVE LINKS BETWEEN (COM S) AND (COM OUT) TERMINALS OF ALL SLAVES TO PREVENT DAMAGE TO THE UNIT AND MAINTAIN SYSTEM ACCURACY.

The following connections are required.

- Power cables
- · Sense connections (either local or remote)
- All interconnection cables and terminations required for parallel, series, 2 X 2 or 3 X 2 configurations are supplied in the applicable Interconnection Kit (see Table 1-5 for part number).

# 2.8.1 MULTIPLE UNIT SOURCE POWER

Multiple units must all be connected to the same a-c input power source.

CAUTION: CONNECTING MULTIPLE UNITS TO DIFFERENT A-C INPUT SOURCES MAY DAMAGE THE BOP POWER SUPPLIES AND/OR THE LOAD.

# 2.8.2 MULTIPLE UNIT PROTECTION

For multiple unit configurations it is necessary to configure the protection so that a fault will shut down all the interconnected power supplies. Figure 2-8 is a simplified diagram showing typical interconnections for master/slave configurations.

CAUTION: REMOVE LINK BETWEEN (COM S) AND (COM MON) AT ALL SLAVES
TO PREVENT DAMAGE TO THE BOP AND MAINTAIN SYSTEM ACCURACY.




FIGURE 2-4. PARALLEL CONFIGURATION, LOCAL SENSING, TYPICAL

2-14 BOP HIPWR 022108

CAUTION: REMOVE LINK BETWEEN (COM S) AND (COM MON) AT ALL SLAVES TO PREVENT DAMAGE TO THE BOP AND MAINTAIN SYSTEM ACCURACY.




FIGURE 2-5. PARALLEL CONFIGURATION, REMOTE SENSING, TYPICAL




FIGURE 2-6. SERIES CONFIGURATION, LOCAL SENSING, TYPICAL

3042753

LOAD

2-16 BOP HIPWR 022108

NOTES: 1. REMOVE LINK BETWEEN (GND NET) AND (GND)FOR ALL SLAVES.

- 2. REMOVE LINK BETWEEN (COM S) AND (COM MON) AT ALL SLAVES TO COMPENSATE FOR DROP IN POWER CONNECTIONS.
- 3. REMOVE LINK BETWEEN (COM S) AND (COM MON) AT MASTER AND BETWEEN (OUT S) AND (OUT MON) AT LAST SLAVE FOR REMOTE SENSING.
- 4. REFER TO CABLE KIT FOR PART NO.

DVM




FIGURE 2-7. SERIES CONFIGURATION, REMOTE SENSING, TYPICAL




FIGURE 2-8. TYPICAL MASTER/SLAVE PROTECTION INTERCONNECTIONS

Upon startup, PAR/SER PROT IN PORT pin 8 of the master goes low, and stays low until all slaves are powered up. Normal power up of a unit causes the transistor connecting PAR/SER PROT IN PORT pin 2 and PAR/SER PROT OUT PORT pin 2 to conduct. The transistors of all units are connected in series, effectively shorting out all the shutdown diodes (the shutdown diodes of all units are also connected in series) connecting PAR/SER PROT IN PORT pin 1 and PAR/SER PROT OUT PORT pin 1. After all the units are powered up and operating normally, the low at PAR/SER PROT IN PORT pin 8 changes to high, but the conducting transistors keep the voltage at pin 8 low and the diodes are cut off. If a fault occurs, the transistor between PAR/SER PROT IN PORT pin 2 and PAR/SER PROT OUT PORT pin 2 of the defective unit is cut off, allowing current to flow through the shutdown diodes. This develops internal shutdown signals that shut down all units.

## 2.8.3 CONFIGURING PARALLEL, SERIES, 2 X 2 OR 3 X 2 COMBINATIONS

NOTE: To power down the combination, first press the **STANDBY** key on the master to disable the output, then turn off the slave(s) followed by the master.

- 1. To configure a unit to be designated as a slave proceed as follows:
  - a. Turn on power only to the unit to be designated as a slave.
  - b. From the power-up screen press to enter the General Setup Menu. Highlight Series/Parallel and press to view the Multiple Units menu (see Table 2-12). If required, enter password (see PAR. 3.2.4.4) before continuing.

2-18 BOP HIPWR 022108

TABLE 2-12. MULTIPLE UNITS MENU FUNCTIONS

SETTING	CHOICES (BOLD = Factory Default)	FUNCTION
CONFIGURATION	STANDALONE PARALLEL SERIES MASTER 2 X 2 MASTER 3 X 2	STANDALONE - Unit operates independently, no additional units connected. PARALLEL - Unit to be configured for parallel operation; opens UNIT TYPE and CONNECTION TYPE options shown below. Used when units are connected in parallel (increase output current) (see NOTE below). SERIES - Unit to be configured for series operation; opens UNIT TYPE and CONNECTION TYPE options shown below. Used when units are connected in series (increase output voltage) (see NOTE below). MASTER 2 X 2 - Unit configured as master in control of two parallel branches comprised of two series connected units. Used when units are connected in parallel and series to double output voltage and current (see NOTE below). MASTER 3 X 2 - Unit configured as master in control of two parallel branches comprised of three series connected units. Used when units are connected in parallel and series to triple output voltage and double output current (see NOTE below).
UNIT TYPE (for parallel and series selections only)	STANDALONE MASTER +1 MASTER +2 MASTER +3 MASTER +4 SLAVE #1 SLAVE #2 SLAVE #3 SLAVE #4 SLAVE #5	STANDALONE - Unit operates independently, no additional units connected. MASTER+1 - Unit is the master (controller), with one slave unit connected. MASTER+2 - Unit is the master (controller), with two slave units connected. MASTER+3 - Unit is the master (controller), with three slave units connected. MASTER+4 - Unit is the master (controller), with four slave unit connected. SLAVE #1 - Unit is slave no. 1 in configuration using one to five slave units. SLAVE #2 - Unit is slave no. 2 in configuration using two to five slave units. SLAVE #3 - Unit is slave no. 3 in configuration using three to five slave units. For Master 2X2 and Master 3X2, slave #3 is always the unit controlled in parallel by the master. SLAVE #4 - Unit is slave no. 4 in configuration using four or five slave units. SLAVE #5 - Unit is slave no. 5 in MASTER 3X2 configuration using two parallel branches comprised of three series-connected units.
CONNECTION TYPE (for parallel and series selections only)	PARALLEL SERIES	Not Selectable - Indicates whether parallel or series was chosen as Configuration type.

- c. From the Multiple Units menu, highlight Configuration (use ADJUST control or the row keys) and press to modify. When prompted, enter ADMIN2 password (see PAR. 3.2.4.4). Select Series, Parallel, Master 2X2 or Master 3X2 and press to apply the change.
- d. If either Series or Parallel were selected in step c above, Connection Type shows Series or Parallel as selected. Highlight Unit Type and press I to modify. Highlight SLAVE #1 and press to apply the change.
- e. Exit the Multiple Units menu and return to main screen by pressing [4] to save the settings upon power-up. The unit goes to REMOTE mode, the status message reads MASTER Module not found, the Fault indicator is lit, and the unit continues to beep once a minute until the master is found. The only function keys displayed are [5], [6] and [6]. While the system is running, [6] and [6] are no longer available; [6] functions normally.

CAUTION: THE UNITS ARE NOW CONFIGURED AS SLAVE(S) TO BE CONTROLLED ONLY BY THE MASTER. DO NOT USE THE SLAVE KEYPAD, RS 232 PORT OR GPIB PORT TO TRY TO CONTROL THE SLAVE(S).


2. Repeat step 1 as necessary to configure all slaves, but at step c highlight applicable **SLAVE** # as appropriate. **Each slave MUST have a different number that is sequentially assigned.** 

- 3. Turn on the unit to be configured as a master and note that upon power up the **FAULT** light will go on (this is normal). Proceed as follows:
  - a. From the power-up screen press to enter the General Setup Menu. Highlight Series/Parallel and press to view the Multiple Units menu (see Table 2-12). When prompted, enter ADMIN2 password (see PAR. 3.2.4.4) before continuing.
  - b. From the Multiple Units menu, highlight **Configuration** (use **ADJUST** control or the keys) and press to modify. Select **Series**, **Parallel**, **Master 2X2** or **Master 3X2**, press to apply the change.
  - c. If Series or Parallel was selected in step b above, Connection Type shows Series or Parallel as selected above. Highlight Unit Type and press to modify. Highlight Master +1, Master +2, Master +3, Or Master +4 (Master +3, Or Master +4 not permitted for series connections) and press to apply the change.
  - d. Exit the Multiple Units menu by pressing [ to save the settings for subsequent power-up cycles. The display shows the master power-up screen (see Figure 2-9).

NOTE: Pressing to exit will cause the unit to revert to a standalone unit. If necessary, repeat steps a through d to configure the unit as a master

- e. Turn off power to the master, then turn on power to the master.
- f. The power-up master module screen (Figure 2-9) shows the status of the slave(s). Refer to Table 2-13 for an explanation of status indications for the slave(s).

If all the slaves are recognized as ready, after about 10 seconds the master LCD reverts to the Power On Default screen (see Figure 2-10). The slaves display the Slave Power On Default screen (see Figure 2-11), except the unit will be in Current Mode for parallel configurations and Voltage mode for series configurations and the message will indicate the unit is operating as a slave. The slave number appears at the lower left of the display. For instructions to return the slave to standalone operation, refer to PAR. 2.8.5. The fault indicators on all units are off.



3042678-1

FIGURE 2-9. MASTER POWER UP SCREEN


2-20 BOP HIPWR 022108

**TABLE 2-13. SLAVE STATUS MESSAGE DEFINITIONS** 

Slave Status Message Displayed on Master Power Up Screen (see Figure 2-9)	MEANING
Ready	Unit is ready for operation.
STANDBY	If unit's FAULT indicator is off, hardware error has NOT been detected, output is ready to be turned on
Powered OFF	Unit is not responding to polls via BITBUS.
Failed	Unit's FAULT indicator is on to indicate a hardware error has been detected.
Not Used	Unit is not part of parallel configuration
Unknown	Waiting for interface communication

If the master power-up screen is still displayed after 10 seconds, a slave was not properly recognized. Pressing or turning power off, then on again, reconfigures the unit as a standalone unit. Verify that the BITBUS cable is installed correctly. Verify that the slave has been properly configured as a slave per step 1 above. Repeat step 3. If the power up screen still does not revert to the power on default screen, refer to troubleshooting.

- 4. Adjust the limits to reflect the increased power capacity of the multiple unit combination as follows:
  - a. From the main screen, press 🛐 to enter the General Setup Menu.
  - b. From the General Setup menu, Highlight Max/Min Settings and press [2]. Press [2] to restore defaults. Verify that the Max/Min settings reflect the multiple unit combination. For example, for a parallel combination the values for +Current Max, -Current Min and ±Current Protect Max/Min now reflect the total current of the parallel combination. Voltage values and limits reflect a series combination. For 2 X 2 and 3 X 2 combinations both current and voltage are affected. NOTE: If desired, these limits may be lowered as described for a standalone unit (see PAR. 3.3.4).
  - c. Press 🛐 to save the settings upon power-up, then 🛐 to exit the General Setup menu and return to the power-up screen



3042678-2

FIGURE 2-10. POWER ON DEFAULT SCREEN FOR MASTER UNIT




FIGURE 2-11. POWER ON DEFAULT SCREEN FOR SLAVE UNIT

#### 2.8.4 OPERATING INSTRUCTIONS FOR MULTIPLE UNIT COMBINATIONS

- Apply power to the combination by first turning on the master, then turn on the slave(s). If the
  master is in STANDBY, depress STANDBY key on the master to apply power to the output
  terminals. (To power down the combination, first press STANDBY key on the master to disable the output, then turn off the slave, followed by the master.
- 2. When the units of a multiple unit combination are first turned on there is a brief delay until all units are communicating over the BITBUS to form the combined assembly.
  - When the master is turned on, the unit initially displays the Serial number as well as the Firmware Revision levels and power up test results for the Display, Interface and Analog processors, then displays the Master Power Up screen (Figure 2-9).
  - When a slave is turned on, the unit initially displays the Slave Power Up screen (Figure 2-11), the Fault indicator is lit, and the unit continues to beep once a minute until the master is found. For instructions to return the slave to standalone operation, refer to PAR. 2.8.5. Once the slave is up and running, the key indicates LOCKOUT and the key shows DISPLAY (see PAR. 3.2.5).
  - When the master finally recognizes all the slaves, the master LCD reverts to the Power
    On Default screen (see Figure 2-10). The slave(s) display the voltage meter (for series
    configurations) or current meter (for voltage configurations), and the message indicates
    the unit is operating as a slave with slave number shown at lower left corner. The fault
    indicators on all units are off.
  - Operation of a multiple unit combination is done by operating the master as described for a single unit. SCPI commands and front panel control actions applied to the master affect the multiple unit combination. The LCD display of the master refers to the multiple unit combination, while the front panel LCD of the slave shows the actual voltage (series) or current (parallel) provided by the slave.

2-22 BOP HIPWR 022108

# 2.8.5 RESTORING A UNIT TO STANDALONE OPERATION


- 1. Turn off power to the master.
- 2. Turn off power to the slave(s).
- 3. Turn on power to the unit to be restored to standalone operation.
- 4. From the power-up screen press \( \bigsize{1} \) to enter the General Setup Menu. Highlight Series/
  Parallel and press \( \bigsize{1} \) to view the Multiple Units menu (see Table 2-12). When prompted, enter ADMIN2 password (see PAR. 3.2.4.4) before continuing.
- 5. Press 1 to return to factory defaults. This configures the unit as a standalone unit.
- 6. Press [4] to save for power-up.
- 7. Turn off power to the unit, then turn power on. The unit will power up as a standalone unit.

# 2.8.6 CHANGING MULTIPLE UNIT CONFIGURATIONS

To change a unit from series, parallel, Master 2X2 or Master 3X2 operation to a different configuration, first set the unit to Standalone by referring to PAR. 2.8.5, then refer to PAR. 2.8.3 and configure as desired.

BOP HIPWR 022108 2-23/(2-24 Blank)

# SIMPLIFIED DIAGRAMS



CAUTION: REMOVE LINK BETWEEN (COM S) AND (COM MON) AT SLAVE 3 TO PREVENT DAMAGE TO THE BOP AND TO MAINTAIN SYSTEM ACCURACY.

2. REMOVE LINKS AT SLAVES 1, 2 AND 4 AS SHOWN TO COMPENSATE FOR DROP IN POWER CONECTIONS.

- 3. REFER TO CABLE KIT FOR PART NO.
- 4. USE #22 AWG WIRE FOR ALL SENSE CONNECTIONS.
- 5. INSTALL LINKS BETWEEN (COM S) AND (COM OUT) AT MASTER AND BETWEEN (OUT S) AND (OUT MON) AT SLAVE 2 FOR LOCAL SENSING.
- 6. FOR 3X2 AND 2X2 CONFIGURATIONS THE MASTER CONTROLS SLAVE 3, THUS CONTROLLING THE SERIES-CONNECTED SLAVES IN PARALLEL WITH THE MASTER.

FIGURE 2-12. 3 X 2 (3 SERIES X 2 PARALLEL) CONFIGURA-TION, LOCAL SENSING, TYPICAL

3042922

## **SECTION 3 - OPERATION**

## 3.1 GENERAL


This section explains how to operate the 1000 Watt BOP Power Supply. The power supply can be operated either in Local mode (see PAR's. 3.2 and 3.3) using the front panel keypad, ADJUST control and graphical display, or in Remote mode.

NOTE: Unless otherwise noted, operating instructions start from the power-up screen (see either Figure 3-3 or Figure 3-4). Press to exit submenus and return to the power-up screen.

Remote mode can either be analog or digital. Analog remote uses analog signals from the Analog I/O port to control the output (see PAR. 3.4). Digital remote (see PAR. 3.5) uses either the built-in GPIB (IEEE 488) (see PAR. 3.5.4) or RS 232 (see PAR. 3.5.6) interface to communicate with a remote computer. GPIB or RS 232 communication is via one of two protocols: 1) SCPI commands which afford full functionality of the BOP (see PAR. 3.6, Appendix A and Appendix B) or 2) CIIL commands (for compatibility with older Kepco products). Operation in remote mode can be simplified by the use of the VISA driver (see PAR. 3.5.5).

## 3.2 POWER SUPPLY BASICS

The following paragraphs describe basic operation of the front panel controls, which are used to configure and operate the power supply. This includes a description of the keypad (PAR. 3.2.1), graphical display (LCD (PAR. 3.2.2), how to turn the unit on (PAR. 3.2.3), how to change the power-up defaults (see PAR. 3.3.7). An explanation of the BOP menus (PAR. 3.2.4) provides basic techniques needed to use the ADJUST control and the function, arrow and numeric keys in conjunction with the LCD to operate the power supply. Operator convenience functions (LCD background and contrast, and the audible beep) are described in PAR. 3.2.5. Refer to Table 3-1 and Figure 3-1 for a description of front panel controls and indicators



3042338


FIGURE 3-1. BOP SERIES FRONT PANEL

# 3.2.1 KEYPAD DESCRIPTION (SEE FIGURE 3-2)

The front panel keypad is comprised of 27 kevs, eleven for 10 digits (0 - 9) plus decimal point. five dedicated to software functions ( 10 indicated by the display, four direction keys (11 indicated by the display, four direction keys (12 indicated by the display, four direction keys (13 indicated by the display, four direction keys (13 indicated by the display, four direction keys (14 indicated by the display, four direction keys (15 indicat

**TABLE 3-1. FRONT PANEL CONTROLS AND INDICATORS** 

NUMBER (FIGURE 3-1)	CONTROL/INDICATOR	FUNCTION
1	POWER ON/OFF circuit breaker A7CB1	Applies source power to unit
2	Alphanumeric/graphic Display (LCD)	Displays output voltage and current as well as information in response to keypad and ADJUST control entries. Displays function of soft function keys F1 through F5, and displays information as required to perform all local functions.
3	STANDBY indicator	Lights to indicate when the unit is in Standby mode. Behavior of the unit in Standby (Output off) is determined by the options chosen for Load Type (see PAR. 3.3.6). If the Load Type is ACTIVE (default), then in Standby mode the unit is set to voltage mode, voltage is set to zero, current protection is set to the nominal, and voltage limit is set to maximum.
4	Keypad	Access all local functions (see PAR. 3.2.1, Figure 3-2 and Table 3-2 for details).
5	FAULT indicator	Lights when a fault is detected. The failure of the following assemblies cause the FAULT indicator to go on: A1 (any control function failure), A2 (overtemperature, instant internal overcurrent, output overvoltage/overcurrent, local +15V failure), A4 (input under/overvoltage, input overcurrent, internal output under/overvoltage, internal output overcurrent, overtemperature, fan failure, local –15V failure). When the FAULT indicator lights, the LCD will briefly display messages about the fault (see Table B-5, Appendix B for details), however the FAULT indicator remains lit. When the fault has been removed, normal operation is restored by cycling power off, then on (preferred) or by briefly pressing the RESET key on the front panel to initiate a shut down and power up sequence (see RESET key, Table 3-2).
6	ADJUST control	The control Increases or decreases the highlighted digit of numeric fields (use or to change the highlight). When depressed, the control Increases or decreases the least significant digit of numeric fields. If the output is enabled, voltage and current adjustments are immediately present at the output without pressing ENTER. For alphanumeric fields, the control cycles through all alphanumeric and symbol characters. (use to highlight the next character and press ENTER when complete). On submenus the control highlights parameter of interest.



3042534

FIGURE 3-2. FRONT PANEL KEYPAD

3-2 BOP HIPWR 022108

# **TABLE 3-2. SPECIAL KEY FUNCTIONS**

KEY	FUNCTION
STANDBY	The STANDBY key toggles the unit between output on (enabled, STANDBY indicator off) and output off (disabled, STANDBY indicator on). When on, the output goes to the programmed settings. Behavior of the unit in Standby (Output off) is determined by the options chosen for Load Type (see PAR. 3.3.6). The default Load Type is ACTIVE, i.e., in STANDBY the unit is set to voltage mode, voltage is set to zero, current protection is set to the nominal, and voltage limit is set to maximum.
MODE	Depressing this key shifts the operating mode from voltage to current and vice versa, and at the same time sets the unit to STANDBY permitting the user to introduce new settings for the selected operating mode. The operating mode is indicated at the upper right of the LCD. Setting the unit to STANDBY when the mode is changed only occurs when using the MODE key.
or 🙀	From the power-up screen, these keys scroll the cursor from digit to digit within a field.
<b>↑</b> or <b>↓</b>	From the power-up screen, these keys scroll through the main or protection fields. Also used to scroll though and select options on other menus.
CLEAR	Clears numeric value to 0 (zero). Clears alphanumeric characters for new entry.
+/-	Switches the sign between + and – when inputting numerical values. The sign change applies only to the main channel: voltage in voltage mode, current in current mode.  CAUTION:Pressing +/– key while the power is applied to the load will reverse the polarity of voltage applied to the load.
ENTER	Activates highlighted parameters. When setting voltage/current values using the keypad, the values entered are not programmed until ENTER is pressed.
HELP	Provides context-sensitive help to assist in using the keypad and display to program the unit. Press HELP repeatedly for more help messages.
f1 through	The "soft" function keys are software dependent, and will change depending on the operation being performed. The key function is indicated by a box in the LCD which is aligned with the key (see PAR. 3.2.2).
RESET switch	Switch is recessed and requires the use of a tool to prevent inadvertent activation. Pressing RESET briefly causes the unit to shut down followed by execution of a power on sequence which results in the unit being set to the power on defaults (see PAR. 3.3.7). To restore normal operation after a fault has been cleared it is recommended that the unit be powered off, then on again instead of using the RESET key.  CAUTION:Pressing RESET will cause voltage transients to appear at the output which may damage a connected load.


## 3.2.2 LCD AND POWER-UP SCREEN DESCRIPTION

The LCD display is a  $320 \times 240$  pixel monochrome window that displays various menus depending on the state of the power supply and operator input. At the power-up screen, the LCD will show actual voltage and current at the BOP output, the mode (at the upper right), the function of the soft keys to the right, help text at the bottom, and main and complementary limit channel settings above the help text.

The power-up screen (Figure 3-3 or Figure 3-4) is presented upon power-up or when all submenus of a function have been exited. This screen shows analog and digital representations of the actual BOP output in the center of the display.

At the upper right of the display, the mode of operation is displayed:

- · Voltage source
- Voltage sink
- Current source
- · Current sink



WHEN SET TO BIPOLAR, ONLY ONE PROTECTION FIELD IS DISPLAYED.
WHEN SET TO INDEPENDENT, TWO PROTECTION FIELDS ARE DISPLAYED AS SHOWN HERE.
3042519-1 SEE PAR. 3.3.3.1 FOR DETAILS.

FIGURE 3-3. POWER-UP SCREEN SHOWING GRAPHIC METERS




FIGURE 3-4. POWER-UP SCREEN SHOWING TIME LINE GRAPH

When in Voltage mode, the power supply will (within the configured and rated limits) provide the programmed output voltage. Current is determined by the load, and cannot exceed the Current Protect limits. Mode displayed at the upper right is VOLTAGE SOURCE. If the protect limit is reached, CPROTECT is displayed.

When in Current mode, the power supply will (within the configured and rated limits) provide the programmed output current. Voltage is determined by the load, and cannot exceed the Voltage Protect limits. Mode displayed at the upper right is CURRENT SOURCE. If the protect limit is reached, VPROTECT is displayed.

If CPROTECT (current protection), VPROTECT (voltage protection) or PROTECT (analog protection, either voltage or current) is displayed, the power supply output is controlled by the protect channel and will not exceed the preprogrammed protection limit.

When in Source mode, the power supply is delivering (sourcing) energy to a passive load.

3-4 BOP HIPWR 022108

When in Sink mode, the power supply is operating as an electronic load, absorbing and recuperating the energy of an active load. Recuperated energy is passed back into the a-c source power line. Mode displayed at the upper right is VOLTAGE SINK when the unit is in voltage mode and an external constant current is injected into the BOP. Correspondingly, CURRENT SINK is displayed when the unit is in current mode and an injected current from an external constant voltage is presented at the output of the BOP. These messages are normally displayed briefly when voltage is decreased towards zero, and may also be displayed briefly during changes in a capacitive load.

The bottom lines of the display provide STATUS, ACTIVE SETTINGS and MESSAGES (including error messages).

STATUS includes whether the unit is under local or remote control, and identifies the main and protect channels. The protect channel will show either a single entry for both positive and negative VPROTECT or CPROTECT or separate entries for + and – VPROTECT or CPROTECT. This is established by selecting either Bipolar or Independent for Protect Entry (see PAR, 3.3.3.1).

ACTIVE SETTINGS show the values that will be applied to the respective channel. The high-lighted settings are used to program the unit and can be changed using the keypad or **ADJUST** control after highlighting. If these are changed using the keypad, the **ENTER** key must be pressed to program the unit; if the **ADJUST** control is used, the changed setting immediately programs the unit without pressing **ENTER**. If the main channel indicates CURR-EXT or VOLT-EXT, the setting establishes the full scale output corresponding to a 10V analog signal (see PAR, 3.4.3.2). If the main or protect channel indicates EXTERNAL, the corresponding setting is determined by an analog reference (see PAR. 3.4.3.1.

MESSAGES change depending on the particular screen being displayed. Error messages are displayed for both local and remote operation, and only appear briefly.

At the right of the display, five graphic boxes indicates the active function of the soft function keys, through F5. Depressing the corresponding key on the keypad activates the function shown on the display. These functions are arranged in a menu format (see PAR. 3.2.4).

## 3.2.3 TURNING THE POWER SUPPLY ON

# CAUTION: DO NOT REPEATEDLY TOGGLE THE CIRCUIT BREAKER/SWITCH AS THIS MAY DAMAGE THE UNIT.

Set POWER ON/OFF circuit breaker/switch (1, Figure 3-1) on front panel to ON. If actuator does not lock when released, wait a few seconds before trying again. The circuit breaker is "trip-free" design; if overload exists, contacts cannot be held closed by actuator.

When the power supply is turned on, it performs a brief self-test that includes testing the three processors (analog, interface and display), then displays the power-up screen (see Figure 3-3 or 3-4). If an error is detected, the FAULT indicator will light, information about the error will be briefly displayed on the LCD.

If the unit powers up in REMOTE mode, press [F1] (see PAR. 3.3.1) to set the unit to LOCAL mode.

NOTE: If the unit is a Slave of a multiple unit configuration, the unit will power up in REMOTE and will display LOCAL LOCKOUT once the Master has taken control of the Slave. To restore LOCAL control of a Slave, power down both master and slave, then turn on only the slave and press [1] (see PAR. 3.3.1) to set the unit to LOCAL mode.

If the display is not viewable, press [3] twice. The display will cycle through the range of contrast settings. Press [5] again to lock in the preferred contrast.

To select between the meter (Figure 3-3) and time line (Figure 3-4) displays refer to PAR. 3.2.5.3. To change the default power-up settings, refer to PAR. 3.3.7.

#### 3.2.4 HOW TO ACCESS THE MENUS

From the power-up screen, pressing the Function keys indicated on the LCD opens the associated menu. The menu opened may list submenus that may be opened either directly by pressing the associated Function keys, or by highlighting an item on the list and pressing the View/Modify function key. Menus and submenus will display a list of parameters, with the top one highlighted. The function key assignments can vary, but generally offer the following choices:

- If allows the highlighted parameter to be viewed or modified. After changing the parameter, the following choices are available.
  - F4 SAVE or **ENTER** to save the change
  - [5] EXIT to abort the change and exit to the previous menu.
- F2 RESTORE DEFAULT restores factory defaults for the parameters displayed (except for GPIB address). The factory defaults may be saved as power-up defaults by pressing F4.
- [3] The function varies, depending on the menu. In most cases [3] is used to abort a change without applying the modified setting. From the power-up screen [5] is used to adjust contrast. In the Revisions/TEST submenu of the General Setup Menu, [5] is used to execute a test.
- §4 SAVE FOR POWER-UP Saves the configuration shown as a power-up setting so the changes will not be lost when the unit is turned off.
- F5 APPLY EXIT applies the current (changed) setting without saving for power-up and exits to the previous menu or to the power-up screen, EXIT leaves the current menu without saving or applying changes.

## 3.2.4.1 OVERALL MENU STRUCTURE

The menu structure is as follows (NOTE: **BOLD** = Factory Default):

Power-up Screen (Power up menu)

- Save/Recall
- Saved Setups (Figure 3-8): Recall one of 99 saved setups.
- Saved Setup Details (Table 3-8): Mode (voltage/current), main channel reference (internal/external
- F2 Waveform
- Saved Waveforms (Figure 3-9): Choose one of 16 saved waveforms.
- New Waveform Settings (Table 3-12): Name (max. 10 characters), protection settings, count, mode (voltage/current)
- Waveform Settings (Figure 3-10): Name, protection settings, count, segment list, mode
- • Segment Details (Table 3-11): Type (square/±ramp/triangle/sine/level), frequency or period, p-p amplitude, offset, start/stop angle for sine and triangle, initial/repeat
- F3 Display
- Display and Beep Settings (Table 3-3): Display (meters/graphics (12 choices)), background (white/black), contrast, beep (On/Off/Error only)

3-6 BOP HIPWR 022108

- F4 Analog Remote Setup
- Analog Remote Settings (Table 3-15): Reference input (internal/external/external reference level), protection limit (internal/external/lesser limit), external mode (enable/disable)
- F5 General Setup (Figure 3-6)
- Interface Settings (Table 3-16): Data format (SCPI/CIIL), GPIB address (default = 6), \*RST sets Output (on/off), Device clear (SCPI/MATE), Serial Baud (Off/9600/19200), Xon/Xoff (enable/disable), prompt (enable/disable)
- Max/Min Settings (Table 3-5): Protect Entry (Bipolar/Independent); for voltage mode: +Voltage max, -Voltage min, ±CProtect max/min; for current mode: +Current max, -Current min, ±VProtect max/min
- Load Type (Figure 3-6): **Active**/Resistive/Battery
- Revisions/Test (Table 3-14): (Tests: display, keypad, interface, serial, analog and output)
- Calibration (PAR. 4.4): Voltage, Current and External and Controls calibration
- Power-up Settings (PAR. 3.3.7): Mode (Voltage/Current), Main channel reference (Internal/External Reference Level), protect channel type (Internal/External/Lesser Limit), Voltage Protect Limit (current mode, Current Protect Limit (voltage mode) output on/off
- · Password (See Figure 3-5 for default settings)
- Password Settings: Menu protection (Interface/Max-Min/Load/Test/Power-up/Keypad @ local/Keypad@power-up), Save Display chg (Enable/Disable), Passwords (Main/Admin1/Admin2 or Unprotected)
- Series/Parallel (Table 2-12): Configuration (Standalone/Parallel/Series/Master 2X2/Master 3X2); for parallel or series: Unit Type (Standalone/Master+1 to+4/Slave #1 to #5) and Connection Type: shows Series or Parallel).

## 3.2.4.2 HOW TO MODIFY A PARAMETER

First access the parameter by accessing the proper menu as described above (PAR 3.2.4); Tables 3-3 through 3-15 list the menu parameters. To modify a parameter listed in a menu or submenu, proceed as follows:

- 1. Highlight the parameter using the 1 and 1 keys.
- 2. When the desired choice is highlighted, press to modify the active setting. The choices are displayed with the active setting highlighted. In the case of numerals, the units digit is highlighted.
  - To change a numeric setting, press the number keys, then press ENTER to program the numbers entered. Use the CLEAR key to clear numbers entered and start over. The ADJUST control can also be used to increment or decrement the highlighted digit. Pressing ADJUST while rotating adjusts the least significant digit. If the output is on (unit not in Standby) changes made using the ADJUST control are immediately applied to the output.
  - For alphanumeric characters use multiple presses of the keys for letters or symbols: (space), (1 (+, -, /), (2 (ABC), (3 (DEF), (4 (GHI), (5 (JKL), (6 (MNO)), (7 (PQRS), (TUV), (9 (WXYZ)). Use the → key to highlight the next character. As an alternative, the → or ↑ keys or ADJUST control will scroll through numbers, and letters and symbols. Use the CLEAR key to clear the entire alphanumeric field and start over
- 3. Press 1 and 2). To abort (return to the menu without applying the change, press 1.

NOTE: Press **HELP** key for more information, press **HELP** again to see multiple screens; press **CLEAR** key to exit the help screen.

# 3.2.4.3 PASSWORD SETUP.

Parameters that can be protected may be designated as Unprotected (no password required) or assigned one of three possible passwords: Main Unit, Admin 1 and Admin 2. The three passwords can be used to independently protect certain settings to prevent tampering or inadvertent

reconfiguration of the BOP, yet allow access to qualified personnel. **These password levels apply only to local operation.** When in remote, only the main password is accessible, acting as a general password (see PAR B.111). The functions that can be password protected are Interface settings, Max/Min settings, Load type, Test, Calibration, Power-up Settings, and Keypad lockout at power-up. In addition, it is possible to prevent changes made to the display settings from being saved for power up by setting Save Display Chg to Disable (default).

When the unit is operating in remote mode with Keypad @ local activated, a password is required before the unit can be returned to local operation. In addition, when a waveform is executing in local mode, depressing for to stop the waveform requires a password before the waveform is stopped.

To change any password you must enter the Admin 2 password to access the Password Menu. The unit is shipped with the Admin 2 password set to "**KEPCO**," the Main Unit password set to "**DEFAULT**," and the Admin 1 password set to "**A**." To change the password or to protect one of the protected menus, proceed as follows:

- 1. Press f from the power-up screen to enter the General Setup menu. Highlight Password and press .
- 2. Enter the Admin 2 password (see PAR. 3.2.4.4 for details), then press [1] to verify. The Password Protection menu (see Figure 3-5) is now displayed.
- 3. To change a password, highlight the Main Unit, Admin 1 or Admin 2 password and press to modify.
- 4. Press **CLEAR** to erase the previous password from memory.
- 5. Enter the new password (see PAR. 3.2.4.4) and press [4] to save. Up to eight characters are permitted for passwords.

NOTE: Do NOT use space characters for passwords

6. To protect or unprotect a menu highlight the password setting for the menu (Interface, Max-Min, Load, Test, Power-up, Keyboard @ Local, Keypad@power-up) and press [1] to modify. Highlight either the desired password (Main Unit, Admin 1 or Admin 2) or Unprotected and press [1] to save.

NOTE: To restore the password protection defaults shown in Figure 3-5, press [72]; this leaves the three individual passwords remain unchanged.

7. When complete, press [4] to save for power-up or [5] to apply the changes (without saving for power-up) and exit.

## 3.2.4.4 HOW TO ACCESS A PASSWORD PROTECTED MENU


An administrator can independently assign one of three passwords (Main Unit, Admin 1 or Admin 2) to eight functions. Under General Setup the Series/Parallel submenu is assigned the Admin 2 password; this cannot be changed.

When trying to modify a protected setting or access a protected menu, the message PASS-WORD IS REQUIRED appears at the top, and the first character is highlighted. Proceed as follows:

3-8 BOP HIPWR 022108

- 1. Enter the first character of the password using the keypad or ADJUST control (see PAR. 3.2.4.2 for entry of alphanumeric characters). (To change the password, refer to PAR. 3.2.4.3.)
- Press to move to the next character and repeat step 1 for the next character of the password.
- 3. Repeat steps 1 and 2 until the correct password is displayed, then press to verify. The protected setting or menu will now be accessible

NOTE: If fine the password is incorrect, the message Password incorrect is displayed at the bottom of the screen. Press CLEAR and proceed to step 1 above.



3042519-10

FIGURE 3-5. PASSWORD PROTECTION MENU, FACTORY DEFAULTS

# 3.2.5 OPERATOR CONVENIENCE FUNCTIONS (DISPLAY MENU)

From the power-up screen (Figure 3-3), pressing [3] opens the operator convenience functions menu (see Table 3-3). The functions listed can be modified using the techniques described in PAR.3.2.4). This function is always available, whether in Local, Remote or Local/Lockout mode.

NOTE: If [ is not available when the operator convenience menu is open, these functions (see PAR. 3.2.5.1 to 3.2.5.3) can not be saved for power-up. To save for power-up it is first necessary to change SAVE DISPLAY CHG at the password setup from DISABLE (default) to ENABLE (see PAR. 3.2.4.3 and Figure 3-5). After saving the changes for power-up, SAVE DISPLAY CHG at the password setup can be set to DISABLE to prevent future changes if desired.

## 3.2.5.1 ADJUSTING LCD BRIGHTNESS, CONTRAST AND BACKGROUND

From the power-up screen, (Figure 3-3), press [3] twice to initiate contrast adjustment. The contrast gradually alternates between light and dark. When the contrast is acceptable, press [5] to apply the change and exit contrast adjust. Use the [2] and [3] keys for fine adjustment of contrast. Contrast can also be adjusted from the power-up screen by pressing [3] once, then pressing [3] and [4] as needed for fine adjustment.

To change the background, press [53] from the power-up screen, Highlight Background, press [54], highlight Black or White, then [54] to save. Press [54] exit and save for power-up or [55] to apply the changes (without saving for power-up) and exit.

TABLE 3-3. DISPLAY (OPERATOR CONVENIENCE) MENU FUNCTIONS

SETTING	CHOICES (BOLD = Factory Default)	FUNCTION
NOTE: To save any of the functions listed below for power-up it is necessary to first change SAVE DISPLAY CHG a setup (see PAR. 3.2.4.3and Figure 3-5) from DISABLE to ENABLE.		
GRAPHIC DISPLAY	Meters 75s Graph 30s Graph 15s Graph 7.5s Graph 3.8s Graph 1.5s Graph 0.8s Graph 0.5s Graph 0.15s Graph 0.15s Graph 0.15s Graph 0.015s Graph 0.015s Graph 0.015s Graph	METERS - Output voltage and current are displayed on representations of analog meters.  GRAPH - Displays a sample of the output for the time indicated (see Figure 3-4). The complete time-line uses 240 points. E.g., selecting 2 Second Graph means that 2S/240 = 50ms sampling, i.e., every 50ms a snapshot of the output state is used to produce a single point.
DISPLAY BACKGROUND	White <b>Black</b>	WHITE - Sets the background to white and displays black characters. BLACK - Sets the background to black and displays white characters.
KEY PRESS BEEP	<b>ON</b> ERROR ONLY OFF	ON - provides an audible beep for each key press and for each error received. ERROR ONLY - silences the beeps for each key press; errors will still cause beep.  OFF - silences all beeps including key presses and errors except for power-up and unit faults
NOTE: Control display contrast by pressing [3] twice to dynamically change the contrast, then press [3] to set when contrast i acceptable. Contrast can also be set directly by pressing [4] once and using [4] as needed (see PAR. 3.2.5.1)		

## 3.2.5.2 ENABLING/DISABLING AUDIBLE BEEPS

From the power-up screen (Figure 3-3), press  $\mathbb{F}^3$ , then refer to Table 3-3 and modify the setting using the techniques described in PAR. 3.2.4). Even though audible beeps are set to off, the beeps will still sound upon power-up or detection of a power supply fault.

## 3.2.5.3 DISPLAYING METERS OR GRAPH (TIME LINE)

The top screen can be configured to either display graphical analog meters (Figure 3-3) showing a coarse representation of voltage and current in addition to the digital readout, or a graphical time line (Figure 3-4). The graphical time line is not an oscilloscope type display. Instead, it samples the output and refreshes the screen at a specified interval: 75, 30, 15, 7.5, 3.8, 1.5, 0.8, 0.3, 0.15, 0.08 or 0.04 seconds. This can be useful when executing a waveform, although it is not a substitute for monitoring the output with an oscilloscope for precision. There is no correlation between voltage and current graphs. For the best graphical representation choose the graph time that is closest to, but greater than, the waveform time duration.

From the power-up screen, press [3], then highlight the Graphic Display setting and press [4]. Highlight any of the meters or one of the graph selections and press [4] to save. Then press [5] to save for power-up or [5] to exit.

3-10 BOP HIPWR 022108

#### 3.3 LOCAL MODE OPERATION

Local operation of the BOP power supply can be accomplished from the front panel via the 27 key keypad, and the ADJUST knob. All indications are provided by the 4-inch graphical display (LCD).

## 3.3.1 SETTING LOCAL MODE

When the power supply is turned on, it is automatically set to Local mode. If the unit is in REMOTE mode and the display shows **F1-Local**, pressing [1] sets the unit to LOCAL mode.

#### 3.3.1.1 KEYPAD LOCKOUT

To prevent the unit from entering local mode from the front panel once remote mode has been entered, refer to PAR. 3.2.4.3 and assign a password to "**Keyboard @ local**." Then the unit will not permit local operation until the proper password has been entered (see PAR. 3.2.4.4). NOTE: The [3] key can still be used to adjust display contrast before entering the password.

If the F1 key legend is F1 - LOCAL LOCK OUT, the keypad has been locked by the remote command SYST:KEYB DIS (see PAR. B.107). To unlock the keypad, either send SYST:KEYB ENAB or turn the unit off then on again.

#### 3.3.1.2 LOCAL PASSWORD PROTECTION AT POWER-UP

It is possible to require a password before the front panel controls can function when the unit is powered up. From the power-up screen, press [5], highlight password, then [1]. Enter Admin 2 password (see PAR. 3.2.4.4) and press [1] to verify. Under Menu Protection, highlight Keypad @ Pwr-up and press F1. Highlight on of three password settings and press [4] to save. Then press [4] to save for power-up (or [5] to exit without applying the changes). When the unit is next powered up, pressing any keypad key or rotating the ADJUST control requires entry of the password selected above before continuing. NOTE: The [5] key can still be used to adjust display contrast before entering the password.

## 3.3.2 SETTING VOLTAGE OR CURRENT MODE

The BOP uses two separate channels, one to set output voltage or current and one to set the corresponding protection limit. The main channel is determined by the **MODE** key (in local mode) which alternately selects either Voltage mode or Current mode or by SCPI command (in digital remote mode). The protection channel is determined automatically by the main channel selected. When Voltage mode is selected, the current protection channel is active, and when Current mode is selected, the Voltage protection channel is active.

## 3.3.3 PROGRAMMING VOLTAGE OR CURRENT AND ASSOCIATED PROTECT LIMITS

From the power-up screen the settable voltage/current parameters are displayed at the bottom of the LCD above the **HELP** message (see Figure 3-3). Use or to highlight the main or protect channel. (For BOP protect limits refer to PAR. 3.3.4.2 and for external limits see PAR. 3.3.4.3.)

1. To verify that the unit is configured for internal references press [4] from the power-up screen and verify that Reference Input and Protection Limit are set to Internal, and External Mode is set to Disable. If necessary to change a setting, use [5] or [6] to highlight the parameter, and press [6] to modify. Highlight the desired selection and press [6] to save, then press [6] to save for power-up or [6] to exit. If analog programming is desired, refer to PAR. 3.4.

- 2. Verify that the load has been configured properly to ensure that the unit behaves as expected when the output is off (see PAR. 3.3.6 for details).
- 3. Press **MODE** key to select the main channel (VOLTAGE or CURRENT); the associated PROTECT channel is automatically selected and displayed.
- 4. Set the output on or off as desired using the **STANDBY** key. The output is off (disabled) when the **STANDBY** indicator is lit, on (enabled) when not lit.
- 5. Use for to highlight the main channel. There are two ways to program the output in local mode. These methods can be used either when the output is disabled (**STANDBY** indicator lit) or enabled.:

CAUTION: WHEN THE ADJUST CONTROL IS ROTATED, THE ACTIVE PARAMETER IS IMMEDIATELY EFFECTIVE IF THE OUTPUT IS ENABLED (ON = STANDBY INDICATOR NOT LIT). THE VOLTAGE/CURRENT APPLIED TO THE LOAD CHANGES AS THE ADJUST CONTROL IS ROTATED.

- a. Use the **ADJUST** control to increase or decrease the main channel setting (e.g., voltage when the unit is in voltage mode). Start with the most significant digit of the desired value, then use to highlight the next digit. For fine adjustment press the **ADJUST** control in while rotating the knob to modify the least significant digit.
- b. Enter the desired value on the keypad using the number keys. For example, to program the BOP to 75.8V, press the following keys in order [7] then press ENTER. For fine adjustment use [6] and [6] to modify the least significant digit. To correct the entry before activation press the CLEAR key to set the value to zero and start over. When the desired value is displayed, press ENTER. This causes the new value to appear at the output and be applied to the load if the output is enabled.

NOTE: The value entered for the main channel and the protect channel is automatically prevented from exceeding the present maximum software limit (see PAR. 3.3.4).

6. To program the corresponding Protect channel, press or as necessary to highlight the Protect channel. Then set the value using either of the two methods described above. If the Protect Entry setting (see PAR. 3.3.3.1) is set to Independent, separate entries for the positive and negative protect channel are possible. Otherwise the value entered is applied to both positive and negative protect channels.

# 3.3.3.1 SELECTING BIPOLAR/INDEPENDENT PROTECTION LIMITS


The BOP can be configured to show the protection limits as either a single value that applies to both protection channels or show individual settings for positive and negative protection limits. Selecting Independent protection limits means that the positive and negative limits are displayed (and can be modified) independently. Bipolar means that for each protection limit (voltage or current) a single value applies to both the positive and negative limits; only one value is displayed and can be edited for both  $\pm$  protection limits.

3-12 BOP HIPWR 022108

TABLE 3-4. VOLTAGE AND CURRENT PARAMETER DEFINITIONS

Term	Definition	To modify refer to PAR.	
			Remote
+E <sub>Onom</sub> -E <sub>Onom</sub>	The nominal (rated) output voltage of the unit determined by model; e.g. for a BOP 36-28MG, ±E <sub>Onom</sub> is 36V.	N/A	N/A
+I <sub>Onom</sub> -I <sub>Onom</sub>	The nominal (rated) output current of the unit determined by model; e.g. for a BOP 36-28MG, ±I <sub>Onom</sub> is 28A.	N/A	N/A
+Voltage –Voltage	Voltage mode only. Positive (+) and negative (–) output voltage values established by keypad or remote command.  Range (+): 0 to +Voltage max  Range (–): 0 to –Voltage min	3.3.3	B.67
+Voltage max –Voltage min	Voltage mode only. Maximum (positive) and minimum (maximum negative) voltage that can be set.  Value (+): 0 to +E <sub>Onom</sub> Value (-): 0 to -E <sub>Onom</sub>	3.3.4.1	B.69, B.70, B.71, B.73
+Current Protect -Current Protect	Voltage mode only. Defines maximum (+) current and Minimum (maximum negative) (-) that unit can source or sink.  Range (+): +Current Protect min to +Current Protect max  Range (-): -Current Protect max to -Current Protect min	3.3.3	B.51, B.52, B.57, B.55
+Current Protect Max -Current Protect Min	Voltage mode only. Maximum setting for +Current Protect and Minimum (maximum negative) setting for -Current Protect.  Value (+): +Current Protect min to (1.01 x +Current max)  Value (-): -Current Protect max to (1.01 x -Current min)	3.3.4.2	B.59, B.60, B.63, B.61
Minimum (box) +Current Protect Min -Current Protect Max	<b>Voltage mode only.</b> Minimum (positive) setting for +Current Protect and maximum (maximum negative) setting for -Current Protect. Values of ±Current Protect between +Current Protect Min and -Current Protect Max (near zero) are not allowed. This zone (also referred to as the <i>minimum (box)</i> is automatically calculated by the BOP (see Figure 1-2).	N/A	N/A
+Voltage Protect  -Voltage Protect	Current mode only. Maximum positive (+) and minimum (maximum negative) (-) voltage that can appear at the output.  Range (+): +Voltage Protect min to +Voltage Protect max  Range (-): -Voltage Protect max to -Voltage Protect min	3.3.3	B.77, B.78, B.83, B.81
+Voltage Protect Max -Voltage Protect Min	Current mode only. Maximum (positive) setting for +Voltage Protect and Minimum (maximum negative) setting for -Voltage Protect.  Value (+): +Voltage Protect min to (1.01 x +Voltage max)  Value (-): -Voltage Protect max to (1.01 x -Voltage min)	3.3.4.2	B.85, B.86, B.89, B.87
Minimum (box) +Voltage Protect Min –Voltage Protect Max	<b>Current mode only.</b> Minimum (positive) setting for +Voltage Protect and maximum (maximum negative) setting for –Voltage Protect. Values of ±Voltage Protect between +Voltage Protect Min and –Voltage Protect Max (near zero) are not allowed. This zone (also referred to as the <i>minimum (box)</i> is automatically calculated by the BOP (see Figure 1-2).	N/A	N/A
+Current -Current	Current mode only. Positive and negative output current established by keypad or remote command. Range (+): 0 to +Current max Range (-): 0 to -Current min	3.3.3	B.41
+Current max  -Current min	Current mode only. Maximum (positive) and minimum (maximum negative) current that can be set.  Value (+): 0 to +I <sub>Onom</sub> Value (-): 0 to -I <sub>Onom</sub>	3.3.4.1	B.43, B.44, B.47, B.45

Press from the power-up screen to enter the General Setup menu (Figure 3-6), then highlight Max/Min Settings. Press flow to enter the Max/Min Settings submenu (Figure 3-7). (If a Password is required, see PAR. 3.2.4.4 for instructions.) Highlight Protect Entry and press flow to change it. Highlight Bipolar or Independent, then flow to save, or flow to abort. When complete, press flow to save for power-up, or flow to abort, or flow to apply the changes (without saving for power-up) and exit.



NOTE: F3 AND F4 ARE ONLY VISIBLE IF A CHANGE HAS BEEN MADE TO A SUBMENU.

3042519-4

FIGURE 3-6. GENERAL SETUP MENU




FIGURE 3-7. MAX/MIN SETTINGS MENU

Selection of Bipolar does not immediately change the protect limit values; it changes how the protect settings are displayed and set from the power-up screen. So if *maximum/minimum* protection limits were set to different values, (e.g, for BOP 36-28MG, current mode, no load, +V Protect Max = 25V and –V Protect Min = 7V) when BIPOLAR is selected, the previous protec-

3-14 BOP HIPWR 022108

tion values (+25, -7) will remain in place until a new value is entered in the Voltage Protection field. When a new Voltage Protect setting, e.g., 22V, is entered with BIPOLAR mode selected, +Voltage Protect is set to +22V and -Voltage Protect to -22V.

NOTE: The use of remote programming (via RS 232 or GPIB) automatically asserts Independent protection limits. Once the unit is returned to local mode, the unit is automatically returned to BIPOLAR mode.

#### 3.3.3.2 UNDERSTANDING VOLTAGE AND CURRENT PROTECT LIMITS

These values are the references for the complementary channels: voltage in current mode and current in voltage mode. The range for these values is between a minimum (box) value (see Figure 1-2) and 1% above the rated nominal value (see PAR. 3.3.4.2). If the unit is in voltage mode, it will enter current protect mode when the load demands more current and energy than permitted by the ±current protect settings. Similarly, if the unit is in current mode, it will enter voltage protect mode if the load demands more voltage and energy than permitted by the ±voltage protect settings. When the protect settings are exceeded, the protection channel limits the output, a VPROTECT, CPROTECT or PROTECT (PROTECT may be seen only when external limits are in use) message is displayed at the upper right of the LCD, and the power supply continues operation.

#### 3.3.3.3 HIDDEN VOLTAGE AND CURRENT PROTECT LIMITS

The BOP employs two back-up channels which function as safety backups if a main channel fails. The backup channel limits are fixed and not user accessible. These limits are set to 5% over the nominal (rated) values for voltage or current. If the software limits for a main channel is changed (PAR. 3.3.4.1) the corresponding protect channel limit is automatically changed to be 5% of the nominal (rated) value above the user-programmed software limit.

# 3.3.4 CHANGING MAXIMUM OR MINIMUM SOFTWARE-CONTROLLED LIMITS

The maximum or minimum allowable voltage and current settings of the unit can be reduced from the nominal using the Max/Min Settings menu. which lists the system's software-controlled voltage and current limits (+Voltage Max, -Voltage Min, +Current Max, -Current Min) as well as the corresponding protection limits organized by operating mode. The default values of the system limits are established by the Model: the nominal (rated) values for voltage and current and 1.01 x the nominal (rated) values for protection. The default values can be reduced by modifying the highlighted parameter. The unit will not accept local or remote commands that exceed the system limits. The system limits are always in effect, even when the unit is controlled by an external reference. If system limits are changed, the protection limits must be changed to correspond to the new system limits. As an example, changing +Voltage Max and -Voltage Min of a BOP 36-28MG to ±3V, respectively, causes the unit to behave as if it was a BOP 3-28MG. In this case it is important to change the +V Protect Max and -V Protect Min limits (e.g., to ±3.3V, respectively) so that the load is protected when operating in Current Mode. System limits are absolute values (do not use minus sign for negative limits).

The internal parameters +Current Protect Min and –Current Protect Max are displayed to completely define the permissible window when operating in Voltage mode. Similarly, +Voltage Protect Min, and –Voltage Protect Max are displayed to completely define the permissible window for voltage when operating in Current mode.

**TABLE 3-5. MAX/MIN SETTINGS MENU** 

SETTING	CHOICES (BOLD = Factory Default)	FUNCTION	
Protect Entry	BIPOLAR INDEPENDENT	BIPOLAR - Causes a single protection limit value (one for voltage, one for current) to apply to both ± limits. Only one value is displayed and edited from the front panel. (see PAR. 3.3.3.1.) INDEPENDENT - Allows + and – protection limits to be set independently. from the front panel (see PAR. 3.3.3.1 for considerations when using remote mode).	
	•	VOLTAGE MODE	
+Voltage Max	(value) +Eomax	Defines the maximum voltage level that can be set in voltage mode. Default = Rated +Output voltage (e.g., for BOP 36-28MG, Eomax = 36). To modify, see PAR. 3.3.4.1.	
-Voltage Min	(value) –Eomax	Defines the minimum (maximum negative) voltage level that can be set in voltage mode. Default = Rated –Output voltage (e.g., for BOP 36-28MG, Eomax = 36). To modify, see PAR. 3.3.4.1.	
+C Protect Max	(value) model specific up to lomax + 1% of lomax	Defines the maximum value for +Current Protect. To modify refer to 3.3.4.1.	
+C Protect Min	(internal value) Not Adjustable	Defines the minimum value that +Current Protect can be set to. This is a calculated value and is not adjustable from the front panel.	
-C Protect Max	(internal value) Not Adjustable	Defines the maximum (minimum negative) value that –Current Protect can be set to. This is a calculated value and is not adjustable from the front panel.	
-C Protect Min	(value) model specific up to lomax + 1% of lomax	Defines the minimum (maximum negative) value for –Current Protect. To modify refer to 3.3.4.1.	
		CURRENT MODE	
+Current Max	(value) +lomax	Defines the maximum current level that can be set in current mode. Default = Rated +Output current (e.g., for BOP 36-28MG, Iomax = 28). To modify, see PAR. 3.3.4.1.	
-Current Min	(value) –lomax	Defines the minimum (maximum negative) current level that can be set in current mode. Default = Rated –Output current (e.g., for BOP 36-28MG, Iomax = 28). To modify, see PAR. 3.3.4.1.	
+V Protect Max	(value) Eomax +1% of Eomax	Defines the maximum value that +Voltage Protect can be set to. To modify refer to 3.3.4.1.	
+V Protect Min	(internal value) Not Adjustable	Defines the minimum value that +Voltage Protect can be set to. This is a calculated value and is not adjustable from the front panel.	
–V Protect Max	(internal value) Not Adjustable	Defines the maximum (minimum negative) value that –Voltage Protect can be set to. This is a calculated value and is not adjustable from the front panel.	
–V Protect Min	(value) Eomax + 1% of Eomax	Defines the minimum (maximum negative) value for –Voltage Protect. To modify refer to 3.3.4.1.	
NOTE: To restore all Max/Min settings defaults, press f5 from the power-up screen, highlight Max/Min settings, press f1 to restore defaults shown above in <b>BOLD</b> . Press f2 to save for power-up or f3 to apply the changes (without saving for power-up) and exit.			

# 3.3.4.1 CHANGING MAXIMUM ACCEPTED VOLTAGE OR CURRENT (MAIN CHANNEL SOFT-WARE LIMITS)

The software limits for the main channels (+Voltage Max, -Voltage Min, +Current Max and - Current Min) are the maximum (positive) and minimum (Maximum negative) values allowable for voltage and current. The default software limits are determined by the model: the nominal (rated) values for voltage and current (e.g., 36V and 28A for the BOP 36-28MG). These four values can be adjusted independently. For example, a BOP 36-28MG, capable of delivering ±36V in voltage mode can be configured to allow voltage to be adjusted only from -1V to +15V by setting -Voltage Min to -1 and +Voltage Max to +15. Similarly, a BOP 36-28MG,

3-16 BOP HIPWR 022108

capable of delivering  $\pm 28\text{A}$  in current mode can be configured to allow current to be adjusted from -0.5A to +10A by setting -Current Min to -0.5 and +Voltage Max to +10. Adjustment range is between 0 and  $\text{E}_{\text{Onom}}$  for voltage and 0 and  $\text{I}_{\text{Onom}}$  for current. Note that these software limits are not the same as the Protect Limits described in PAR. 3.3.4.2.

The main channel software limit values can be lowered (closer to zero) by the user, e.g., to prevent inadvertent damage to a specific circuit under test. When the maximum/minimum values are lowered, the unit will not accept values that exceed the new software limits. If the user attempts to enter a value that exceeds the software limit, the unit will continue to function. in local mode the Exceeding Maximum Allowed Value message is displayed, and the output will be clamped to the main channel software limit (maximum/minimum) value. In remote mode the command is considered invalid and is disregarded: a 120 error is produced and the message Voltage Out of Range or Current Out of Range is displayed on the front panel.

The main channel software limits are always in effect, even when the unit is controlled by an external reference. If main channel software limits are changed from the default, the protection limits must be changed to correspond to the new software limits (see PAR. 3.3.4.2). As an example, changing +Voltage Max and –Voltage Min of a BOP 36-28MG to ±3V, respectively, causes the unit to behave as if it was a BOP 3-28MG. In this case it is important to change the +V Protect Max and –V Protect Min limits (e.g., to ±3.3V, respectively) so that the load is protected when operating in Current Mode.

- 1. Press form the power-up screen to enter the General Setup menu, then highlight Max/Min Settings.
- 2. Press to enter the Max/Min Settings submenu (Figure 3-7 and Table 3-5). (If a Password is required, see PAR. 3.2.4.4 for instructions.)
- 3. Highlight the voltage or current max/min value and press [1] to change it. Software limits are absolute values (do not use minus sign for negative limits). Use number keys to change the setting, then [4] to save.
- 4. When complete, press [4] to save for power-up, [5] to abort, or [5] to apply the changes (without saving for power-up) and exit.
- 5. Upon return to the power-up screen, the main channel (voltage or current) is compared against the main channel limits in effect. If the main channel exceeds the limit, it is set to zero.

# 3.3.4.2 CHANGING MAXIMUM/MINIMUM PROTECTION SOFTWARE-CONTROLLED LIMITS

The  $\pm$  protection limits are software limits that establish the maximum and minimum (maximum negative) allowable levels of output voltage in current mode and current in voltage mode. The default protection limits are 1% above  $E_{Omax}$  or 1% above  $I_{Omax}$ .

The protect channel limits are +V (voltage) Protect max, -V Protect min, +C (current) Protect Max and -C Protect min (see Table 3-4); these prevent the unit from delivering voltage or current that exceed these settings. In voltage mode the current protect channel is clamped to the limit value; in current mode the voltage protect channel is clamped to the limit value. Adjustment

range is between a minimum (box) value (see Figure 1-2) and 1% above the nominal (rated) value.

# CAUTION: WHEN WORKING WITH ACTIVE LOADS, ALWAYS ADJUST THE BOP PROTECTION LIMITS TO BE ABOVE THE MAXIMUM VALUES OF VOLTAGE OR CURRENT EXPECTED FROM THE LOAD. FOR EXAMPLE, WHEN THE BOP IS OPERATING IN VOLTAGE MODE SINKING ENERGY FROM A CONSTANT CURRENT TYPE LOAD, SET THE CURRENT PROTECTION LIMITS OF THE BOP ABOVE THE MAXIMUM CURRENT EXPECTED FROM THE LOAD.

- 1. Press form the power-up screen to enter the General Setup menu, then highlight Max/Min Settings and press to view. (If a Password is required, see PAR. 3.2.4.4 for instructions.)
- 2. Highlight the ±CPROTECT or ±VPROTECT max/min value and press [1] to change it. Software limits are absolute values (do not use minus sign for negative limits). Use number keys to change the setting. Press [4] to save, or [5] to abort.
- 3. When complete, press [4] to save for power-up, or [5] to abort, or [5] to apply the changes (without saving for power-up) and exit.
- 4. Upon return to the power-up screen, the new protection limit (voltage or current) is compared against the protection limits in effect. If the new protection limit setting is below the existing setting for the protection limit, the protection channel (voltage or current) is set to zero.

#### 3.3.4.3 EXTERNAL LIMITS

These limits are external analog signals which are converted within the BOP to digital signals that program the protection channels only: current protect in voltage mode and voltage protect in current mode. The range of each analog input signal is +1V to +10V, corresponding to a range for clamping the output between minimum, 10% of nominal (positive and negative), to +max/-min of nominal rating. Refer to PAR. 3.4.4 for details on implementing external limits.

Table 3-4 explains the effect that these limits have in both voltage and current mode, and references the corresponding paragraph for changing the parameter in either local or remote mode.

#### 3.3.5 ENABLING/DISABLING DC OUTPUT POWER

The BOP output can be disabled (OFF) or enabled (ON) by toggling the **STANDBY** key in local mode or sending the SCPI OUTPut ON or OUTPut OFF command (see PAR. B.12) via the selected digital remote control bus (see PAR. 3.5). The behavior of the unit when disabled depends on the Load Type setting (see PAR. 3.3.6 and Table 3-6 for details).

# 3.3.6 DETERMINING HOW THE UNIT RESPONDS WHEN OUTPUT IS OFF (LOAD TYPE)

The BOP supports three Load Type selections (see Table 3-6) which determine how the power supply responds when the output is off: ACTIVE, RESISTIVE and BATTERY. (Load type CUSTOM (not normally active) permits customized settings to be implemented; for details contact consult factory.) These selections are designed to provide proper operation with different load types. It is important to note that the Load Type selection does not affect the settings of the power supply for ON state; it only affects the main internal reference level and the protection levels during the OFF state.

3-18 BOP HIPWR 022108



For inductive loads, and especially superconducting magnet type loads, the inherent offset of the BOP in the OFF state may generate significant current in the circuit. A properly rated switch in parallel with a resistor must be connected between the power supply and the load. The switch must be open and the BOP front panel LCD must read 0V, 0A before removing or installing connections between BOP and load.

**ACTIVE.** Active mode (default setting) is necessary for the power supply to function properly and safely with inductive loads and constant-current-type active electronic loads. Active mode can also be used with resistive loads. Table 3-6 indicates how the power supply responds to a command to go from Output ON to OFF. When the output is disabled, the unit is set to voltage mode, voltage is set to zero and both current protect and voltage limit are set to maximum. When the unit is enabled, the pre-existing settings for voltage, current protect and voltage limit are restored.



For both inductive loads and constant-current-type active electronic loads when the BOP output is set to OFF, a path is provided for absorbing either the energy accumulated in the reactance of the load during the ON state, or energy delivered by an electronic load. This prevents damage to the load and power supply as well as providing safety for the user. However, In addition to the built-in safety features, constant-current-type active electronic loads must be adjusted to zero and the BOP front panel LCD must read 0V, minimum current, before handling the power supply-to-load connections.

**RESISTIVE.** This mode, as the name suggests, is useful for resistive loads. Table 3-6 indicates how the power supply responds to a command to go from Output ON to OFF.



Accessing the BOP after the output is disabled in BATTERY mode is hazardous because (1) high current arcing is possible and (2) either the external battery voltage, or the voltage (±Voltage Protection max) on the BOP output terminals may be dangerous. Therefore, for battery and constant-voltage-type active electronic loads it is recommended that two properly rated external switches be installed for safety: one in series with the battery, and one across the BOP output. After the unit is set to OFF, first open the switch is series with the battery, then close the switch across the BOP output to ensure safety before handling BOP connections. When connecting the battery, the switch across the output should be opened after the connections are complete and then the switch in series with the battery should be closed. If the constant-voltage-type active electronic load is adjusted to zero before handling the power supply-to-load connections, only the switch across the BOP output is required.

**BATTERY**. This mode is necessary for the power supply to function properly and safely with either battery or constant-voltage-type active electronic loads. This mode prevents the battery from discharging during the OFF state. When the output is disabled (set to OFF), the BOP will go to current mode, current will be set to zero, with voltage protect and current limit set to maximum. In this way the battery will not be discharged while the output is OFF. For constant-voltage-type active electronic loads this mode stops energy flow during the OFF state. Table 3-6 indicates how the power supply responds to a command to go from Output ON to OFF.

TABLE 3-6. POWER SUPPLY BEHAVIOR WHEN OUTPUT IS SET TO OFF

LOAD TYPE SETTING	If unit was in Voltage Mode when output OFF command issued.	If unit was in Current Mode when output OFF command issued.
ACTIVE	<ul> <li>Unit remains in voltage mode.</li> <li>Voltage set to zero.</li> <li>Both ± Current Protect set to maximum.</li> <li>Both ± Voltage Limit. remain at maximum.</li> </ul>	<ul> <li>Unit set to voltage mode.</li> <li>Voltage set to zero.</li> <li>Both ± Current Protect. remain at maximum.</li> <li>Both ± Voltage Limit set to maximum.</li> </ul>
RESISTIVE	<ul> <li>Unit remains in voltage mode.</li> <li>Voltage set to zero.</li> <li>Both ± Current Protect set to minimum box values.</li> <li>Both ± Voltage Limit. remain at maximum.</li> </ul>	<ul> <li>Unit set to voltage mode.</li> <li>Voltage set to zero.</li> <li>Both ± Current Protect set to minimum box values.</li> <li>Both ± Voltage Limit set to maximum,</li> </ul>
BATTERY	<ul> <li>Unit set to current mode.</li> <li>Current set to zero.</li> <li>Both ± Voltage Protect. remain at maximum.</li> <li>Both ± Current Limit set to maximum.</li> </ul>	<ul> <li>Unit remains in current mode,</li> <li>Current set to zero.</li> <li>Both ± Voltage Protect set to maximum.</li> <li>Both ± Current Limit remain at maximum.</li> </ul>

To configure, press form the power-up screen, then highlight Load Type and press formodify. (If a Password is required, see PAR. 3.2.4.4 for instructions.) Highlight Active, Resistive or Battery (see explanations and associated WARNINGS above) and press for power-up, for to abort, or for to apply the changes (without saving for power-up) and exit. After configuring, the new setting will be effective when the power supply goes from output on to output off.

To restore factory default (Active), press [5] from the power-up screen, highlight Load Type, press [7], then press [7] to restore default. Press [7] to save for power-up or [7] to exit

# 3.3.7 CHANGING THE DEFAULT POWER UP SETTINGS

When the BOP is shipped, the following default settings are programmed to be in effect each time the unit is turned on, however these defaults may be changed as indicated below;

- Mode: Voltage (may be voltage or current, see PARs. 3.3.2 and 3.4.2. Table 3-7 illustrates the relationship between Mode, Main Channel, Protection Type and Levels settings.
- Main Channel: Internal (may be Internal, External, or External Reference Level, PARs. 3.3.3 and 3.4.3).
- Protection type: Internal (may be Internal, External, Lesser Limit) (see PARs. 3.3.3 and 3.4.4)
- Levels, Voltage and Current: maximum (see PAR. 3.4.4) Represents the power-up values for protection limit channels (bipolar limits), voltage for current mode and current for voltage mode. Table 3-7 illustrates the relationship between Mode, Main Channel, Protection Type and Levels settings.
- Output: on (may be on or off) (see PAR. 3.3.5)

To change the default settings refer to the applicable paragraph(s) specified above as needed, then from the power-up screen press [5]. Highlight Power-up Settings and press [1]. (If a Pass-

3-20 BOP HIPWR 022108

word is required, see PAR. 3.2.4.4 for instructions.) Highlight the parameter and press to modify. Use for the ADJUST control to highlight a selection, then press for to save. To change a value use the number keys to enter new setting, then to save. When all power-up settings have been configured, press for power up or for to exit and abort the change.

To restore the factory default power-up settings listed above, from the power-up screen press [5]. Highlight Power-up Settings and press [7]. Then press [7] to restore the defaults. Then press [7] to save for power up or [7] to exit and abort the change.

These settings can be directly applied to a load upon power-up. Many other configurable settings can be saved for power up using the  $\mathbb{F}^4$  key after modifying the setting

TABLE 3-7. EXAMPLES SHOWING HOW POWER-UP SETTINGS FUNCTION

Mode	Main Channel	Protection Type	Levels	Power-up condition (output ON) (All referenced pins located on Analog I/O Port see PAR. 3.4 and Figure 2-1)
Voltage	Internal	Internal	Voltage: 10 Current: 25	Unit powers up in voltage mode, 0V, ±current protection set to 25A. Pressing MODE changes mode to current, puts unit in standby: output to 0A, ±voltage protection to power-up setting of 10V, output off and STANDBY indicator on.
Current	Internal	Internal	Voltage: 10 Current: 25  Unit powers up in current mode, 0A, ±voltage protection set to 10V.  MODE changes mode to voltage, puts unit in standby: output to 0V, protection to power-up setting of 25A, output off and STANDBY indi	
Voltage	External or ExtRefLvl	Internal	Voltage: 10 Current: 25	Unit powers up in voltage mode, output voltage determined by Analog port, pin 11 (see PAR. 3.4.3.1 for External, PAR. 3.4.3.2 for ExtRefLvI), ±current protection set to 25A. Pressing <b>MODE</b> changes mode to current, puts unit in standby, ±voltage protection to power-up setting of 10V. When output is on (STANDBY indicator off), output current determined by pin 11.
Current	External or ExtRefLvl	Internal	Voltage: 10 Current: 25	Unit powers up in current mode, output current determined by Analog port, pin 11 (see PAR. 3.4.3.1 for External, PAR. 3.4.3.2 for ExtRefLvI), ±voltage protection set to 10V. Pressing <b>MODE</b> changes mode to voltage and puts unit in standby, ±current protection to power-up setting of 25A. When output is on (STANDBY indicator off), output voltage determined by pin 11.
Voltage	Internal	External or Lesser Limit	Voltage: 10 Current: 25	Unit powers up in voltage mode, 0V, ±current protection determined by pins 5 and 13 (see PAR. 3.4.4 for External, PAR. 3.4.4.1 for Lesser Limit). Pressing <b>MODE</b> changes mode to current, puts unit in standby. When output is on, (STANDBY indicator off), ±voltage protection determined by, pins 6 and 14.
Current	Internal	External or Lesser Limit	Voltage: 10 Current: 25	Unit powers up in Current mode, 0A, ±voltage protection determined by pins 6 and 14 (see PAR. 3.4.4 for External, PAR. 3.4.4.1 for Lesser Limit). Pressing <b>MODE</b> changes mode to voltage, puts unit in standby. When output is on, (STANDBY indicator off), output voltage is 0V, ±current protection determined by, pins 5 and 13.

#### 3.3.8 STORING/RECALLING POWER SUPPLY OUTPUT SETTINGS

The power supply settings (mode, main channel reference type and setting, protection limit type and setting and output status) can be stored in one of 99 memory locations for later recall. This feature is accessible from the front panel by pressing from the power-up screen to view the Saved Settings screen (Figure 3-8). For a description of abbreviations used, refer to PAR. 3.3.8.1 To view previously saved settings refer to PAR 3.3.8.2. To save the power supply settings or modify previously saved settings refer to PAR. 3.3.8.3. To recall saved settings and apply them to the output refer to PAR. 3.3.8.5.

#### 3.3.8.1 UNDERSTANDING ABBREVIATIONS USED FOR SAVED SETTINGS

The parameters listed in Table 3-8 are displayed, followed by a listing of the first 20 memory locations, displayed in two rows of ten. Use and keys to display additional columns or navigate to the desired location.

Locations that are not empty show an abbreviated representation of the saved settings. (To see **all** the pertinent settings for a particular location, highlight the location, then press [1]; press to exit without modifying the settings.)


If either Voltage or Current mode were saved, the main channel setting is listed under the Main heading followed by **V** (voltage) or **A** (current), followed by either **f** (Output OFF), **n** (Output ON). If the reference type is ExtRefLvI (instead of Internal or External), the uppercase **V** or **A** is replaced by lowercase **v** or **a**. The protection setting is listed under the Prot heading.

If External mode was saved, the protection setting is followed by **C**, indicating that the mode (voltage or current is **C**onditioned by the external signal applied to pin 2 of the Analog I/O Port (see Table 2-10).

If the protection setting is followed by a minus sign (–) it indicates that the negative protection value (displayed) is set larger (absolute value) than the positive protection value (not shown on the list). Similarly, if the protection setting is followed by a plus sign (+) it indicates that the positive protection value (displayed) is set larger than the negative protection value (not shown on the list).

If Main channel reference was saved as External, **EXT** is listed under the Main heading. In this case the main channel reference uses the external voltage applied to pin 11 of the Analog I/O Input Port (see Table 2-10).

If Protection type was saved as External, **EXT** is listed under the Prot heading. In this case the protection settings are determined by the levels applied to the appropriate pins of the Analog I/O Input Port (see Table 2-10). If the main channel is voltage, the protection settings are determined by pin 5 (negative current protection) and pin 13 (positive current protection). If the main channel is current, the protection settings are determined by pin 6 (negative voltage protection) and pin 14 (positive voltage protection).



3042519-12

FIGURE 3-8. SAVED SETUPS MENU

3-22 BOP HIPWR 022108

# 3.3.8.2 VIEWING SAVED SETTINGS

- 1. Pressing from the power-up screen displays the Saved Setups screen (Figure 3-8) consisting of a list of locations 1 through 20 arranged in two columns of 10 rows. Use and keys to display additional columns. NOTE: Use the number keys as a shortcut, e.g., pressing 4 immediately highlights location 41, showing the column with locations 41 through 50.
- 2. Use the and keys to highlight the desired memory location; When the desired location is highlighted, press . The details of the parameters listed in Table 3-8 are displayed.

#### 3.3.8.3 SAVING SETTINGS AND ERASING OR MODIFYING PREVIOUSLY SAVED SETTINGS

- 1. Press [1] from the power-up screen to enter the Saved Setups screen (Figure 3-8).
- 2. Use the and keys to highlight the desired memory location; To erase a highlighted memory location, press 3. The list will show erased locations as **Empty**.
- 3. Press [1] to see the details stored in the highlighted location.
- 4. Once the details are displayed, use the 🖭 and 🏠 keys to highlight the desired parameter.

TABLE 3-8. SAVE/RECALL MENU

PARAMETER	CHOICES (BOLD = Factory Default)	FUNCTION
NOTE: DEFAULT	values for empty cells are th	e settings of the unit at the time the save/recall menu is entered.
MODE	VOLT CURRENT EXTERNAL	VOLT - Selects voltage mode. Voltage value determined by SETTING. CURRENT - Selects current mode. Current value determined by SETTING. EXTERNAL - Used for customized configuration where EXT VM/CM signal at pin 2 of I/O port controls mode; consult factory for details.
MAIN CHANNEL REFERENCE	INTERNAL EXTERNAL EXTL REF LVL	INTERNAL: Any external reference applied to the Analog I/O port pin 11 is ignored and the internal reference established by SETTING field.  EXTERNAL: The internal reference is ignored, and the external reference applied to the Analog I/O port pin 11 is used (see PAR. 3.4.3.1).  EXTL REF LVL: Allows the gain of the BOP to be established by the maximum output voltage or current introduced by the SETTING field. (see PAR. 3.4.3.2).
SETTING	nn.nnn or nnn.nnn (model and parameter dependent)	Sets the active channel setting. E.g., if VOLT mode is selected, nnn.nnn is voltage setting, if CURRENT mode is selected, nn.nnn is current setting. If EXTERNAL mode is selected, SETTING is not available.
PROTECTION MODE	INTERNAL EXTERNAL LESSER LIMIT	INTERNAL - Allows limits to be controlled by POSITIVE and NEGATIVE values. EXTERNAL: Allows limits to be controlled by analog signals applied to the analog port (see PAR. 3.4.4).  LESSER LIMIT: Allows protect limit to be automatically selected from either 1) the external analog voltage applied to the Analog I/O port or 2) the value set in the POSITIVE and NEGATIVE fields. Whichever limit has a lower absolute value (closest to zero) has effect (see PAR. 3.4.4).
POSITIVE	nn.nnn or nnn.nnn	This is the positive value for Voltage protect if CURRENT mode is selected, or the positive value for Current protect if VOLTAGE mode is selected. If EXTERNAL mode is selected, this field is not accessible.
NEGATIVE	nn.nnn or nnn.nnn	This is the negative value for Voltage protect if CURRENT mode is selected, or the negative value for Current protect if VOLTAGE mode is selected. If EXTERNAL mode is selected, this field is not accessible.
OUTPUT	OFF ON	OFF - Output disabled. The behavior of the unit when output is disabled depends on the LOAD TYPE setting (see PAR.3.3.6). ON - Output enabled.

NOTE: If a value to be saved is beyond the range of the unit, the value saved will be limited to the maximum value. If the Mode is changed, the numerical values for the main and protection channels must be revised accordingly.

- To modify the parameter, press [1]. Highlight the desired choice from a list, or use the keypad to enter a numeric value, then press [14] to save, or [15] to abort.
- To exit without changing the parameter, press [5].
- 5. Continue to modify parameters as described in step 4 above. When all parameters have been modified, press to save for power-up. Press to exit without storing the changes.

NOTE: If the message CHANGES NOT ALLOWED is displayed, the memory location has been remotely locked (see PAR. A.12 for details).

6. After the changes have been saved, the unit returns to the Saved Settings screen, where the saved settings can now be applied to the output by pressing [2].

#### 3.3.8.4 COPYING PREVIOUSLY SAVED SETTINGS TO A NEW LOCATION

- 1. Press [1] from the power-up screen to enter the Saved Setups screen (Figure 3-8).
- 2. Use the and keys to highlight the location to be copied, then press 4.
- 3. Highlight an **Empty** location and press [4] to save to the highlighted location, or press [5] to abort the copy.

# 3.3.8.5 APPLYING SAVED SETTINGS TO THE OUTPUT (RECALL)

- 1. Press [1] from the power-up screen to enter the Save/Recall menu.
- 2. Use the And Akeys to highlight the desired memory location. When the desired location is highlighted, press to view the detailed settings before execution, or press 2 to apply the settings to the output. Refer to PAR. 3.3.8.3 to modify a setting before execution.

# 3.3.9 WAVEFORM GENERATION

# 3.3.9.1 PROTECTING THE LOAD WHEN ACCESSING WAVEFORMS

CAUTION: BEFORE PRESSING TO ENTER THE SAVED WAVEFORM SCREEN FROM THE POWER-UP SCREEN, PERFORM THE FOLLOWING STEPS TO AVOID UNEXPECTED VOLTAGES OR CURRENTS FROM PREVIOUS SETTINGS BEING BRIEFLY APPLIED TO THE LOAD WHEN THE WAVEFORM IS FIRST EXECUTED.

- 1. Use the MODE key to set the operating mode of the unit (voltage or current) to correspond with the mode of the waveform.
- 2. Set the main channel to zero, and the protection channel to maximum. This ensures that the waveform will start from zero. Otherwise, between pressing STANDBY to turn the output on, and pressing to execute the waveform, the previously programmed settings of the power supply will be applied to the load until the waveform starts executing.


3-24 BOP HIPWR 022108

#### 3.3.9.2 WAVEFORM OVERVIEW

After observing the precautions of PAR. 3.3.9.1, the Saved Waveforms screen (Figure 3-9) is entered by pressing from the power-up screen (Figure 3-3). Waveforms that have been previously saved will be displayed with the previously assigned names; waveforms that have been erased will appear as Empty. Up to 16 separate local waveforms can be programmed and stored from the front panel.

Each waveform has an identifying name, the operating mode (voltage or current), positive and negative protection values, and the count (the number of times the complete waveform is to be repeated). Setting the count to zero allows the waveform to repeat continuously.

A waveform is comprised of at least one, or as many as 10 segments. Each segment has an individually specified value for Type, Frequency or Period, Amplitude, Offset, Start angle, Stop angle, and Initial/Repeat; see Table 3-11 for details. Refer to PAR. 3.3.9.5 to view a previously saved waveform, PAR. 3.3.9.6 to execute a previously saved waveform, PAR. 3.3.9.7 to modify a previously saved waveform, PAR. 3.3.9.8 to create a new waveform and PAR. 3.3.9.9 for an example with detailed instructions on how to create a complex waveform.



3042519-8

FIGURE 3-9. SAVED WAVEFORMS MENU

#### 3.3.9.3 UNDERSTANDING HOW WAVEFORMS ARE GENERATED

Waveform are generated by the BOP by producing a series of discrete output levels (points) in a prescribed pattern. In the case of sine, triangle and ramps, this produces an output that conforms to an approximation of the selected waveform type. The number of points available for a waveform is limited to 3933 for all segments. Since there are a finite number of points, the lower the frequency, the more points used, and the smoother the output waveform will appear. As the frequency increases, fewer points are available for each cycle and the resulting waveform may appear somewhat more jagged. Tables 3-9 and 3-10 list the number of points used for each frequency range of sine, triangle and ramp waveforms and for square waveforms, respectively. Levels use a maximum of 60 points.

This means that a waveform consisting of a single sinewave segment at 0.1 Hz will use all 3840 points to generate each cycle, while a sinewave at 440 Hz will use 24 points for each cycle.

Note that a single segment between 0.01Hz and 1.8Hz uses all available points, so subsequent segments will not be accepted. Four segments of 2.81Hz will be acceptable, while five segments at 2.81 Hz will not be accepted. Reducing the segment by using the start and stop angle will also reduce the number of points used.

Each time a segment is added, the waveform is validated. When a segment is added that causes the point total to exceed 3933, three asterisks \*\*\* will appear to the left of the segment, and the error message "LIST TOO SMALL" will be displayed briefly. This can be corrected by either reducing the number of segments, or increasing the frequency of the existing segments until the point total is acceptable.

# 3.3.9.4 WAVEFORM SPECIFICATIONS

Refer to Table 1-2 for specifications applicable to waveforms created either locally, using the BOP front panel (Local) or remotely from a host computer, using LIST commands (Remote). Differences between local and remote operation are highlighted.

TABLE 3-9. SINE, TRIANGLE AND RAMP WAVEFORM FREQUENCY VS. POINTS

Freq (See Notes	Total Points			
From	То			
0.01Hz	2.7Hz	3840		
2.71Hz	3.6Hz	2880		
3.71Hz	5.5Hz	1920		
5.6Hz	8.3Hz	1280		
8.4Hz	11.0Hz	960		
11.1Hz	14.7Hz	720		
14.8Hz	22.1Hz	480		
22.2Hz	33.2Hz	320		
33.3Hz	44.3Hz	240		
44 4Hz	55.4Hz	102		

Frequ (See Notes	•	Total Points
From	То	
55.5Hz	66.5Hz	160
66.6Hz	88.7Hz	120
88.8Hz	118.3Hz	90
118.4Hz	147.9Hz	72
148Hz	177.4Hz	60
177.5Hz	221.8Hz	48
221.9Hz	295.8Hz	36
295.81Hz	354.9Hz	30
355.9Hz	443.7Hz	24 (See Note 2)
443.8z	532Hz	20 (See Note 3)

NOTES: 1. As the frequency varies within the range, the time interval per point varies proportionately.

TABLE 3-10. SQUARE WAVEFORM FREQUENCY VS. POINTS

Frequ (See N	Total Points	
From	From To	
0.02Hz	1.8Hz	3840
1.81Hz	2.7Hz	2880
2.71Hz	4.0Hz	1920
4.01	5.4Hz	1280
5.41	7.2Hz	960
7.21Hz	10.8Hz	720
10.81	16.3Hz	480

Frequ (See No	•	Total Points
From	То	
43.51Hz	58.0Hz	120
58.01Hz	72.5Hz	90
72.51Hz	87.0Hz	72
87.01Hz	108.7Hz	60
108.71Hz	145.0Hz	48
145.2.9Hz	174.0Hz	36
174.1Hz	217.5Hz	30

3-26 BOP HIPWR 022108

<sup>2.</sup> Sine and Triangle segments can not exceed 443Hz.

<sup>3.</sup> Ramp segments can not exceed 532Hz.

TABLE 3-10. SQUARE WAVEFORM FREQUENCY VS. POINTS

			_	
Frequency (See Note 1)		Total Points		(S
From	То			Fron
16.31Hz	21.7Hz	320		217.6
21.71Hz	27.1Hz	240		261.11
27.11Hz	32.6Hz	192		435H
55.5Hz	66.5Hz	160		653


Frequ (See No	•	Total Points		
From	То			
217.6Hz	261.0Hz	24		
261.1Hz	435.0Hz	20		
435Hz	652.5Hz	12		
653	1000	10		

NOTE: 1. As the frequency varies within the range, the time interval per point varies proportionately.

#### 3.3.9.5 VIEWING STORED WAVEFORMS

After observing the precautions of PAR. 3.3.9.1, press [2] from the power-up screen to access the Saved Waveforms screen (Figure 3-9). Use [1] or [2] or the encoder to highlight the name of a previously saved waveform, then press [1] to view the Waveform Settings screen (see Figure 3-10). The lower half of the LCD shows a representation of the programmed waveform. The letters along the vertical axis of the graph at the lower left side indicate whether the waveform is programmed to operate in voltage or current mode. The message at the upper right indicates the actual mode of the power supply while the waveform is being executed. The upper half presents the waveform name, positive and negative protection settings, the repetition count, followed by a listing of segments. The type (square, sine, etc.), frequency, p-p amplitude, and whether the segment is initial (run only the first time) or repeating is indicated by I or R, respectively. To see the offset, start/stop angle, initial/repeat for a segment, use [2] or [3] or the encoder to highlight the segment, then press [4] (Initial/Repeat is not available for the last segment, since the last segment must repeat). Use use [4] or [4] to highlight the parameter, press [5], then set the value or highlight the desired setting and press [6] to save for power-up or [6] to abort and exit without changing the parameter.

NOTE: VOLTAGES SHOWN ARE FOR BOP 100-10MG



3042519-6

FIGURE 3-10. WAVEFORM SETTINGS MENU

#### 3.3.9.6 EXECUTING A WAVEFORM

After observing the precautions of PAR. 3.3.9.1, press [2] from the power-up screen to enter the Saved Waveforms screen (Figure 3-9). Highlight one of the stored waveforms, then press [4] to execute the waveform.

To stop execution, press [F5]. This stops waveform execution and puts the unit into standby (STANDBY indicator on).

While the waveform is executing, the display shows a graphic of the programmed waveform (repeating segments only) below the message **Waveform Executing**.



Be sure that output power is OFF (Standby indicator lit) while connecting monitoring device. Be sure that connections are secure and that terminals are not inadvertently shorted.

It is recommended that an oscilloscope be used to view the actual output. Connect the oscilloscope across OUT S and COM S terminals of the rear panel terminal block to monitor the output at the load, or between OUT MON and COM MON to monitor the BOP output at the BOP (see Figure 2-1).

# 3.3.9.7 MODIFYING PREVIOUSLY STORED WAVEFORMS

To edit a previously stored waveform, first observe the precautions of PAR. 3.3.9.1, then view the waveform and highlight the segment to edit as specified in PAR. 3.3.9.5. (The operating mode can not be edited; to change from a voltage waveform to a current waveform, refer to PAR. 3.3.9.8 to start a new waveform.)

When editing a segment, a submenu showing the parameters for that segment will open (see Table 3-11). Use or the encoder to highlight the parameter, then press to edit, change the parameter, then press to save or save or to abort. Then press to save for power or to abort and exit without saving the segment parameters that were edited.

TABLE 3-11. WAVEFORM SEGMENT DETAILS MENU

SETTING	CHOICES	FUNCTION
Туре	Square Pos Ramp Neg Ram Triangle Sine Level	Square - Square wave, bipolar, starts with positive excursion (see Note 1).  Pos Ramp - Increasing ramp, bipolar (see Note 1).  Neg Ramp - Decreasing ramp, bipolar (see Note 1).  Triangle - bipolar, starts with positive excursion, start/stop angle may be user controlled (see Note 1).  Sine bipolar, starts with positive excursion, start/stop angle may be user controlled (see Note 1).  Level - value determined by offset., duration determined by Period.
Frequency (Hz) or Period (Sec) for Level only	xxxx.xxx (Hz) or xx.xxxx (Seconds) (see Note 3)	Square wave: 0.02 to 1000 Hz Ramp: 0.02 to 532 Hz Sine or Triangle:0.01 to 443 Hz Level: Period in seconds. 0.005 to 1.9999 seconds
Amplitude (P to P)	xxx.xxx (Volts or Amperes)	Peak to peak amplitude of segment. Volts or Amperes determined by mode selected for waveform. Value within model rating acceptable (e.g., for BOP 100-10MG, maximum amplitude is 200V). Values that exceed the maximum or minimum software limits (see PAR. 3.3.4.2) are neither acepted nor executed.

3-28 BOP HIPWR 022108

#### **TABLE 3-11. WAVEFORM SEGMENT DETAILS MENU**

SETTING	CHOICES	FUNCTION
Offset	xxx.xxx (Volts or Amperes)	DC level on which the waveform (centered) will ride or Amplitude for Level segments. Volts or Amperes determined by mode selected for waveform. E.g. for BOP 100-10MG, to specify a positive ramp that goes from +30V to +80V, set amplitude to +50V and offset to +55V. Since p-p amplitude of segment is centered on offset, it is possible for the waveform to exceed the model ratings (e.g., for the BHK 100-10MG, if the amplitude is set to 150V and the offset is -50V, the negative portion of the segment will exceed the -100V maximum of the model). In this case the output is clamped to the max/min software limit in effect (see PAR. 3.3.4.1). Values that exceed the maximum or minimum software limits (see PAR. 3.3.4.2) are neither acepted nor executed.
Start Angle (Sine or Triangle only)	xxx x (degrees)	The point at which the sine or triangle waveform segment starts. Values from $0.0^\circ$ to $360.0^\circ$ are acceptable. Default is $0.0^\circ$ .
Stop Angle (Sine or Triangle only)	xxx x (degrees)	The point at which the sine or triangle waveform segment stops. Values from 0.0° to 360.0° acceptable. Default is 0.0° (functions the same as 360°)
Initial/ Repeat	Repeating Initial	Repeating - Segment is executed for each cycle specified by the Count (see Note 2). Initial - Segment is executed only on the first count and skipped for all subsequent counts. Useful for preconditioning applications (see Note 2).  All segments except the last may be set to Initial or Repeating. The last segment is always Repeating

#### **NOTES**

- 1. All waveforms except Level are centered on the offset. E.g. for a BOP 100-10MG, a positive ramp of 100V p-p amplitude, 10V offset, will start at -40V and increase to +60V over the time period (T) determined by the frequency (F): T = 1/F.
- 2. When starting a new waveform, the first segment is always a repeating segment. One or more initial segments can be inserted before the first repeating segment. Segments inserted before an initial segment are automatically set to initial; segments inserted after a repeating segment are automatically set to repeating. It is recommended that the repeating segments be created first. E.g. For a waveform with five segments, 1 and 2 designated Initial and 3, 4, and 5 designated Repeating, If the count was set to 10, the first waveform would be comprised of segments 1 through 5, but the next nine waveforms would only have segments 3, 4, and 5. This feature can be useful for establishing an initial delay or preconditioning the load prior to running the repeating waveform.
- 3. If the internal memory space used to process a waveform segment is exceeded, \*\*\* is displayed to the left of the segment(s) in error. This can be corrected by 1) increasing the frequency (the lower the frequency, the more memory is used), 2) reducing the number of segments.

To delete a segment, highlight the segment at the Waveform Settings screen (Figure 3-10), the press  $\mathbb{R}^3$ , to permanently erase the segment. This change is saved immediately and can not be undone.

To add a segment, at the Waveform Settings screen (Figure 3-10) highlight the segment following the one to be added (e.g., if there are three existing segments (1, 2, 3), to add a segment between 2 and 3, highlight 3. To add a segment following 3, highlight **End of Segments**. After highlighting the segment, press [2] to insert a new segment. The parameters applicable to the waveform type selected (see Table 3-11 for details) can then be modified as desired.

# 3.3.9.8 CREATING A NEW WAVEFORM

1. After observing the precautions of PAR. 3.3.9.1, press [72] from the power-up screen to enter the Saved Waveforms screen (Figure 3-9), highlight one of the waveforms designated **Empty**, then press [72]. The Waveform Settings screen (Figure 3-10) opens.

2. Assign a name to the waveform: highlight Name, press 1 to modify, change the name using the 1 or 1 keys or **ADJUST** or the multiple presses of the numeric keys (see PAR. 3.2.4.2 for details). Press 1 to save or 1 to abort.the change and exit.

**TABLE 3-12. NEW WAVEFORM SETTINGS MENU** 

SETTING	CHOICES	FUNCTION
Name	Alphanumeric characters (10 characters max.) (Name Assigned by User)	Waveforms are assigned a number from 1 to 16. When a new waveform is programmed, a name must be assigned so it can be easily recognized and recalled. Up to 16 waveforms can be stored from the front panel.
Mode	VOLTAGE CURRENT	Determines the active mode for the waveform. This setting cannot be changed once it has been saved. To change the mode, create a new waveform and delete the existing waveform.
Protection Positive Negative		Assigns the positive and negative protect levels to be in effect while the waveform is running. These levels apply to the complementary channel. (e.g., if the Mode selected is voltage, the complementary channel is the current channel.
Count	0-999	Determines how many times the waveform is to be repeated, except for segments marked Initial, which are only executed once To repeat the waveform indefinitely, set the count to 0

- 3. Refer to Table 3-12 and enter the desired settings for Mode, Positive and Negative Protection and Count. These settings apply to all waveform segments. (Note that the setting for mode cannot be changed once it has been saved; to change the mode, create a new waveform.) For each parameter listed in Table 3-12 use or or or ADJUST to highlight the parameter, then press to edit, change the parameter, then press to save or save or save or to abort and exit.
- 4. Refer to Table 3-11 and enter the parameters for the first segment: Type, Frequency, Amplitude (p-p) and Offset. For each parameter use or or or the encoder to highlight the parameter, then press to edit, change the parameter, then press to save or sa
- 5. When segment is complete, press fall to save for power up. Continue to add segments as desired.

NOTE: When the first segment is added, start/stop angle is not accessible, however this can be modifed once the segment has been added.

6. When adding a new segment, the parameters of the highlighted segment are copied. It is not possible to move or copy a segment to another location. Refer to Table 3-11, Note 2 for details about initial vs. repeating segments. Refer to PAR. 3.3.9.9 for a detailed example of how to add segments to build a complex waveform.

#### 3.3.9.9 USING SEGMENTS TO BUILD A WAVEFORM

The following steps provide detailed instructions to illustrate how a complex waveform, illustrated in Figure 3-11, may be created by building segments. Refer to PAR. 3.2.4 for details on changing parameters if needed.

3-30 BOP HIPWR 022108




FIGURE 3-11. SAMPLE WAVEFORM

- 1. After observing the precautions of PAR. 3.3.9.1, press [72] from the power-up screen to enter the Saved Waveforms screen (Figure 3-9), highlight a waveform designated **Empty** and press [72] to create a new waveform.
- 2. The initial waveform settings are displayed (see Table 3-11 and Table 3-12 for parameter details. Use to modify the initial settings for the waveform. For each parameter, use to save the setting.

Name	CAP CHARG
Mode	VOLTAGE
Protection	
Positive	10
Negative	10
Count	0
Segment	
Туре	Neg Ramp
Frequency (Hz)	50
Amplitude (p-p)	4
Offset	8

When all settings are complete, press [4] to save for power-up. This step creates a repeating negative ramp starting at +10V decreasing to +6V since it is a 4V p-p signal riding on an 8V offset. The frequency of 50 Hz establishes the time duration of 20 ms for the segment.

3. From the Waveform Settings screen, highlight segment NEG RAMP 50.0HZ 4.00 R and press to insert a new segment. Use to modify the following settings of the new segment. For each parameter, use to save the setting.

Type Level
Period (sec) 0.002
Offset 0
Initial/Repeat Initial

When complete, press  $\P$  to save for power-up. This step changes the 2ms, 0V level to be executed only once at the beginning of the waveform.

4. From the Waveform Settings screen, highlight segment LEVEL 0.002s 0.00 I and press to insert a new segment. Use to modify the following settings of the new segment. For each parameter, use to save the setting.

Type Level Period (sec) 0.001 Offset 1.5

When all settings are complete, press to save for power-up. This step creates a 1.5V level of 1ms prior to the 0V level. This segment is automatically set to Initial since the previous segment is set to Initial. The first two segments form a positive 2ms, pulse, delayed 1ms from the start of execution. The pulse can be used for synchronizing an external monitoring device.

5. From the Waveform Settings screen, highlight segment NEG RANP 50.0HZ 4.00 R and press to insert a new segment. Use to modify the following settings for the next segment. For each parameter, use to save the setting.

Type Sine
Frequency (Hz) 25
P to P Amplitude 20
Offset 0
Start angle 90.0
Stop angle 90.0
Initial/Repeat Initial

When all settings are complete, press [4] to save for power-up. This step creates another initial segment which is the first quadrant of a 20V p-p sine wave riding on a 0V offset. It starts at 0V and rises to 10V (1/2 of 20) over 10 ms (1/4 of 40ms period established by 25Hz frequency). This segment simulates the initial charging of a capacitor.

6. From the Waveform Settings screen, highlight End of Segments and press [2] to insert the next segment. Use [1] to modify the following settings for the next segment. For each parameter, use [4] to save the setting

Type Sine
Frequency (Hz) 50
Amplitude (p-p) 8
Offset 6
Start angle 0.0
Stop angle 90.0

When all settings are complete, press [4] to save for power-up. This step create a repeating 1/4 sine wave that starts at 6V and rises to 10V over 5 ms (1/4 of 20ms period established by 50Hz frequency). The waveform shown in Figure 3-11 has now been saved. Note that by careful calculation of period and start/stop angle, accurate waveform simulations can be attained.

7. Either execute the completed waveform by pressing **STANDBY** (to turn the output on), then [f4], or press [f5] to return to the Saved Waveforms screen.

3-32 BOP HIPWR 022108

#### 3.3.9.10 COPYING A WAVEFORM

After observing the precautions of PAR. 3.3.9.1, press figure from the power-up screen to enter the Saved Waveforms screen (Figure 3-9). Highlight one of the stored waveforms, then press figure 3.4. Then highlight a waveform location designated **Empty** and press figure 1 to save or figure 3.5. The copied waveform may then be modified and saved with a new name if desired (see PAR. 3.3.9.7).

#### 3.3.10 RESET

CAUTION: PRESSING RESET WILL CAUSE VOLTAGE TRANSIENTS TO APPEAR AT THE OUTPUT WHICH MAY DAMAGE A CONNECTED LOAD. SWITCH IS RECESSED TO PREVENT INADVERTENT ACTIVATION.

Pressing **RESET** causes the power supply to execute a complete power on sequence to reset the power supply to the power up settings (see PAR. 3.3.7).

# 3.3.11 OPERATOR TESTING

The Test System submenu is entered by pressing f5 from the power-up screen, then highlight Revison/Test and press f1. Upon power-up all tests are flagged as **Untested**. Table 3-14 lists the tests that can be run. Highlight the choice and press f3 to run the selected test.

# 3.3.12 ERROR MESSAGE EXPLANATIONS

When a key press is not accepted, an error message is displayed at the bottom of the screen. Although recovery from most operator errors is obvious and simple, Table 3-13 lists all the error messages along with associated explanations as to why they occurred.

**TABLE 3-13. ERROR MESSAGE EXPLANATIONS** 

ERROR MESSAGE	EXPLANATION		
General			
Multiple Decimal places not supported	Decimal key was pressed while to the right of the existing decimal point.		
Exceeding Maximum Allowed Value	To check maximums, go to power-up screen, press [F5], highlight Max/Min Settings, press [F1].		
Sign does not affect Protection Limits	Protection Limit field is positive or negative, numerical value does not need sign		
Entry incomplete, Depress ENTER key	When changing either the main channel or the protect channel, using the number keys, the change must be applied to the output by pressing <b>ENTER</b> before moving on to change the other channel.		
Executing List	A waveform is currently executing via remote mode. Commands to change the output are not accepted until list is stopped (send command VOLT:MODE FIXED).		
Save Disabled, Request ignored	Save Display Change is disabled. From power-up screen, press [75], highlight password settings to enable.		
EXTERNAL MODE enabled.	<b>MODE</b> key does not function while Mode is being controlled externally. Press [F4], highlight External Mode and change to Disable.		
F2 Key not valid	F2 only works when labeled. key was probably pressed inadvertently.		
Password incorrect	Enter the correct password and press [F1]. If password has been lost and can not be recovered, refer to PAR. 3.6.3.12.1 to reset to factory defaults.		
Setup Menu			
F3 - Invalid	only works when labeled. Key was probably press inadvertently.		
F4 - Invalid			
Master/Slave Menu			

TABLE 3-13. ERROR MESSAGE EXPLANATIONS (CONTINUED)

ERROR MESSAGE	EXPLANATION		
Series or Parallel when not STANDALONE	Mismatch between Unit type and Connection type. Automatically reverts to Unit type: Standalone, Connection Type: standalone.		
Calibration invalid - Multiple Unit	Consult Factory.		
BITBUS option must be Disabled	Change CIIL mode to SCPI. From power-up screen press highlight Interface Data Format, press highlight SCPI, press highlight SCPI, press highlight to save for power-up, then cycle BOP off, then on.		
	Waveform Menu		
External Reference Waveform not accessible	Reference Input must be set to Internal for waveforms to be executed. Press Highlight Reference Input, press Highlight Internal, press Highlight Internal, press Highlight Internal for waveforms to be executed. Press Highlight Reference Input must be set to Internal for waveforms to be executed. Press Highlight Reference Input must be set to Internal for waveforms to be executed. Press Highlight Reference Input must be set to Internal for waveforms to be executed. Press Highlight Reference Input must be set to Internal for waveforms to be executed. Press Highlight Reference Input must be set to Internal for waveforms to be executed. Press Highlight Reference Input must be set to Internal for waveforms to be executed. Press Highlight Reference Input must be set to Internal for waveforms to be executed. Press Highlight Internal for waveforms to be executed.		
External Mode - Waveform not accessible	External Mode must be disabled for waveforms to be executed. Press $f_{1}^{4}$ highlight External Mode, press $f_{1}^{4}$ highlight Disable, press $f_{2}^{4}$ , then $f_{3}^{4}$ .		
External Limits - Waveform not accessible	Protection Limit must be set to Internal for waveforms to be executed. Press $^{f4}$ highlight Protection Limit, press $^{f1}$ highlight Internal, press $^{f4}$ , then $^{f5}$ .		
Empty Entry - use F2 instead	Empty location cannot be modified using $\P$ 1 Press $\P$ 2 to start new waveform.		
No Room to insert - delete a segment.	No more than 10 segments are allowed in a waveform.		
Unable to delete segment.	Try again. If still unable to delete segment, contact factory. for RMA.		
Only EDIT allowed on Entry.	When viewing waveform, if name, count or protection levels are highlighted, press modify the setting. And are not functional with these parameters.		
MODE incorrect - Please Change	A voltage waveform was executed while the unit was in current mode or a current waveform was executed while the unit was in voltage mode. Press <b>MODE</b> key to change correct mode, press STANDBY key to set output on then press $\mathbb{F}_{m}^{4}$ to run the waveform		
Unit in STANDBY - Please Change	Output must be on for the waveform to be executed. press <b>STANDBY</b> key to set output on then press $rac{\mathbb{F}^4}{\mathbb{F}^4}$ to run the waveform		
Can not delete Single Segment - use F1 to Change	Waveform must have at least one segment.		
Can not delete the empty segment.	"End of Segments" was highlighted when 3 - Erase was pressed. Move highlight to vali segment and try again.		
Entry not Empty, Use F1 to change.	. Pressed while a previously saved waveform was highlighted. Use to modify or highlight Empty and press for a new waveform.		
Under Minimum allowed value	Frequency or period was too small.		
Frequency has no sign	+/- key is not functional when modifying frequency.		
Use F5 to stop waveform.	not valid when waveform already executing.		

# 3.4 ANALOG REMOTE MODE PROGRAMMING

The BOP can be programmed remotely using analog signals applied to the remote Analog I/O port at the rear panel (see Figure 2-1 and Table 2-10). Analog remote programming allows the user to 1) establish voltage or current mode (PAR. 3.4.2), 2) control the main channel using the BOP as a power amplifier (PAR. 3.4.3) and 3) establish the protection limits (PAR. 3.4.4). An output signal proportional to output current is also provided for external use (PAR. 3.4.5).

# 3.4.1 REMOTE OUTPUT OFF

There are two ways two turn off the output using remote signals: (1) Remote Shutdown which requires the unit to be turned off, then on in order to restore operation and (2) Remote Standby which sets the output to OFF, putting the unit in STANDBY status.

3-34 BOP HIPWR 022108

# 3.4.1.1 REMOTE SHUTDOWN

A standalone unit can be shut down using a remote signal applied to the PROTECTION EXT. PORT as shown in Figure 3-12 or 3-13. A multiple unit configuration (parallel, series or seriesparallel) can be disabled by applying a remote signal to the master PAR/SER PROTECTION PORT as shown in Figure 3-12 or 3-14. When the signal is momentarily active (minimum 100 microseconds), power transfer between input and output is stopped (both input and output internal modules are shut off). This condition is latched and requires the unit to be turned off, then on again to restore normal operation.




FIGURE 3-12. REMOTE SHUTDOWN USING EXTERNAL POWER, STANDALONE OR MULTIPLE UNITS




FIGURE 3-13. REMOTE SHUTDOWN USING INTERNAL POWER, STANDALONE UNITS




FIGURE 3-14. REMOTE SHUTDOWN USING INTERNAL POWER, MULTIPLE UNITS,

#### 3.4.1.2 REMOTE STANDBY

3042930

A standalone unit or a multiple unit configuration (parallel, series or series-parallel) can be set to STANDBY status by applying a remote signal to the TRIGGER PORT as shown in Figure 3-15. For multiple unit configurations this signal must be applied to the master. When the signal is momentarily active (short or logic 0 for a minimum of 100 microseconds), the output is set to OFF after a maximum delay of 200 milliseconds and the STANDBY indicator goes on. Depressing the STANDBY key or sending the OUTP ON command via the remote interface restores the unit to the previous state and the STANDBY indicator goes off.




FIGURE 3-15. REMOTE STANDBY, STANDALONE OR MULTIPLE UNITS

# 3.4.2 VOLTAGE/CURRENT MODE CONTROL

The mode of operation, voltage or current, can be programmed externally by applying a signal at pin 2, referenced to pin 9, of the Analog I/O port. Applying a TTL logic 1 (or open circuit) programs the unit to voltage mode. Applying a TTL logic 0 (or short) programs the unit to current mode.

To be functional this feature must first be configured from the front panel. From the power-up screen press [4] to enter the Analog Remote Setup menu (see Table 3-15). Highlight External Mode, then press [5], highlight Enable and press [6]. Press [6] to apply the changes (without saving for power-up) and exit to the power-up screen or [6] to abort. The Save/Recall feature (PAR. 3.3.8) can also be used to restore this setting upon power-up.

# 3.4.3 CONTROLLING THE OUTPUT USING THE BOP AS A POWER AMPLIFIER

The BOP can function as a power amplifier by means of the External Reference input at the Analog I/O port. This analog signal controls the main channel of the BOP. To use the BOP as a power amplifier see the following instructions for using the external reference: PAR. 3.4.3.1 for fixed gain, PAR. 3.4.3.2 for variable gain by establishing the maximum full scale output.

3-36 BOP HIPWR 022108

# **TABLE 3-14. REVISIONS/TEST MENU**

SE	TTING	CHOICES (BOLD = Factory Default)	FUNCTION	
\	M OUTPUT VOLTAGE XX CURRENT YY	(Cannot be highlighted) XX.0 YY.0	Displays rated output voltage and current of power supply. including all slaves connected in parallel or series.	
TEST	DISPLAY	Status (see NOTE below)	Automatic test, reports status messages (see NOTE below).	
	KEYPAD	Status (see NOTE below)	Requires depressing keys indicated on LCD.  This test requires pressing every key on the keypad, plus moving the ADJUST control clockwise and counterclockwise, with the ADJUST control depressed and released. As the keys and control function pass the tests, the corresponding function on the LCD is highlighted. When the last test is successful, the LCD displays "passed." The test must be completed within two minutes, otherwise a "Failed" indication is displayed.	
	INTER- FACE	Status (see NOTE below)	Automatic test, reports status messages (see NOTE below).	
	SERIAL	Status (see NOTE below)	Automatic test of serial port - requires installation of loop back test connector. (see PAR. 3.5.6.4). Reports status messages (see NOTE below).	
	ANALOG	Status (see NOTE below)	Automatic test which does not affect unit output. Reports status messages (see NOTE below).	
OUTPUT Status (see NOTE below)		Status (see NOTE below)	<b>CAUTION: DISCONNECT LOAD BEFORE RUNNING THIS TEST.</b> Output is automatically programmed to +E <sub>Onom</sub> for ~800 msec, then –E <sub>Onom</sub> for ~800 msec, then to 0V. Reports status messages (see NOTE below).	
REVISIONS  DISPLAY INTERFACE ANALOG  (Cannot be highlighted) X.XX Y.YY 2.2Z		x.xx y.yy	Displays current firmware revision for display, interface and analog processors.	
UNTE TEST PASS	NOTE: Test status is as follows:  UNTESTED Initial status when first entering menu.  TESTING Test is running.  PASSED Test was successful.  FAILED Test failed.			

FAIL EXT SERIAL test failed - verify loop back connector installed (see PAR. 3.5.6.4).

# 3.4.3.1 FIXED GAIN USING EXTERNAL REFERENCE CONTROL

The main channel of the BOP, voltage in voltage mode, and current in current mode, can be controlled by an external reference voltage, 0 to  $\pm 10V$  applied at pin 11, referenced to pin 4, of the Analog I/O port. The input impedance for this signal is 20K ohms. This feature is enabled as follows:

- 1. From the power-up screen, press [4], highlight Reference Input and press [5]. Highlight External and press [5] to save. Then press [5] to apply the changes (without saving for power-up) and exit. NOTE: This setting can be saved for power-up only by using the password-protected Power-up Settings menu (see {PAR. 3.3.7), otherwise internal references are used for both main and protection channels upon power-up.
- 2. To return to digital or local control, from the power-up screen press [4], then highlight Reference Input and press [5]. Highlight Internal and press [6] to save. Then press [6] to apply the change and exit.

**TABLE 3-15. ANALOG REMOTE SETUP MENU** 

SETTING	CHOICES (BOLD = Factory Default)	FUNCTION	
REFERENCE INPUT PIN 11 (referenced to pin 4)	INTERNAL EXTERNAL EXTL REF LVL	INTERNAL: Any external reference applied to the Analog I/O port pin 11 is ignored and the output is controlled using either the local front panel keypad (see PAR. 3.3.2) or remote SCPI commands (see Appendix B). EXTERNAL: The external reference applied to Analog I/O port pin 11 is used to control the output (see PAR. 3.4.3.1). The internal reference is ignored. EXTL REF LVL: Allows the gain of the BOP to be established by the maximum output voltage or current introduced in the main channel field. (see PAR. 3.4.3.2).	
PROTECTION LIMIT PINS 5, 6, 13, 14 (referenced to pin 12)	INTERNAL EXTERNAL LESSER LIMIT	INTERNAL - Allows the limits to be controlled by digital signals from either the keypad (local, see PAR. 3.3.2) or SCPI command (remote, see Appendix B). EXTERNAL: Allows the limits to be controlled by analog signals applied to the analog port; limits set from the keypad or SCPI command have no effect (see PAR. 3.4.4). LESSER LIMIT: Allows protect limit to be automatically selected from either 1) the external analog voltage applied to the Analog I/O port or 2) the value set from the keypad or SCPI command). Whichever limit has a lower absolute value (closest to zero) has effect.	
EXTERNAL MODE PIN 2 (referenced to pin 9)	DISABLE ENABLE	DISABLE - Allows the main channel (voltage or current) to be selected by either the front panel MODE key or SCPI command. The condition of pin 2 of the Analog I/O port is ignored (see PAR. 3.3.2).  ENABLE - The front panel MODE key and SCPI commands are prevented from affecting the active channel. Mode is determined by pin 2 of the Analog I/O port (see PAR. 3.4.2). This function cannot be saved for power-up.	
NOTE: Power-up state for Reference Input and Protection Limit are established by Power-up Settings Menu (PAR. 3.3.7) under General Setup Menu (Figure 3-6).			

NOTE: Each time the Reference Input setting is changed, the unit generates an internal \*RST reset command (see PAR. A.11) which requires the BOP output and/or protection limits to be reprogrammed.

When the external reference is used, the BOP functions as a power amplifier, amplifying the external reference at pin 11 to produce the output.

The nominal (inherent) voltage gain of each model is calculated by  $(G_{NOM-V}) = E_{Onom} / E_{REF-V}$ and nominal (inherent) current gain is  $(G_{NOM-I}) = I_{Onom} / E_{REF}$ . Thus the nominal gain is the ratio between the nominal (rated) voltage or current (E<sub>Onom</sub> or I<sub>Onom</sub>), and the external reference (E<sub>RFF</sub>) used to produce that output.

So for an external reference of  $\pm 10V$ , the nominal voltage gain  $(G_{NOM-V}) = E_{NOM-V}/10$ , e.g., the voltage gain of a BOP 36-28MG is 36/10 = 3.6. The nominal current gain  $(G_{NOM-1})$  is  $I_{NOM-V}/10$ , e.g., the current gain of a BOP 36-28MG is 28/10 = 2.8.

The external reference voltage may be d-c, a-c, or a combination of a-c plus d-c. The maximum frequency of an a-c signal should be below the inherent frequency response of the BOP (2KHz for voltage, 800Hz for current (see Table 1-2). For parallel or series combinations, the frequency response is reduced as specified in the instruction manual included with the cable kit. A frequency that exceeds the bandwidth of the BOP will cause the output to be distorted.

For linear response (input vs. output) the software limit (see 3.3.4.1) should be set to nominal and the maximum peak value (d-c plus a-c) of the reference signal must not exceed ±10V. If the input signal exceeds the limit value (either ±10V if the software limit is set to nominal, or a lesser

3-38 BOP HIPWR 022108 voltage for a user-determined software limit) clipping of the output voltage or current to the limit will occur.

NOTE: If the system limits have been modified (PAR. 3.3.4), the output of the power supply will never exceed the modified system limits. E.g, for a BOP 36-28MG, if the system voltage limit is modified to ±18V, applying a positive analog voltage to pin 11 that starts at zero and rises to +10V causes the output to rise from zero and reach +18V when the external reference reaches +5V. The output stays at +18V while the reference increases from +5V to +10V since the system voltage limits for this example are ±18V.

#### 3.4.3.2 VARIABLE GAIN USING EXTERNAL REFERENCE LEVEL

The BOP can function as a variable gain power amplifier similar to the fixed (inherent or nominal) gain amplifier as described in PAR. 3.4.3.1. The user can determine a new (lower) full scale output value for the ±10V reference level (applied at pin 11, referenced to pin 4, of the Analog I/O port) by configuring the Reference input as follows:

- 1. From the power-up screen press [4] and highlight Reference Input. Press [5], highlight ExtlRefLvl and press [54]. Then press [55] to apply the changes (without saving for power-up) and exit.
- 2. To return to digital or local control, from the power-up screen, press [4], then highlight Reference Input and press [5]. Highlight Internal and press [5] to apply the changes (without saving for power-up) and exit.

NOTE: Each time the Reference Input setting is changed, the unit generates an internal \*RST reset command (see PAR. A.11) which requires the BOP output and/or protection limits to be reprogrammed.

For an external reference of  $\pm 10V$ , the nominal voltage gain ( $G_{NOM-V}$ ) of a BOP 36-28MG is 36/10 = 3.6. If the new full scale voltage for 10V is set to 29V, the voltage gain is changed from 3.6 to 29/10 = 2.9. The gain can be changed from the front panel, but the output is controlled by the external reference signal and can not bne changed from the front panel.

New Gain = New Full scale set at front panel / External reference that produces Full scale output. This means that the External reference voltage, from +10V to -10V, can control the full scale output voltage from +29V to -29V. The gain range is between zero and the nominal gain of each model.

Once the feature is configured, the new full scale value is entered by changing the active setting value of the main channel. This determines the full scale output to be produced by a 10V external reference.

The gain in voltage mode is  $G_V = V_{SET}/10$  where  $V_{SET}$  is the desired full scale voltage (in Volts) entered at the front panel.

The gain in current mode is  $G_A = I_{SET}/10$  where  $I_{SET}$  is the desired full scale current (in Amperes) entered at the front panel.

NOTE: If the system limits have been modified (PAR. 3.3.4), the output of the power supply will never exceed the modified system limits.

# 3.4.4 EXTERNAL PROTECTION LIMITS

When PROTECTION LIMIT on the Reference Menu is set to EXTERNAL, the protect limits are determined by four analog signals referenced to Ground (pin 12) which are applied to the Analog I/O Port (see PAR. 3.4.4).

To be functional this feature must first be configured from the front panel. From the power-up screen press [4], and highlight Protection Limit. Press [5] to modify, then highlight External and press [6] to save. Then press [6] to apply the changes (without saving for power-up) and exit.

Only two signals are active, affecting the complementary protect channel, ±current protect limit for voltage mode and ±voltage protect limit for current mode. A voltage between +1V and +10V at the following pins (referenced to Ground, pin 12) will control the corresponding protection parameter between 10% of the nominal value (see Figure 1-2) and the corresponding positive or negative nominal full scale value.

- -I\_LIM\_EXT (pin 5) This +1V to +10V analog signal sets the negative current protect limit from 10% of the nominal value to -full scale current. +10V corresponds to rated minimum (maximum negative) current (e.g., for BOP 36-28MG, +10V sets negative current limit to -28A).
- -V\_LIM\_EXT (pin 6) This +1V to +10V analog signal sets the negative voltage protect limit from 10% of the nominal value to -full scale voltage. +10V corresponds to rated minimum (maximum negative) voltage (e.g., for BOP 36-28MG, +10V sets negative voltage limit to -36V).
- **+I\_LIM\_EXT (pin 13)** This +1V to +10V analog signal sets the positive current protect limit from 10% of the nominal value to full scale current. +10V corresponds to rated maximum current (e.g., for BOP 36-28MG, +10V sets positive current limit to +28A).
- +V\_LIM\_EXT (pin 14) This +1V to +10V analog signal sets the positive voltage protect limit from 10% of the nominal value to full scale voltage. +10V corresponds to rated maximum voltage (e.g., for BOP 36-28MG, +10V sets positive voltage limit to +36V).

The maximum frequency of an a-c signal used for the external protection limit must be at least 100 times lower that the sampling rate of the external signal (100Hz), resulting in a bandwidth of 1Hz.

The external programming circuit must be able to sink 0.15mA maximum provided by the BOP. When the input is an open circuit, the corresponding input signal automatically goes to 20% above the nominal protection limit.

NOTE: Each time Protection Limit setting is changed, the unit generates an internal \*RST reset command (see PAR. A.11) requiring the BOP output to be reprogrammed.

#### 3.4.4.1 USING BOTH LOCAL/DIGITAL AND EXTERNAL PROTECTION LIMITS

When PROTECTION LIMIT on the Reference Menu is set to Lesser Limit, the protect limits are automatically selected from either 1) the external analog voltage applied to the Analog I/O port (see PAR. 3.4.4) or 2) the value set from the keypad or SCPI command. Whichever limit has a lower absolute value (closest to zero) has effect.

To be functional this feature must first be configured from the front panel. From the power-up screen press [4], and highlight Protection Limit. Press [5] to modify, then highlight Lesser Limit and press [5] to apply the changes (without saving for power-up) and

3-40 BOP HIPWR 022108

exit. NOTE: Each time Protection Limit setting is changed, the unit generates an internal \*RST reset command (see PAR. A.11) requiring the BOP output to be reprogrammed.

# 3.4.5 MONITORING OUTPUT CURRENT USING AN ANALOG SIGNAL

The BOP provides an output analog signal, 0 to ±10V, that is proportional to the output current which is always available. For the master of a parallel or series configuration this signal is proportional to the output current of the parallel or series combination. This signal is available at pin 3, referenced to pin 10, of the Analog I/O port. To protect the BOP circuitry this signal is provided via a series 2K ohm resistor, thus requiring a high impedance monitoring device or instrument.

# 3.5 DIGITAL REMOTE MODE PROGRAMMING

BOP models may be digitally programmed over a control bus using SCPI (Standard Commands for Programmable Instruments). SCPI provides a common language conforming to IEEE 488.2 for instruments used in an automatic test system (see PAR. 3.6). The control bus used must be either the IEEE 488 standard communication bus (General Purpose Interface Bus, GPIB), or the RS 232C Serial Bus.

Refer to Table 2-11 for input/output signal allocations for communication via the GPIB, Table 2-5 for RS 232, and Table 2-2 for the BITBUS. All power supply functions available from the keypad can be programmed via remote SCPI commands. In addition, some features that are not available from the keypad may be implemented using remote commands (see PAR. 3.5.1).

This section includes a discussion of GPIB bus protocols (PAR. 3.5), instructions for changing the GPIB address (PAR. 3.5.3.1.1), a discussion of the VISA (Virtual Instrumentation Software Architecture) driver supplied with the unit (PAR. 3.5.5), RS 232C Operation (PAR. 3.5.6), followed by a detailed explanation of SCPI programming (PAR. 3.6).

#### 3.5.1 OPERATING FEATURES AVAILABLE ONLY BY REMOTE COMMANDS

The following paragraphs describe features of the BOP that are not available from the front panel, but can be implemented using remote commands.

#### 3.5.1.1 EXPANDED WAVEFORMS AND PROGRAMS

Refer to the documentation supplied with the VISA driver included with the BOP for more detailed information regarding waveforms and programs, including examples of how to create a table to load the variables.

# 3.5.2 PROGRAMMING TECHNIQUES TO OPTIMIZE PERFORMANCE

# 3.5.2.1 PROGRAMMING VOLTAGE/CURRENT LIMIT AND CURRENT/VOLTAGE LIMIT

Kepco's auto-crossover digital supplies can operate in either voltage mode with current limit, or current mode with voltage limit. The operating mode is determined by the voltage and current commands received, as well as the load. Each time voltage and current commands are received, the unit must evaluate the commands and the load conditions to determine the necessary operating mode. Reducing the number of times this evaluation must be made is desirable because Kepco's digital auto-crossover supplies employ two separate feedback loops. Each time there is a potential mode change, there is always an uncontrolled period of a few milliseconds while the two feedback loops compete for control of the output. By changing only the active parameter (e.g., voltage for voltage mode), there is no doubt as to what the operating

mode will be, so the unit is never uncontrolled, response is quick and no transients are possible. Recommended programming techniques are:

- 1. Minimize programmed mode (voltage or current) changes. Unless absolutely required by the test parameters, allow the power supply to automatically switch modes as determined by the load. This will improve response time and reduce undesirable transients.
- 2. Once the mode (voltage or current) is programmed, program the active parameter to zero and the complementary limit parameter to the maximum anticipated for application. Then program only the active parameter. The active parameter is the parameter that controls the output, e.g., voltage controls the output in voltage mode.
- 3. Never program both the active and complementary limit parameter to zero. This can result in long response times. Set the active parameter to zero and the complementary limit parameter to a minimum, e.g., 10% of maximum, to ensure that the active mode is defined.

#### 3.5.2.2 MAKING SURE THE PREVIOUS COMMAND IS COMPLETE

Some SCPI commands require a flash memory update and can take an indeterminate amount of time to complete. These commands are:

- \*SAV
- MEM:PACK
- MEM:UPD
- CAL:COPY
- CAL:SAVE
- SYST:PASS:NEW
- SYST:SEC:IMM

When sending these commands via the GPIB, these commands require a query to be added to the command string to verify the previous command is complete. When the command is complete, the unit updates the status byte and indicates MAV (Message Available, bit 4 - see Table A-3) is true. MAV indicates that there is a response to be received by the computer, so when it becomes set, the unit is ready for its next command after reading back the data from the query that was added to the command string.

When sending the above commands via the RS 232 bus, data flow control must be enabled (XON) for the unit to properly update flash memory.

The \*OPC? query is ideal to check if the previous command is complete since it returns either a 1 or 0. It is important that it be sent as a part of the same string as the command that causes a flash update. As an example, sending CAL:SAVE 12/31/2005;:\*opc? or \*opc?;:CAL:SAVE 12/31/2005 are valid command strings. Sensing the commands separately will not verify that the previous command is complete. Figure 3-16 is a program written in C, incorporating these techniques.

Failure to provide an adequate delay can result in:

- · Commands that are not processed,
- The following command may be received in error, causing an error in the transmission,
- Unit lock-up requiring power cycling of the unit. If working via the GPIB bus, sending Interface Clear and Device Clear followed by \*RST will unlock the unit.

3-42 BOP HIPWR 022108

```
#include <formatio.h>
#include <utility.h>
#include <gpib.h>
#include <ansi_c.h>
/*Overhead for the use of a NATIONAL INSTRUMENTS gpib interface */
int unit desc;
                                                  // handle for the national instruments controller
int GPIbus=0;
                                                  // GPIB card 0
int adr=6;
                                                  // Power Supply address
char status_byte;
                                                  // status byte from the power supply
#define MAV 0x10 /* bit 4 of the status byte is the Message AVailable bit by 488.2 specification */
/* Function Send_with_wait
 INPUT: string to be sent to power supply
 Description: adds the *OPC? query and performs serial polls to wait for the command to be completed.
int Send_with_wait(char *command);
char snd[501];
                                                   // data to be sent to the power supply
char rcv [10];
                                                   // data from power supply
int j;
sprintf(snd,"%s;:*OPC?,command);
                                                 // Add *OPC? to the command
                                                  // so there is a response from the
                                                  // power supply
Send(GPIbus, adr, snd, strlen(snd), 2);
for (j=0;j<500;j++)(</pre>
                                                 // Send the data to the power supply
for (j=0; j<500; j++) (
                                                 // loop until ready (5 seconds max)
                                                 // Wait for command to complete
    Delay(.05);
   Delay(.05); // Wait for command to complete ibrsp(unit_desc,&status_byte); // get status byte if ((status_byte& 0x10) ==0x10) break;) // by looking for data in string
Receive (GPIbus, adr, rev, rev_buf_size,10); // so the error queue will not receive a 410 error
}
                                                  // test code to show operation of function.
unit_desc=ibdev(GPIbus,adr,adr/256,T100ms,1,0x40a);Delay(.005);
Send (GPIbus, adr, "VOLT 10; curr .01", sizeof("VOLT 10; curr .01"), NLEND;
Send_with_wait("*SAV 10");
```

# FIGURE 3-16. PROGRAMMING EXAMPLE TO VERIFY PREVIOUS COMMAND HAS COMPLETED

# 3.5.3 REMOTE MODE SETUP

When either of the two interface ports are in use, PAR's 3.5.3.1 (GPIB), 3.5.3.2 and (RS 232) describe how to configure the port to meet the user's requirements.

The BOP can be conveniently substituted for a standard BOP that is currently being used with one of Kepco's BIT cards by using one of the Compatibility Modes provided (see PAR. 3.5.3.4 and 3.5.3.5.

The **system:set** and **system:Language** commands can be used to configure the BOP to operate in a manner consistent with earlier models of Kepco's 100W, 200W and 400W BOP power supplies.

# 3.5.3.1 GPIB PORT SETUP

The following paragraphs describe the how to configure the GPIB port.

#### 3.5.3.1.1 CHANGING THE GPIB ADDRESS

The default address is 6. To change the GPIB address press f5 from the power-up screen, then press f1 to enter the Interface menu (see Table 3-16) Highlight GPIB Address and press f1, then use the number keys to enter the desired address and press f4 to save. Press f4 to save for power-up or f5 to apply the changes (without saving for power-up) and exit.

**TABLE 3-16. INTERFACE SETTINGS MENU** 

SETTING	CHOICES (BOLD = Factory Default)	FUNCTION	
Interface Data Format	SCPI CIIL	SCPI (Standard Commands for Programmable Instruments) - see PAR. 3.6. and Appendix B. CIIL - Provides compatibility with early Kepco power supplies and controllers.	
GPIB Address	0 - 30 ( <b>06</b> )	Assigns address used by external GPIB controller to communicate with BOP.	
*RST set Output	OFF ON	OFF - Sending *RST causes output to go off (per IEEE 488.2 specifications) (see PAR. 3.5.3.1.3 for details). ON - Sending *RST causes output to go on (see PAR. 3.5.3.1.3 for details).	
Device Clear	SCPI MATE	SCPI - sending Device Clear (DCL) or selected DCL has no effect on output voltage and current per IEEE specification 488.2.  MATE - When device clear is received, the power supply output is set to zero volts.	
Serial Baud Rate	<b>OFF</b> 9600 19200	Selects RS 232 serial port baud rate.	
Xon/xoff	ENABLE DISABLE	ENABLE - Allows BOP to control when data is received (see PAR. 3.5.6.2.1). DISABLE - Disables XON/XOFF. If both Serial XON/XOFF and Prompt functions are disabled, Echo mode is the default (see PAR. 3.5.6.2.2).	
Prompt	DISABLE ENABLE ENAB+ECHO	ENABLE - Enables Serial Prompt (see PAR. 3.5.6.2.3). DISABLE - Disables Prompt. If both Serial XON/XOFF and Prompt functions are disabled, Echo mode is set (see PAR. 3.5.6.2.2). ENAB+ECHO - Enables Serial Prompt (see PAR. 3.5.6.2.3) and Echo (see PAR. 3.5.6.2.2) modes. Prompt is returned when the unit is ready and any received characters are echoed back to the sender.	
NOTE: To restore all interface settings defaults, press ff from the power-up screen, highlight Interface Settings, press ff to restore defaults shown above in <b>BOLD</b> . Press f4 to save for power-up or f5 to apply the changes (without saving for power-up) and exit.			

# 3.5.3.1.2 CONFIGURE DEVICE CLEAR (DCL) CONTROL

The device clear (DCL) and selected device clear can be set to operate in two modes. In the MATE mode, when the device clear is received, the output of the power supply is set to zero volts. In the SCPI mode sending DCL or selected DCL has no effect on output voltage and current as required by IEEE specification 488.2. The factory default value is SCPI mode.

To change the Device Clear configuration press [5] from the power-up screen, then press [6] to enter the Interface menu (see Table 3-16) Highlight Device Clear and press [6], then highlight SCPI or MATE and press [64] to save. Press [64] to save for power-up or [65] to apply the changes (without saving for power-up) and exit.

3-44 BOP HIPWR 022108

#### 3.5.3.1.3 DETERMINING WHETHER \*RST COMMAND SETS THE OUTPUT OFF OR ON

The user can control whether the \*RST command (see PAR. A.11) sets the output on or off. Table 3-17 describes how the unit operates depending on how \*RST set Output is configured, and the load type selected.

From the power-up screen press [5], and note whether "\*RST set Output" setting is as desired. To modify highlight Interface Settings (see Table 3-16) and press [1], then highlight On or Off and press [1] to save. Press [4] to save for power-up or [5] to apply the changes (without saving for power-up) and exit.

#### TABLE 3-17. OPERATION OF #RST COMMAND

Load type when *RST	BOP Status After *RST Issued			
Issued (see NOTE)	Internal	Front Panel Display		
Active or Resistive Load	Voltage mode	LCD shows mode is Voltage, Source		
(see PAR. 3.3.6)	Main Channel reference set to 0.0V	Vset set to 0.0V		
	Current protect set to 5% of I <sub>Onom</sub>	±CProt set to minimum (box) values		
	Voltage protect set to 5% above E <sub>Onom</sub>	If *RST set to OFF, output is disabled		
		If *RST set to ON, output is enabled		
Battery Load (see PAR.	If *RST set to OFF, unit is set to Voltage Mode	LCD shows mode is Voltage, Source		
3.3.6)	If *RST set to ON, unit is set to Current Mode	Vset set to 0.0V		
	Main Channel reference set to 0.0A	±CProt: minimum (box) values		
	Current protect set to 5% of I <sub>Onom</sub>	If *RST set to OFF, output is disabled		
	Voltage protect set to 5% above E <sub>Onom</sub>	If *RST set to ON, output is enabled		
NOTE: Prior to issuing *RST unit may be operating in either voltage mode or current mode.				

# 3.5.3.2 RS 232 SERIAL PORT SETUP

Paragraphs 3.5.3.2.1 through 3.5.3.2.3 below describe the setup required for the BOP to communicate via the RS 232C Serial bus using SCPI commands.

# 3.5.3.2.1 SELECT BAUD RATE

To change the Baud Rate configuration press form the power-up screen, then press for enter the Interface menu (see Table 3-16). Highlight Baud Rate and press form, then highlight the Off (to disable the serial port), 9600 or 19,200 and press form to save. Press for power-up or form to apply the changes (without saving for power-up) and exit.

#### 3.5.3.2.2 CONFIGURE XON/XOFF PROTOCOL

From the power-up screen press [5], then press [1] to enter the Interface menu (see Table 3-16), highlight SERIAL XON/XOFF and press [1]. Highlight the desired option and press [4] to save, then press [54] to save for power-up or [55] to apply the changes (without saving for power-up) and exit.

**Enable** - Allows BOP to control when data is received (see PAR. 3.5.6.2.1 for a description of Xon/Xoff protocol).

**Disable** - Disables XON/XOFF. If both Serial XON/XOFF and Prompt functions are disabled, Echo mode is set (see PAR. 3.5.6.2.2 for a description of echo mode).

#### 3.5.3.2.3 CONFIGURE PROMPT MODE

From the power-up screen press [5], then press [1] to enter the Interface menu (see Table 3-16). Highlight Serial Prompt and press [1], highlight the desired option and press [4] to save,

then press for power-up (see PAR. 3.5.6.2.3 for a description of prompt mode).

**Enable** - Enables Serial Prompt (see PAR. 3.5.6.2.3 for a description of prompt mode).

**Disable** - Disables Prompt. If both Serial XON/XOFF and Prompt functions are disabled, Echo mode is the default (see PAR. 3.5.6.2.2 for a description of Xon/Xoff mode).

**Enab+echo** - Enables Serial Prompt (see PAR. 3.5.6.2.3) and Echo (see PAR. 3.5.6.2.2) modes. Prompt is returned when the unit is ready and any received characters are echoed back to the sender.

#### 3.5.3.3 ESTABLISH COMMUNICATION LANGUAGE

Communication via GPIB port can be executed using either SCPI or CIIL protocols. From the power-up screen press [5], highlight Interface Settings and press [7] to enter the Interface menu (see Table 3-16). To change the setting, highlight Data Format, press [7], highlight SCPI or CIIL and press [7] to save, then press [7] to apply the changes (without saving for power-up) and exit, or press [7] to save for power-up.

# 3.5.3.4 BIT 4882 COMPATIBILITY.

To replace a standard BOP/BIT 4882 card combination with a BOP with minimal reconfiguration of existing test setups, send **SYSTEM:SET 4882** followed by **MEMOTY:UPDate INTERFACE**.

# 3.5.3.5 BIT 4886 COMPATIBILITY

To replace a standard BOP/BIT 4886 card combination with a BOP High Power with minimal reconfiguration of existing test setups, send **SYSTem: SET 4885**.

# 3.5.4 IEEE 488 (GPIB) BUS PROTOCOL

Table 3-18 defines the interface capabilities of the BOP power supply (Talker/Listener) relative to the IEEE 488 (GPIB) bus (reference document *ANSI/IEEE Std 488: IEEE Standard Digital Interface for Programmable Instrumentation*) communicating with a Host Computer—Controller (Talker/Listener). Tables 3-19 and 3-20 define the messages sent by the BOP, or received by the BOP, via the IEEE 488 bus in IEEE 488 command mode and IEEE 488 data mode, respectively. These messages are enabled during the "handshake" cycle, with the BOP power supply operating as either a Talker or a Listener. (See PAR. 3.5.3.1 to change the GPIB address.

TABLE 3-18. IEEE 488 (GPIB) BUS INTERFACE FUNCTIONS

FUNCTION	SUBSET SYMBOL	COMMENTS	
Source Handshake	SH1	Complete Capability (Interface can receive multiline messages)	
Acceptor Handshake	AH1	Complete Capability (Interface can receive multiline messages)	
Talker	T6	Basic talker, serial poll, unaddress if MLA (My Listen Address) (one-byte address)	
Listener	L4	Basic listener, unaddress if MTA (My Talk Address) (one-byte address).	
Service Request	SR1	Complete Capability. The interface sets the SRQ line true if there is an enabled service request condition.	
Remote/Local	RL1	Complete capability. Interface selects either local or remote information. In local mode the BOP executes front panel commands, but can be set to remote mode via IEEE 488 bus. When in Remote mode all front panel keys are disabled except LOCAL function key. LOCAL function key can be disabled using keypad lockout command (see Appendix B, PAR. B.107) so that only the controller or a power on condition can restore Local mode.	
Parallel Poll	PP0	No Capability	

3-46 BOP HIPWR 022108

TABLE 3-18. IEEE 488 (GPIB) BUS INTERFACE FUNCTIONS (CONTINUED)

FUNCTION	SUBSET SYMBOL	COMMENTS
Device Clear	DC1	Complete Capability. BOP accepts DCL (Device Clear) and SDC (Selected Device Clear).
Device Trigger	DT1	Respond to *TRG and <get> trigger functions.</get>
Controller	C0	No Capability

TABLE 3-19. IEEE 488 (GPIB) BUS COMMAND MODE MESSAGES

MNEMONIC	MESSAGE DESCRIPTION	COMMENTS
ATN	Attention	Received
DAC	Data accepted	Received or Sent
DAV	Data Valid	Received or Sent
DCL	Device Clear	Received (see PAR. 3.5.3.1.2)
IFC	Interface Clear	Received
MLA	My Listen Address	Received
MTA	My Talk Address	Received
ОТА	Other Talk Address	Received
RFD	Ready for Data	Received or Sent
SDC	Selected Device Clear	Received
SPD	Serial Poll Disable	Received
SPE	Serial Poll Enable	Received
SRQ	Service Request	Sent
UNL	Unlisten	Received
UNT	Untalk	Received

TABLE 3-20. IEEE 488 (GPIB) BUS DATA MODE MESSAGES

MNEMONIC	MESSAGE DESCRIPTION	COMMENTS
DAB	Data Byte	Received or Sent
END	End	Received or Sent
EOS	End of String	Received or Sent
RQS	Request Service	Sent
STB	Status Byte	Sent

#### 3.5.5 BOP VISA INSTRUMENT DRIVER

The VISA instrument driver for the BOP power supply, available for download at www.kepco-power.com/drivers.htm, simplifies programming with a VISA compatible GPIB controller. Included are:

- source code (C) for all VISA functions (kp\_bophi.c)
- a complete programming reference manual (kp bophi.doc)
- a sample application of the VISA functions (written in C) which can be used to program one or more BOP power supplies using a virtual front panel observed on a computer monitor (kp\_appl.c)

Although the software drivers supplied by Kepco are VISA compliant, they also require the installation of the proper VISA driver from your GPIB card supplier. Many vendors supply this software with the hardware; National Instruments (http://www.natinst.com) has the driver for their cards available on the internet at a file transfer site (ftp://ftp.natinst.com — find the folder for support and VISA drivers).

# 3.5.6 RS232-C OPERATION

The BOP may be operated via an RS232-C terminal, or from a PC using a terminal emulation program. The default settings are as follows:

Baud rate: OFFParity: NoneData Bits 8Stop Bits 1

Prompt DISABLEXON/XOFF ENABLE

To change baud rate, or select prompt, echo or XON/XOFF, refer to PAR. 3.5.3.2 and Table 3-16.

# 3.5.6.1 SERIAL INTERFACE

The serial interface behaves like the GPIB interface in that the command is parsed after receiving a control character of either a Line Feed or Carriage Return. The serial interface supports six special control characters. The six special control characters are:

Escape (1B<sub>H</sub>) Causes the input buffer to be cleared. This character is used to ensure

that the buffer is empty when the host powers on since it is possible that the TMA 4882-27 controller was previously powered on and received some characters prior to the initialization of the host com-

puter.

Backspace (08<sub>H</sub>) Causes the last character in the input buffer to be removed from the

input buffer queue.

Carriage Return (0D<sub>H</sub>) Causes the input buffer to be parsed by the BOP.

Line Feed  $(0A_H)$  Causes the input buffer to be parsed by the BOP.

3-48 BOP HIPWR 022108

#### 3.5.6.2 RS 232 IMPLEMENTATION

The following paragraphs are provided to help the user understand how the RS 232 serial interface is implemented in the BOP. Since the RS 232 protocol does not use a parity bit, The XON/XOFF method of communication is selected as the default to ensure "handshake" control of serial communication.

The echo mode is an optional method used to ensure reliable communication between the command originator (computer) and the BOP power supply, thus avoiding a more complex "handshake" protocol. When the BOP is in the RS 232 echo mode it returns all data sent to the host controller.

The BOP provides an additional option that allow handshake communication: the Prompt method. By using the handshake options (prompt and XON XOFF) the host controller can ensure that serial data interrupts occurring after parsing of the incoming message do not result in lost data.

Figure 3-17 illustrates the echo mode, the prompt method and the default XON XOFF method described in the following paragraphs.




FIGURE 3-17. RS 232 IMPLEMENTATION

Only seven control characters (characters between  $00_{\rm H}$  and  $1F_{\rm H}$ ) are acknowledged by the power supply:

- Carriage Return (CR, 0D<sub>H</sub>)
- Line Feed (LF, 0A<sub>H</sub>)
- Back Space (BS, 08<sub>H</sub>)
- Escape (ESC, 01B<sub>H</sub>)
- XON (011<sub>H</sub>)
- XOFF (013<sub>H</sub>)
- CAN (018<sub>H</sub>)

BS deletes the last character entered, with the exception of CR or LF characters. Either the CR or LF character acts as the line terminator, initiating parsing of the ASCII data sent to the BOP

by the command originator. When the line is parsed and the commands are sent to the analog processor, the BOP sends the line terminator sequence CR LF to the command originator.

The ESC character is used for synchronization, causing the BOP to reset its input buffer and return a CR LF sequence.

The XON character enables the transmitter if XON/XOFF flow control is enabled (see PAR. 3.5.3.2.2 and Table 3-16).

The XOFF character stops data transmission if XON/XOFF flow control is enabled (see PAR. 3.5.3.2.2 and Table 3-16).

The CAN character resets the receive and transmit pointers and queues.

CAUTION: When the serial port has received an XOFF, the error message -400, QUE error will be placed in the queue to indicate the loss of transmitted information due to a received XOFF character. When XON is received, the unit will transmit all data in it's buffer followed by the exclamation character (!). This (!) character is not part of any message from the BOP and indicates the transmission buffer has been cleared and the BOP is idle.

All non-control characters are sent via the serial port of the command originator. The control character BS is echoed as BS Space BS. Only the first control character is returned in response to either a CR LF or LF CR character sequence (see Figure 3-17).

#### 3.5.6.2.1 XON XOFF METHOD

The XON XOFF method allows the BOP to control when the command originator is allowed to send data. The command originator can only send data after the XON (transmission on) character (011 $_{\rm H}$ ) has been received; the command originator stops sending data after receiving the XOFF (transmission off) character (013 $_{\rm H}$ ), and waits until the XON character is received before sending additional data.

Control characters, either CR or LF, are returned as XOFF CR if echo mode is on, and as XOFF if echo mode is off. XOFF stops data from the command originator and the BOP returns the normal sequence of CR LF (if echo mode is enabled).

#### 3.5.6.2.2 ECHO MODE

Echo mode is one method of ensuring data is transferred without errors. This mode should only be enabled when errors in operation are detected.

Each byte (character) is echoed back to the sender where it is verified as the same character that was just sent. If the wrong character is echoed back, sending the ESC character clears the line to allow retransmission of the character. It is important the CR and LF characters are NOT sent until the verification process is complete.

When working in echo mode, it is possible to receive the NAK (15 hex) from the BOP. This indicates an unknown quantity of echoed characters have been lost due to a queue overflow problem. The error queue will also contain the *-400, QUE error* message, To prevent this, please insure the received data string does not exceed 127 characters between line terminators and no more than four queries are sent between line terminators in SCPI mode of operation

All non-control characters are sent via the serial port of the command originator.

3-50 BOP HIPWR 022108

#### **3.5.6.2.3 PROMPT METHOD**

The command originator sends a message line (command) to the BOP and waits until the prompt sequence CR LF >  $(3E_H,\ 62_{10})$  is received. The BOP sends the prompt sequence CR LF > to the command originator indicating the power supply is ready to receive the next command and data will not be lost. This method is useful in an interactive mode as well as with certain process controllers.

#### 3.5.6.3 USING SCPI COMMANDS FOR RS 232 COMMUNICATION.

The unit must be in remote mode before the RS 232 commands to affect the output can be executed (e.g., VOLT 10;OUTP ON). This can be accomplished by sending SYST:REM ON prior to sending any commands that affect the power supply output. (See PAR. B.113 and Figure B-5)

#### 3.5.6.4 ISOLATING RS 232 COMMUNICATION PROBLEMS

A Loop Back test can be run from the front panel to aid in isolating RS 232 communication problems. The unit is designed to pass the test only with the Loop Back test connector (part of Kit 219-0436, see Table 1-5) installed.

- 1. From the power-up screen press [5] key to enter the General Setup menu, then highlight Revisions/TEST. press [1] to enter the Test Subsystem menu.
- 2. Highlight Serial Interface and press [3] to run the test with the Loop Back Test connector NOT installed and verify the LCD reads Failed. If the LCD reads Passed, the power supply is defective and requires repair.
- 3. Install the loop back test connector into RS 232 port and press the [3] key to rerun the test. If the LCD reads Passed, the power supply is operating properly. If the LCD reads Failed, the unit requires repair.
- 4. To test the integrity of the cable assembly connecting the power supply RS 232 port to the computer, remove the Loop Back test connector from the power supply RS 232 port and connect the cable in its place. With the DB9 adapter installed on the opposite end of the cable, connect a short jumper wire between pins 2 and 3 of the adapter connector and repeat the test of step 3 above. If the LCD display reads Failed, the cord is either the improper type (not null modem) or is defective. If the LCD display reads Passed, the cable is correct; remove the jumper and reconnect the cable to the computer.

If each of the above steps is completed successfully, the problem lies in the computer hardware and/or software. Refer to the Product Support area of the Kepco website for additional information regarding RS 232 communications problems: www.kepcopower.com/support.

#### 3.6 SCPI PROGRAMMING

SCPI (Standard Commands for Programmable Instruments) is a programming language conforming to the protocols and standards established by IEEE 488.2 (reference document ANSI/IEEE Std 488.2, IEEE Standard Codes, Formats, Protocols, and Common Commands). SCPI commands are sent to the BOP Power Supply as ASCII output strings within the selected programming language (PASCAL, BASIC, etc.) in accordance with the manufacturer's requirements for the particular GPIB controller card used.

Different programming languages (e.g., BASIC, C, PASCAL, etc.) have different ways of representing data that is to be put on the IEEE 488 bus. It is up to the programmer to determine how to output the character sequence required for the programming language used. Address infor-

mation (GPIB address) must be included before the command sequence. (See PAR.3.5.3.1.1 to establish the BOP Power Supply GPIB address.)

#### 3.6.1 SCPI MESSAGES

There are two kinds of SCPI messages: program messages from controller to power supply, and response messages from the power supply to the controller. Program messages consist of one or more properly formatted commands/queries and instruct the power supply to perform an action; the controller may send a program message at any time. Response messages consist of formatted data; the data can contain information regarding operating parameters, power supply state, status, or error conditions.

#### 3.6.2 COMMON COMMANDS/QUERIES

Common commands and queries are defined by the IEEE 488.2 standard to perform overall power supply functions (such as identification, status, or synchronization) unrelated to specific power supply operation (such as setting voltage/current). Common commands and queries are preceded by an asterisk (\*) and are defined and explained in Appendix A (see Table 4-4). Refer also to syntax considerations (PARs 3.4.3 through 3.4.6).

#### 3.6.3 SCPI SUBSYSTEM COMMAND/QUERY STRUCTURE

Subsystem commands/queries are related to specific power supply functions (such as setting output voltage, current limit, etc.) Figure 3-18 is a tree diagram illustrating the structure of SCPI subsystem commands used in the BOP Power Supply with the "root" at the left side, and specific commands forming the branches. The following paragraphs introduce the subsystems; subsystem commands are defined and explained in Appendix B.

#### 3.6.3.1 ABORT SUBSYSTEM

This subsystem allows pending trigger levels to be cancelled.

#### 3.6.3.2 DISPLAY SUBSYSTEM

This subsystem controls the second line of the LCD. The first line will always display the LOCal or REMote operation status and the constant Voltage (CV) or constant Current functioning mode (CC).

#### 3.6.3.3 INITIATE SUBSYSTEM

This subsystem enables the trigger system. When a trigger is enabled, the triggering action will occur upon receipt of a GPIB <GET>, \*TRG or TRIGger command. If a trigger circuit is not enabled, all trigger commands are ignored.

#### 3.6.3.4 LIST SUBSYSTEM

The LIST subsystem allows the BOP to generate complex waveforms by executing a series of points in order. Each point contains a value for the main channel (either voltage or current) and the duration (dwell) that the value will appear at the output (from 93 microseconds to 0.034 second. The list system supports from 2950 to 5900 points per waveform, depending on the number of different dwells in the waveform: For example, if each point in the list has the same duration (a single dwell time), 5900 points are supported; if no more than 126 different dwell times are specified, 3933 points are supported, and if each point has a different dwell, a maximum of 2950 points are supported. The number of points supported is determined automatically by the BOP firmware.

3-52 BOP HIPWR 022108

The LIST subsystem includes a subsystem for waveform generation. The waveform generation is invoked with the verb APPLY. When APPLY is added to a list:volt or list:curr command, the BOP adds a series of points to the list arrays. The BOP can apply these points to approximate a SINE, Triangle, RAMP (positive or negative) or square waveform or a level. The basic command requires a type, frequency (or period for a level), a peak-to-peak amplitude (or amplitude for a level).and offset (offset not needed for a level) The unit will create an appropriate number of points in both the dwell and output control array to create the waveform centered on zero volts. An optional offset can be added to the command to cause the BOP to generate a non-centered waveform. For example, a 5 volt 400 Hertz sine wave may be centered at -3 volts. The list subsystem has controls the allow the user to modify the unit's behavior to generate parts of waveforms and to used specific dwell times as appropriate. The APPLY subsystem accommodates 126 different segments in a single waveform provided the generated points fit in the array. See paragraph 3.3.9.3 for an explanation of how a waveform is generated by the BOP.

#### 3.6.3.5 MEASURE SUBSYSTEM

This query subsystem returns the voltage and current measured at the power supply's output terminals.

#### 3.6.3.6 OUTPUT SUBSYSTEM

This subsystem controls the power supply's voltage and current outputs

#### 3.6.3.7 MEMORY SUBSYSTEM

This subsystem controls the Flash Memory used by the BOP microprocessors and is used for storing setup parameters and for storing a list for later recall and execution

The unit's configuration, voltage and current, saved setups (\*SAV and \*RCL command) and Calibration values are stored in Flash Memory. Since the Flash EEPROM cannot be modified by writing a single data byte, the block must be erased and then the data written into the correct locations.


Saved setups are accomplished by the 99 memory locations (groups of settings) which are stored in the nonvolatile memory. Each setting contains values for: Mode, main channel setting (voltage or current), Reference setting, positive and negative protect values, External Protect setting (see Table 3-18), and the keypad state (locked/unlocked. If the keypad is locked (SYST:KEYB DISable), the \*SAV command creates a protected setting that can not be altered from the front panel.

The BOP accomplishes this by partitioning the Flash memory. As the amount of Flash memory used becomes larger with each subsequent data update, the Flash memory fills up and needs to be compressed. The compression of the Flash EEPROM, called packing, is automatically handled by the BOP microprocessor's code. The packing process can take a half a second to accomplish Because it is automatically executed, it can occur after any \*SAV or save of Calibration. When the memory is out of space, the internal microprocessor moves the any data in the first page to the end of the flash array and then erases the first flash page. The pack process can take 500 milliseconds to complete. Packing is automatically invoked during power up initialization if the BOP finds that any storage area is over 90% utilized.

The following statistics are a guide as to when a MEMORY PACK will occur.

 Save area - Approximately 300 \*SAV operations can be completed before a PACK will occur automatically.

- Variable area around 3000 updates can be completed prior to an automatic PACK occurring. Variable areas also include serial number updates and password updates.
- Calibration 64 calibrations can be saved before a PACK is required.



<sup>♣</sup> See PAR. 3.5.2.2 and Figure 3-16 for special programming considerations.

#### FIGURE 3-18. TREE DIAGRAM OF SCPI COMMANDS USED WITH BOP POWER SUPPLY (SHEET 1 OF 2)

3-54 BOP HIPWR 022108

<sup>\*</sup> Requires MEM:UPD to save for power-up.

```
ROOT: (colon)-
                    [SOURce:] subsystem
                                                                                           LIST subsystem
                    [SOURce:]
                                                        [SOURce:]
                                                                                           LIST
                                                        CURRent
                    VOLTage
                                                                                              :CLEar
                                                          [:LEVel]
                      [:LEVel]
                                                                                              :COUNt val
                                                             [:IMMediate]
                         [:IMMediate]
                                                                                              :COUNt?
                                                               [:AMPLitude] val
                           [:AMPLitude] val
                                                                                              :CURRent val,val
                           [:AMPLitude]? MIN, MAX
                                                               [:AMPLitude]? MIN, MAX
                                                                                                APPLy
                                                             :TRIGgered
                                                                                                SWEep
                         :TRIGgered
                                                               [:AMPLitude] val
                           [:AMPLitude] val
                                                                                                SWEep?
                                                               [:AMPLitude]? MIN, MAX
                           [:AMPLitude]? MIN, MAX
                                                                                                :POINts?
                                                          :LIMit[:BOTH] *
                      :LIMit[:BOTH] *
                                                                                              :CURRent?
                                                                                              :DWELI val,val
                                                             :NEGative *
                         :NEGative 🛠
                                                                                              :DWELI?
                                                             :NEGative?
                         :NEGative?
                                                                                                :POINts?
                                                             :POSitive *
                         :POSitive *
                                                                                              :QUERy val
                                                             :POSitive?
                         :POSitive?
                                                                                              :QUERy?
                       :MODE FIXed, LIST, TRANsient,
                                                           :MODE FIXed, LIST, TRANsient,
                                                                                              :RES? val1,val2,val3
                                                               EXTernal, EXTReflevel,
                           EXTernal, EXTReflevel,
                                                                                              :VOLTage val,val
                                                               PROTect
                           PROTect
                                                                                                APPLy
                                                           :MODE?
                      :MODE?
                                                                                                SWEep
                                                           :PROTect
                       :PROTect
                                                                                                SWEep?
                                                             [:BOTH]
                         [:BOTH]
                                                                                                :POINts?
                                                             [:BOTH]?
                         [:BOTH]?
                                                                                              :VOLTage?
                                                             :NEGative
                         :NEGative
                                                             :NEGative?
                         :NEGative?
                                                             :POSitive
                         :POSitive
                                                             :POSitive?
                         :POSitive?
                                                             :LIM[:BOTH] *
                         :LIM[:BOTH] *
                                                             :LIM[:BOTH]?
                         :LIM[:BOTH]?
                                                             :LIM:NEGative 🛠
                         :LIM:NEGative *
                                                             :LIM:NEGative?
                         :LIM:NEGative?
                         :LIM:POSitive *
                                                             :LIM:POSitive *
                                                             :LIM:POSitive?
                         :LIM:POSitive?
                                                        FUNCtion
                                                           :MODE VOLT, CURR, EXTernal
                                                           :MODE?
                                                             :TRIGger VOLTage, CURRent
                                                             :TRIGger?
```

Requires MEM:UPD to save for power-up.

#### FIGURE 3-18. TREE DIAGRAM OF SCPI COMMANDS USED WITH BOP POWER SUPPLY (SHEET 2 OF 2)

#### 3.6.3.8 STATUS SUBSYSTEM

This subsystem programs the power supply status register. The power supply has two groups of status registers: Operation and Questionable. Each group consists of three registers: Condition, Enable, and Event.

#### 3.6.3.9 TRIGGER SUBSYSTEM

This subsystem controls the remote triggering of the power supply.

#### 3.6.3.10 [SOURCE:]VOLTAGE AND [SOURCE:]CURRENT SUBSYSTEMS

These subsystems program the output voltage and current of the power supply.

#### 3.6.3.11 CALIBRATE SUBSYSTEM

The BOP series of power supplies support software calibration. A full calibration consist of a voltage calibration and a current calibration. These calibration procedures include steps that prepare the unit for series or parallel operation. Both voltage and current calibrations consist of a zero (performed on the main channels only) and positive and negative full scale calibrations with both internal and external references. In addition, the external reference and variable gain are also calibrated. There are two ways to perform the calibration: locally using the front panel keys, or remotely sending commands through the GPIB bus. These two ways cannot be combined.

In order to enter the calibration mode the correct calibration access code (password) must be entered. If the password has been forgotten call the factory and a secret password (which has been assigned to your power supply) will be provided. During the calibration, new calibration data is computed which is than stored in the non volatile memory.

Refer to PAR. 4.2 for calibration equipment requirements.

During voltage calibration, the voltage, voltage protect and voltage readback are calibrated and during current calibration the current, current protect and current readback are calibrated. The normal procedure is to calibrate voltage first and then current. However, you do not have to do a complete calibration each time. If required, you may calibrate only the voltage or the current and then proceed to saving the calibration results. For voltage calibration all loads must be disconnected and the sense terminals connected to the corresponding output terminals. The digital voltmeter will be connected to the sensing terminals (OUT S and COM S) of the power supply. For current calibration after disconnecting all loads an appropriate shunt resistor will be connected across output terminals and the digital voltmeter will be connected across the sense terminals of the shunt resistor.

#### 3.6.3.12 SYSTEM SUBSYSTEM

This subsystem controls system-level commands, including setup of the GPIB and Serial ports, error queries, front panel setup (keyboard lockout, display illumination, and audible beeps), passwords, command language, setup of device clear, line feed and reset, and restoring factory calibration.

#### 3.6.3.12.1 FORGOTTEN PASSWORDS

If the password is lost, it is possible to enable the password interface by sending

SYST:PASS:CEN POWERSUPPLIER

Once enabled, the passwords can be set to the default values

SYST: SEC: OVERRIDE

This restores the passwords to the following:

Main: DEFAULT Admin2: KEPCO

Admin1: (none assigned)

3-56 BOP HIPWR 022108

#### 3.6.4 PROGRAM MESSAGE STRUCTURE

SCPI program messages (commands from controller to power supply) consist of one or more *message units* ending in a *message terminator*. The message terminator is not part of the syntax; it is defined by the way your programming language indicates the end of a line ("newline" character). Sending a character with EOL line asserted is another way of sending a message terminator. The message unit is a keyword consisting of a single command or query word followed by a message terminator (e.g., CURR?<newline> or TRIG<end-of-line>). The message unit may include a data parameter after the keyword separated by a space; the parameter is usually numeric (e.g., CURR 5<newline>), but may also be a string (e.g., OUTP ON<newline>). Figure 3-19 illustrates the message structure, showing how message units are combined. The following subparagraphs explain each component of the message structure.

NOTE: An alternative to using the message structure for multiple messages defined in the following paragraphs is to send each command as a separate line. In this case each command must use the full syntax shown in Appendix B.

#### 3.6.4.1 KEYWORD

Keywords are instructions recognized by a decoder within the BOP, referred to as a "parser." Each keyword describes a command function; all keywords used by the BOP are listed in Figure 3-18.

Each keyword has a long form and a short form. For the long form the word is spelled out completely (e.g. STATUS, OUTPUT, VOLTAGE, and TRIGGER are long form keywords). For the short form only the first three or four letters of the long form are used (e.g., STAT, VOLT, OUTP, and TRIG). The rules governing short form keywords are presented in Table 3-21.

IF NUMBER OF LETTERS IN LONGFORM KEYWORD IS:	AND FOURTH LETTER IS A VOWEL?		
4 OR FEWER	(DOES NOT MATTER)	ALL LONG FORM LETTERS	MODE
5 OR MORE	NO	THE FIRST FOUR LONG FORM LETTERS	MEASure, OUTPut, EVENt
5 OR MORE	YES	THE FIRST THREE LONG FORM LETTERS	LEVel, IMMediate, ERRor

TABLE 3-21. RULES GOVERNING SHORTFORM KEYWORDS

You must use the rules above when using keywords. Using an arbitrary short form such as ENABL for ENAB (ENABLE) or IMME for IMM (IMMEDIATE) will result in an error. Regardless of which form chosen, you must include all the letters required by that form.

To identify the short form and long form in this manual, keywords are written in upper case letters to represent the short form, followed by lower case letters indicating the long form (e.g., IMMediate, EVENt, and OUTPut). The parser, however, is not sensitive to case (e.g., outp, OutP, OUTPut, or OUTp are all valid).

#### 3.6.4.2 KEYWORD SEPARATOR

If a command has two or more keywords, adjacent keywords must be separated by a colon (:) which acts as the keyword separator (e.g., CURR:LEV:TRIG). The colon can also act as a root specifier (paragraph 3.6.4.7).

#### 3.6.4.3 QUERY INDICATOR

The question mark (?) following a keyword is a query indicator. This changes the command into a query. If there is more than one keyword in the command, the query indicator follows the last keyword. (e.g., VOLT? and MEAS:CURR?).

#### 3.6.4.4 DATA

Some commands require data to accompany the keyword either in the form of a numeric value or character string. Data always follows the last keyword of a command or query (e.g., VOLT:LEV:TRIG 14 or SOUR:VOLT? MAX

#### 3.6.4.5 DATA SEPARATOR

Data must be separated from the last keyword by a space (e.g., VOLT:LEV:TRIG 14 or SOUR:VOLT? MAX




FIGURE 3-19. MESSAGE STRUCTURE

## 3.6.4.6 MESSAGE UNIT SEPARATOR

When two or more message units are combined in a program message, they must be separated by a semicolon (;) (e.g., VOLT 15;MEAS:VOLT? and CURR 12; CURR:TRIG 12.5).

#### 3.6.4.7 ROOT SPECIFIER

The root specifier is a colon (:) that precedes the first keyword of a program message. This places the parser at the root (top left, Figure 3-18) of the command tree. Note the difference between using the colon as a keyword separator and a root specifier in the following examples:

VOLT:LEV:IMM 16 Both colons are keyword separators.

3-58 BOP HIPWR 022108

:CURR:LEV:IMM 4 The first colon is the root specifier, the other two are keyword separators.

VOLT:LEV 6;:CURR:LEV 15 The second colon is the root specifier, the first and third are keyword separators

:INIT ON;:TRIG;:MEAS:CURR?;VOLT? The first three colons are root specifiers.

#### 3.6.4.8 MESSAGE TERMINATOR

The message terminator defines the end of a message. One message terminator is permitted:

new line (<NL>), ASCII 10 (decimal) or 0A (hex)

NOTE: Kepco power supplies *require* a message terminator at the end of each program message. The examples shown in this manual assume a message terminator will be added at the end of each message. Where a message terminator is shown it is represented as <NL> regardless of the actual terminator character.

#### 3.6.5 UNDERSTANDING THE COMMAND STRUCTURE

Understanding the command structure requires an understanding of the subsystem command tree illustrated in Figure 3-18. The "root" is located at the top left corner of the diagram. The parser goes to the root if:

- a message terminator is recognized by the parser
- · a root specifier is recognized by the parser

Optional keywords are enclosed in brackets [] for identification; optional keywords can be omitted and the power supply will respond as if they were included in the message. The root level keyword [SOURce] is an optional keyword. Starting at the root, there are various branches or paths corresponding to the subsystems. The root keywords for the BOP Power Supply are :ABORt, :CALibrate, :DISPlay, :INITiate, :LIST, :MEASure, :OUTPut, [:SOURce], :STATus, :SYSTem and :TRIGger. Because the [SOURce] keyword is optional, the parser moves the path to the next level, so that VOLTage, CURRent, and FUNCtion commands are at the root level.

Each time the parser encounters a keyword separator, the parser moves to the next indented level of the tree diagram. As an example, the STATus branch is a root level branch that has three sub-branches: OPERation, PRESet, and QUEStionable. The following illustrates how SCPI code is interpreted by the parser:

#### STAT:PRES<NL>

The parser returns to the root due to the message terminator.

#### STAT:OPER?;PRES<NL>

The parser moves one level in from STAT. The next command is expected at the level defined by the colon in front of OPER?. Thus you can combine the following message units STAT:OPER? and STAT:PRES;

#### STAT:OPER:COND?;ENAB 16<NL>

After the OPER:COND? message unit, the parser moves in one level from OPER, allowing the abbreviated notation for STAT:OPER:ENAB.

#### 3.6.6 PROGRAM MESSAGE SYNTAX SUMMARY

- Common commands begin with an asterisk (\*).
- Queries end with a question mark (?).
- Program messages consist of a root keyword and, in some cases, one or more message units separated by a colon (:) followed by a message terminator. Several message units of a program message may be separated by a semicolon (;) without repeating the root keyword.
- If a program message has more than one message unit, then a colon (:) must precede the next keyword in order to set the parser back to the root (otherwise the next keyword will be taken as a subunit of the previous message unit).
  - e.g., the command meas:volt?;curr? will read output voltage and output current since both volt? and curr? are interpreted as subunits of the meas command.
- Several commands may be sent as one message; a line feed terminates the message.
  Commands sent together are separated by a semicolon (;). The first command in a message starts at the root, therefor a colon (:) at the beginning is not mandatory. E.g., the command meas:volt?;:curr? will read output voltage and programmed current since the colon preceding curr? indicates that curr? is not part of the meas command and starts at the root.
- UPPER case letters in mnemonics are mandatory (short form). Lower case letters may
  either be omitted, or must be specified completely (long form)
   e.g., INSTrument (long form) has the same effect as INST (short form).
- Commands/queries may be given in upper/lower case (long form)
   e.g., SoUrCe is allowed.
- Text shown between brackets [] is optional.
   e.g., :[SOUR]VOLT:[LEV] TRIG has the same effect as :VOLT TRIG

#### 3.6.7 STATUS REPORTING

The status reporting of the BOP power supply follows the SCPI and IEEE 488.2 requirements. The serial poll response of the BOP power supply provides summary bits of the status and error reporting system. The simplest status report is the command valid reporting and data availability, This successful decoding of a command string generates no error and is indicated by the bit 3 of the serial poll response being a zero. The setting of bit 4 in the status byte indicates data is available to the controller in response a command query message.

#### 3.6.7.1 STATUS REPORTING STRUCTURE

The status reporting of the BOP uses four status registers, illustrated in Figure 3-20. These registers are the Questionable, Operation, Standard Event and Service Request registers. The Questionable and Operation registers are 16 bit registers and the Standard Event and Service Request registers are 8 bits. These four registers are referred to as condition registers. Each of the four condition registers is associated with two related registers: an event register which holds unlatched events reported in real-time by the instrument and is cleared by reading the register, and an enable register which allows the contents of the event register to be passed through to set the associated condition register.

3-60 BOP HIPWR 022108




FIGURE 3-20. STATUS REPORTING STRUCTURE

A zero to one transition of a condition register is added to the event register if the specific bit in the enable register is also a 1. Reading an event register clears all of the bits found in the event register. If any bits are set in an event register, the following condition register bit is then set. For example, if the STAT:QUES:ENB (enable) register has bit 0 set and a voltage error is detected, the event registers bit 0 is set. The 1 in the event register causes bit 3 of the status byte to be asserted. The Service Request register is ANDed with its enable register for all bits except bit 6. The result is placed in bit 6 of the Service Request register. If bit 6 is a 1 (true), it causes the MBT-G power supply to assert the SRQ line to the host controller.

Figure 3-20 also shows that if the error/event queue is not empty, bit 3 is set in the Service Request register and bit 4 indicates that a message is available in the output buffer.

#### 3.6.7.2 OPERATIONAL STATUS REGISTER

The OPERational condition register contains conditions which are a part of the instrument's normal operation. The definition of each of these bits (condition register) is as follows:

- 1 through 7 Not Used always zero.
- 8 Constant Voltage 1 indicates the instrument is in constant voltage mode.
- 9 Not Used always zero.
- 10 Constant Current 1 indicates the instrument is in constant current mode.
- 11 through15 Not Used always zero.

#### 3.6.7.3 QUESTIONABLE STATUS REGISTER

The QUEStionable condition register (see Figure 3-20) contains status bits representing data/signals which give an indication of the quality of various aspects of the signal.

A bit set in the QUEStionable condition register indicates that the data currently being acquired or generated is of questionable quality due to some condition affecting the parameter associated with that bit.

- 0 Voltage Mode 1 indicates the instrument is in Voltage mode.
- 1 Current Mode 1 indicates the Power Supply is in Current mode. Changes in this bit do not affect the event register.
- 2 Not Used always zero.
- 3 Thermal Error 1 indicates a thermal error has been detected.
- 4 11 Not Used always zero.
- 12 Voltage Error 1 indicates an error has been detected in Voltage mode.
- 13 Current Error 1 indicates an error has been detected in Current mode.
- 14 15 Not Used always zero.

#### 3.6.8 SCPI PROGRAM EXAMPLES

Refer to Appendix B, Figures B-1 through B-6 for examples illustrating the use of SCPI commands.

Figure 3-21 is an example of a program using SCPI commands to program the BOP Power Supply. The program illustrated is for a configuration using an IBM PC or compatible with a National Instruments GPIB interface card. (It will be necessary to consult the manufacturer's data to achieve comparable functions with an interface card from a different manufacturer.) This program sets output voltage (Voltage mode) or voltage limit (Current mode) to 5V, and current limit (Voltage mode) or output current (Current mode) to 1A, then reads the measured (actual) voltage and current, then prints the measurements.

3-62 BOP HIPWR 022108

```
Sample Program For KEPCO power supply, using National Instruments */
  GPIB interface card and IBM PC or compatible computer
#include <stdio.h>
#include "decl.h"
char rd_str[80];
                                                      // Input buffer
char dat_str[80];
                                                      // Output buffer
int bd,adr;
main() {
    adr = ibfind("DEV6");
                                                      // Open DEV6 (defined by IBCONF)
    bd = ibfind ("GPIB0");
                                                      // Open GPIB card
                                                      // Send Interface Clear
    ibsic (bd);
                                                      // Set remote line true
    ibsre(bd,1);
    strcpy(dat_str,"VOLT 5;CURR 1");
                                                      // Define a set command
    strcat(dat\_str,"\r\n");
                                                      // Append delimiter
    ibwrt(adr,dat_str,strlen(dat_str));
                                                      // Send string to power supply
    strcpy(dat str,"MEAS:VOLT?;CURR?");
                                                      // Define a measure command
    strcat(dat str,"\r\n");
                                                      // Append delimiter
    ibwrt(adr,dat str,strlen(dat str));
                                                      // Send string to power supply
    strset(rd_str,'\0');
                                                      // Clear input buffer
    ibrd(adr,rd_str,64);
                                                      // Read result of measure
    printf("received : %s\n",rd str);
                                                      // Print voltage and current
}
```

FIGURE 3-21. TYPICAL EXAMPLE OF BOP POWER SUPPLY PROGRAM USING SCPI COMMANDS

BOP HIPWR 022108 3-63/(3-64 Blank)

#### **SECTION 4 - CALIBRATION**

#### 4.1 GENERAL

This section contains the calibration instructions for the Power Supply. It is recommended that the user be familiar with Local Mode operation (PAR.3.2) before calibrating the unit.

A full calibration consist of a voltage calibration and a current calibration. Both voltage and current calibrations consist of zero, max and min, and protection limit calibration. In addition, the control signals required for series and parallel operation of multiple units are also calibrated. It is recommended that the unit be recalibrated annually.

In order to enter the calibration mode the correct password may be required (see PAR. 3.2.4.4). If the password has been lost, call the factory and a special password will be provided. During the calibration, new calibration data is computed which is then stored in the nonvolatile memory.

Calibration of the BOP is performed in one of three ways: locally using the front panel keys (PAR. 4.4), remotely by sending commands through either the GPIB or RS 232 bus (PAR. 4.3), or remotely using the graphical interface supplied with the instrument driver available at www.kepcopower.com/drivers.htm (PAR. 4.4.3). This VISA compliant driver works with many GPIB cards from suppliers like National Instruments and Hewlett-Packard. These three ways cannot be combined. Separate calibration procedures are provided for units connected in series or parallel.

NOTE: During calibration, various circuits of the BOP are verified. If an error occurs during the verification process, the unit will beep and an error 24(x), Hardware, (see PAR. B.104) will be placed in the error queue.

**TABLE 4-1. CALIBRATION SUMMARY** 

Туре	Step	Reference Type and Value	Monitored Parameter Output Conditions		Notes
VOLTAGE INTERNAL	1. ZERO 2. POSITIVE 3. NEGATIVE	Internal	Output Voltage 1. 0.0v 2. +Voltage FS 3. –Voltage FS	NO LOAD AUTOMATIC VM	DVM between OUT S and COM S.     Adjust for zero, positive and negative FS.
VOLTAGE PROTECTION	1. POSITIVE 2. NEGATIVE	Internal	Output Voltage 1. +Voltage FS 2Voltage FS  NO LOAD AUTOMATIC CM		1. DVM between OUT S and COM S. 2. Adjust for positive and negative FS.
VOLTAGE EXTERNAL	1. ZERO 2. POSITIVE	External: 1. 0.0V 2. +10.0V (Analog I/O Port, pin 11 ref to pin 4)	Output Voltage 1. 0.0v 2. –Voltage FS	NO LOAD AUTOMATIC VM	1. DVM between OUT S and COM S. 2. Adjust for zero, positive FS.
VOLTAGE GAIN	1. ZERO 2. POSITIVE	External: 1. 0.0V 2. +10.0V (Analog I/O Port pin 11 ref to 4)	Output Voltage: 1. 0.0V 2. 0.0V  No Load Automatic VM		1. DVM between OUT S and COM S 2. Adjust for zero (both Zero and Posi- tive).
EXTERNAL CONTROLS, SERIES	1. ZERO 2. )POSITIVE	External: 1. 0.0V 210.0V (Par/Ser CTRL-IN Port, pin 8 ref to 1)	Output Voltage: 1. 0.0V 2. +10.0V	No Load Automatic VM	1. DVM between OUT S and COM S 2. Adjust for zero, +10.0V 3. Calibrate unit for Slave in Series

TABLE 4-1. CALIBRATION SUMMARY (CONTINUED)

Туре	Step	Reference Type and Value	Monitored Parameter	Output Conditions	Notes
Remote Calibr. VOLTAGE EXTERNAL PROTECTION, Pos. Voltage Neg. Voltage (together)	1. ZERO 2. POSITIVE	External: 1. 0.0V 2. +10.0V (Analog I/O Port pin 14+6 ref to pin12)	N/A	No requirements	Automatic internal measurement     Remote Calibration only.
CURRENT, INTERNAL	1. ZERO 2. POSITIVE 3. )NEGATIVE	Internal	Output Current: 1. 0.0A 2. +Current FS 3. –Current FS	Short with Meas. Shunt Automatic CM	DVM between probe terminals of Meas.     Shunt (LO towards COM S)     Adjust for zero, positive and negative FS
CURRENT, PROTECTION	1. POSITIVE 2. NEGATIVE	Internal	Output Current: 1. +Current FS 2Current FS	Short with Meas. Shunt Automatic VM	DVM between probe terminals of Meas.     Shunt (LO towards COM S)     Adjust for positive and negative FS.
CURRENT, EXTERNAL	1. ZERO 2. POSITIVE	External: 1. 0.0V 2. +10.0V (Analog I/O Port pin 11 ref to 4)	Output Current: 1. 0.0A 2. +Current FS	Short with Meas. Shunt Automatic CM	1. DVM between probe terminals of Meas. Shunt (LO towards COM S). 2)Adjust for zero, pos FS.
CURRENT, GAIN	1. ZERO 2. POSITIVE	External: 1. 0.0V 2. +10.0V (Analog I/O Port pin 11 ref to 4)	Output Current: 1. 0.0A 2, )0.0A	Short with Meas. Shunt Automatic CM	1. DVM between probe terminals of Meas. Shunt (LO towards COM S) 2. Adjust for zero (both Xero and Positive)
EXTERNAL CONTROLS, PARALLEL	1. ZERO 2. POSITIVE	External: 1. 0.0V 2. +10.0V (Par/Ser CTRL-IN Port pin3 ref. to pin1)	Output Current: 1. 0.0A 2. +Current FS	Short with Meas. Shunt Automatic CM	DVM between probe terminals of Meas.     Shunt (LO towards COM S)     Adjust for zero, pos.     FS     Calibrate unit for Slave in Parallel
EXTERNAL CONTROLS, I_OUT	1. ZERO 2. POSITIVE	INTERNAL	Voltage at Par/Ser CTRL-IN Port pin 6 ref. to pin1: 1. 0.0V 2. +10.0V	Short with Meas. Shunt Automatic CM	1. DVM at Par/Ser CTRL-IN Port pin 6 ref. to pin 1 2. Adjust for zero, +10.0V 3. Calibrate unit for Master in Parallel
Remote Calibr. CURRENT EXTERNAL PROTECTION, Pos. Current Neg. Current (together)	1. ZERO 2. POSITIVE	External: 1. 0.0V 2. +10.0V (Analog I/O Port pins 13, 5 ref to pin 12)	N/A	No requirements	Automatic internal measurement     Remote Calibration. only.

4-2 BOP-1K 022108

**TABLE 4-1. CALIBRATION SUMMARY (CONTINUED)** 

Туре	Step	Reference Type and Value	Monitored Parameter	Output Conditions	Notes
Local Calib. EXTERNAL PROTECTION, Pos. Voltage Neg. Voltage Pos. Current Neg. Current (together)	1. ZERO 2. POSITIVE	External: 1. 0.0V 2. +10.0V (Analog I/O Port pins 14, 6, 13, 5 ref to pin12)	N/A	No requirements	Automatic internal measurement     Local Calibration only.

#### 4.2 TEST EQUIPMENT REQUIREMENTS

Table 4-2 lists sense resistors recommended for measuring current and includes Kepco and Manufacturer's part numbers. The value of the sense resistor chosen should be known with 0.001% accuracy. If other than a recommended sense resistor is to be used, it must be rated for at least 100W power dissipation (actual power dissipation will be approximately 10W). The thermal coefficient of the sense resistor chosen should be 10 ppm or better.

The digital voltmeter (DVM) used to measure output voltage and the voltage across the current sensing resistor should have at least six digits, multiple ranges, the smallest resolution must be at least one microvolt and the accuracy must be at least 0.0001%.

To calibrate the external programming capabilities of the BOP a DC reference voltage with the following minimum specifications is required.

- Value: 0.0V ±0.1mV and 10.0V ±0.1mV (either positive and negative or floating)
- Stability: better than 10<sup>-5</sup>
- Internal Impedance: better than 0.1 Ohms
- Output Current: >0.5mA when sourcing, >0.15mA when sinking

**TABLE 4-2. SUGGESTED SENSE RESISTORS** 

MODEL	VALUE	KEPCO PART NO.	MANUFACTURER	MANUFACTURER PART NO.
BOP 10-75MG BOP 20-50MG BOP 36-28MG	0.001 OHM	115-3033	ISOTEK	RUG-Z-R001-0.1 TK10
BOP 50-20MG BOP 72-14MG BOP 100-10MG	0.01 OHM	115-2997	ISOTEK	RUG-Z-R010-0.1 TK10

NOTE: ALL SENSE RESISTORS MUST BE MOUNTED ON A HEATSINK WITH A MINIMUM SURFACE AREA OF 36 SQUARE INCHES TO MAINTAIN THERMAL STABILITY DURING CALIBRATION; FORCED CCOOLING IS RECOMMENDED. KEPCO HEATSINK P/N 136-0451 WILL PROVIDE ADQUATE COOLING FOR THE SENSE RESISTOR.

TABLE 4-3. VOLTAGE CALIBRATION MEASUREMENTS AND TOLERANCES

MODEL	VOLTAGE ZERO	±FULL SCALE VOLTAGE	±FULL SCALE VPR LIMIT
BOP 10-75MG	0V ±0.0001V	10V (MAX) -10V (MIN) ±0.001V	10V (MAX) -10V (MIN) ±0.003V
BOP 20-50MG	0V ±0.0002V	20V (MAX) -20V (MIN) ±0.002V	20V (MAX) -20V (MIN) ±0.006V
BOP 36-28MG	0V ±0.0036V	36V (MAX) -36V (MIN) ±0.0036V	36V (MAX) -36V (MIN) ±0.01V
BOP 50-20MG	0V ±0.005V	50V (MAX) -50V (MIN) ±0.005V	50V (MAX) -50V (MIN) ±0.015V
BOP 72-14MG	0V ±0.0072V	72V (MAX) -72V (MIN) ±0.0072V	72V (MAX) -72V (MIN) ±0.022V
BOP 100-10MG	0V ±0.01V	100V (MAX) -100V (MIN) ±0.01V	100V (MAX) -100V (MIN) ±0.03V

#### 4.3 CALIBRATION USING REMOTE SCPI COMMANDS VIA GPIB OR RS 232 INTERFACE

The primary means of adjustment are the **CAL:DATA** commands. Basically these commands are fine and coarse adjustments, however there are slight differences in how they work for different types of calibrations.

- a. **ZERO Calibrations (always done first).** The only means of adjustment is the **CAL:DATA <VALUE>** command which provides a total of 4095 increments of adjustment starting at 0, with 2047 increments in either direction to achieve maximum output levels of  $\pm 2.5\%$  of  $E_{Onom}$ . Adjust the output to obtain the closest value to zero.
- b. MAX and MIN Calibrations. The primary means of adjustment is the CAL:DATA <VALUE> command to either increase (CAL:DATA 1) or decrease (CAL:DATA -1) the output value. Adjustment can be done in larger increments by increasing the numeric value, e.g., CAL:DATA +10 or CAL:DATA -10. Adjust the output to obtain the closest value above the full scale value.
- c. **VPR and CPR Calibrations**. The only means of adjustment is the **CAL:DATA <VALUE>** command which provides a total of 4095 increments of adjustment from zero to maximum. Adjust the output to obtain the closest value above the full scale value.

4-4 BOP-1K 022108

TABLE 4-4. CURRENT CALIBRATION MEASUREMENTS AND TOLERANCES

MODEL	SENSE RESISTOR VALUE (SEE NOTE AND TABLE 4-2)	CURRENT ZERO	±FULL SCALE CURRENT	±FULL SCALE CPR LIMIT
BOP 10-75MG	0.001 Ohm	0V ±0.008mV	0.075V (MAX) -0.075V (MIN) ±0.008mV	0.075V (MAX) -0.075V (MIN) ±0.038mV
BOP 20-50MG	0.001 Ohm	0V ±0.005mV	0.05V (MAX) -0.05V (MIN) ±0.005mV	0.05V (MAX) -0.05V (MIN) ±0.025mV
BOP 36-28MG	0.001 Ohm	0V ±0.003mV	0.028V (MAX) -0.028V (MIN) ±0.003mV	0.028V (MAX) -0.028V (MIN) ±0.014mV
BOP 50-20MG	0.01 Ohm	0V ±0.02mV	0.2V (MAX) -0.2V (MIN) ±0.02mV	0.2V (MAX) -0.2V (MIN) ±0.10mV
BOP 72-14MG	0.01 Ohm	0V ±0.014mV	0.14V (MAX) -0.14V (MIN) ±0.014mV	0.14V (MAX) -0.14V (MIN) ±0.07mV
BOP 100-10MG	0.01 Ohm	0V ±0.01mV	0.1V (MAX) -0.1V (MIN) ±0.01mV	0.1V (MAX) -0.1V (MIN) ±0.05mV
REFER TO NOTES FOR SENSE RESISTOR VALUE OTHER THAN LISTED HERE	R <sub>SENSE</sub> SEE NOTE.	SEE NOTE A.	SEE NOTE B.	SEE NOTE C.
USE SPACE PROVIDED AT RIGHT FOR CALCULATED VALUES.				

NOTES: The following formulas are used to calculate proper calibration values for Sense Resistors other than those recommended.

 $\mathbf{R}_{\mathrm{SENSE}}$  = the measured value of the sense resistor in ohms (0.001% accuracy).

I<sub>Onom</sub> = Nominal (rated) current output of BOP in Amperes (e.g., for BOP 50-20M, I = 20A)

A. 0V, Tolerance =  $\pm$  (R<sub>SENSE</sub>) x (0.1) x (I<sub>Onom</sub>) -- result in mV.

B.  $(\mathbf{R}_{SENSE}) \times (\mathbf{I}_{Onom})$  --result in V, Tolerance =  $\pm (\mathbf{R}_{SENSE}) \times (0.1) \times (\mathbf{I}_{Onom})$  --result in mV.

B.  $(\mathbf{R}_{\text{SENSE}}) \times (\mathbf{I}_{\text{Onom}})$  --result in V, Tolerance =  $\pm (\mathbf{R}_{\text{SENSE}}) \times (0.5) \times (\mathbf{I}_{\text{Onom}})$  --result in mV.

#### 4.3.1 CALIBRATION PROCEDURE USING SCPI COMMANDS

The following procedure provides a complete calibration of the unit. Steps 14 and 15 calibrate the control signal used when the unit is a slave in series configurations. Steps 29 and 30 calibrate the control signal used when the unit is a master in parallel configurations. Steps 31 and 32 calibrate the control signal used when the unit is a slave in parallel configurations. There is no need for a special calibration step when the unit is used as a master in series configurations since the BOP output voltage (which is calibrated by this procedure) is used to control the next unit in series.

NOTES: 1. For ZERO calibration, adjust output to obtain value closest to zero.

- 2. For FULL SCALE calibration adjust the output to obtain the closest value above the nominal full scale value.
- 3. Set the unit for local sensing with GND Network in (see Figure 4-1) and disconnect load from BOP output to prepare the unit for voltage calibration.




FIGURE 4-1. CALIBRATION SETUP

- Initiate calibration by sending the SCPI command SYSTem:PASSword:CENable DEFAULT
  and then send CAL:STATe 1. The password DEFAULT has been set at the factory. If the
  password has been changed from DEFAULT, substitute the correct password for the unit in
  the SYST:PASS:CEN command. If the password has been lost, consult factory.
- 2. Set the BOP to zero volts output by sending CAL: VOLT ZERO. Connect a Digital Voltmeter (DVM) to the BOP OUT S and COM S terminals to measure the output voltage. Send CAL: DATA commands as needed (see PAR. 4.3c) to adjust the BOP output until the DVM reads as close to zero as possible within tolerance specified in Table 4-3 for VOLTAGE ZERO.
- 3. Set the BOP to maximum positive output voltage by sending CAL: VOLT MAX. Measure the voltage output using the DVM. To adjust, send CAL: DATA commands as needed (see PAR. 4.3b) until the DVM reading is as close as possible above the nominal full scale value within the tolerance specified in Table 4-3 for +FULL SCALE VOLTAGE.
- 4. Set the BOP to maximum negative output voltage by sending CAL: VOLT MIN. To adjust, send the CAL: DATA command as needed (see PAR. 4.3b) until the reading is as close as possible above (absolute value) the nominal full scale value within the limits specified in Table 4-3 for –FULL SCALE VOLTAGE.
- 5. Send CAL: VPR MAX to adjust the maximum positive voltage protection limit of the power supply. Send the CAL: DATA commands as needed (see PAR. 4.3c) until the reading is as close as possible above the nominal full scale value within the limits specified in Table 4-3 for +FULL SCALE VPR LIMIT.
- 6. Send CAL: VPR MIN to adjust the maximum negative protection limit of the power supply. Send the CAL: DATA commands as needed (see PAR. 4.3c) until the reading is as close as possible above (absolute value) the nominal full scale value within the limits specified in Table 4-3 for –FULL SCALE VPR LIMIT.

4-6 BOP-1K 022108

- 7. Connect a 0V ±0.1mV d-c reference to pin 11 (EXT\_REF) referenced to pin 4 (SGND) of the Analog I/O Port connector (A2A5J6). Set the BOP to zero volts output by sending CAL: VEXT ZERO. Connect the DVM to the BOP output and send CAL: DATA commands as needed (see PAR. 4.3c) to adjust the BOP output until the DVM reads as close to zero as possible within tolerance specified in Table 4-3 for VOLTAGE ZERO.
  - NOTE: Accuracy of the 10V d-c reference must be  $\pm 0.1$ mV in order for the calibrated unit to meet published specifications.
- 8. Replace 0V reference at pin 11 (EXT\_REF) of the Analog I/O Port connector (A2A5J6) with a +10V d-c reference. Set the BOP to maximum positive output voltage by sending CAL:VEXT MAX. Measure the voltage output using the DVM. To adjust, send CAL:DATA commands as needed (see PAR. 4.3b) until the DVM reading is as close as possible above the nominal full scale value within the tolerance specified in Table 4-3 for +FULL SCALE VOLTAGE.
- 9. Replace +10V reference at pin 11 (EXT\_REF) of the Analog I/O Port connector (A2A5J6) with a 0V ±0.1mV d-c reference. Set the BOP to zero volts output by sending CAL:VGA ZERO. Connect DVM to the BOP OUT S and OUT COM terminals to measure the output voltage. Send CAL:DATA commands as needed (see PAR. 4.3c) to adjust the BOP output until the DVM reads as close to zero as possible within tolerance specified in Table 4-3 for VOLTAGE ZERO.
- 10. Replace 0V reference at pin 11 (EXT\_REF) of the Analog I/O Port connector (A2A5J6) with a +10V d-c reference. Set the BOP to maximum positive output voltage by sending CAL:VGA MAX. Measure the output voltage using the DVM. To adjust, send CAL:DATA commands as needed (see PAR. 4.3b) until the DVM reading is as close to zero as possible within tolerance specified in Table 4-3 for VOLTAGE ZERO.
- 11. Set the BOP to zero volts output by sending CAL:VLIM ZERO. Disconnect the +10V d-c reference voltage from the analog I/O port external reference pin (A2A5J6 pin 11) of the BOP, then connect 0V ±0.1mV d-c reference voltage from the external voltage source to VLIM+\_EXTERNAL and VLIM-\_EXTERNAL (pins 14 and 6) referenced to pin 12 (GND1) of the BOP analog I/O connector (A2A5J6), then send the CAL:ZERO command. This enables the BOP to recognize that the voltage at the VLIM\_EXTERNAL pins is 0V.
- 12.Connect +10.0V ±0.1mV d-c reference voltage from the external voltage source to VLIM+\_EXTERNAL and VLIM-\_EXTERNAL (pins 14 and 6) referenced to pin 12 (GND1) of the BOP analog I/O connector (A2A5J6), then send CAL:VLIM MAX, then CAL:ZERO commands. This enables the BOP to recognize that the voltage at the VLIM+\_EXTERNAL pin is 10.0V.
- 13. Set the BOP to minimum (maximum negative) output by sending CAL: VLIM MIN, then send the CAL: ZERO command. This enables the BOP to recognize that the voltage at the VLIM\_EXTERNAL pin is 10.0V.
- 14. Connect a 0V ±0.1mV d-c reference to pin 8 (S\_IN\_SERIAL) of the PAR/SER CONTROL IN connector (A2A5J3) referenced to COM S terminal at the rear panel (use mating connector supplied with the unit, P/N 142-0488 to gain access to PAR/SER CONTROL IN connector pins). Set the BOP to zero volts output by sending CAL:SER ZERO. Connect the DVM to the BOP OUT S and OUT COM terminals and send CAL:DATA commands as needed (see PAR. 4.3b) to adjust the BOP output until the DVM reads as close to zero as possible within tolerance specified in Table 4-3 for VOLTAGE ZERO.

- NOTE: Accuracy of the 10V d-c reference must be ±0.1mV in order for the calibrated unit to meet published specifications.
- 15. Connect a -10V ±0.1mV d-c reference to pin 8 (S\_IN\_SERIAL) of the PAR/SER CONTROL IN connector (A2A5J3) referenced to COM S terminal at the rear panel. Set the BOP to maximum positive output voltage by sending CAL:SER MAX. Measure the voltage output using the DVM. Send CAL:DATA commands as needed (see PAR. 4.3a) until the DVM reading is as close as possible to +10V.
- 16. Send CAL: ZERO to prepare for current calibration. After sending the command, the BOP output will be set to zero volts. Refer to Figure 4-2 to connect the C terminals of the Kelvin type sense resistor to the BOP and connect the DVM to the P (probe) terminals of the sense resistor ((LO terminal of DVM to common P terminal). Table 4-4 provides recommended sense resistor values for various BOP current outputs, as well as the formula for calculating expected measured values and tolerances for any sense resistor other than those recommended. Table 4-2 lists Kepco and Manufacturer part numbers for those sense resistors recommended.



The sense resistor will be dissipating full rated current of the BOP. If it is hot to the touch, the sense resistor value, power rating and/or cooling are incorrect; refer to PAR. 4.3 and Table 4-2.




FIGURE 4-2. CURRENT SHUNT (SENSE RESISTOR) CONNECTIONS

17.Set the BOP to zero volts across the sense resistor (corresponding to zero current) by sending CAL:CURR ZERO. Send CAL:DATA commands as needed (see PAR. 4.3a) until the reading is as close to zero as possible within the limits specified in Table 4-4 for CURRENT ZERO.

4-8 BOP-1K 022108

- 18. Set the BOP to maximum positive output current by sending CAL:CURR MAX. Measure the current by reading the voltage across the sense resistor. To adjust, send CAL:DATA commands as needed (see PAR. 4.3b) to adjust the BOP output until the DVM reads as close as possible above the nominal full scale value within tolerance specified in Table 4-4 for +FULL SCALE CURRENT.
- 19. Set the BOP to maximum negative output current by sending CAL:CURR MIN. Continue to measure the output current of the supply using the DVM connected to the sense resistor. To adjust, send CAL:DATA commands as needed (see PAR. 4.3b) to adjust the BOP output until the DVM reads as close as possible above (absolute value) the nominal full scale value within tolerance specified in Table 4-4 for –FULL SCALE CURRENT.
- 20. Send CAL:CPR MAX to adjust the maximum positive current protection limit of the power supply. To adjust, send CAL:DATA commands as needed (see PAR. 4.3c) to adjust the BOP output until the DVM reads as close as possible above the nominal full scale value within tolerance specified in Table 4-4 for +FULL SCALE CPR LIMIT.
- 21.Send CAL:CPR MIN to adjust the minimum (maximum negative) current protection limit of the power supply. To adjust, send CAL:DATA commands as needed (see PAR. 4.3c) to adjust the BOP output until the DVM reads as close as possible above (absolute value) the nominal full scale value within tolerance specified in Table 4-4 for –FULL SCALE CPR LIMIT.
- 22. Send CAL: ZERO to set the BOP output to zero. Connect 0V ±0.1mV d-c reference voltage to external reference pin 11 referenced to pin 4 (SGND) of the BOP analog I/O port (A2A5J6). Set the BOP to zero volts across the sense resistor (corresponding to zero current) by sending CAL:CEXT ZERO. Send CAL:DATA commands as needed (see PAR. 4.3a) until the reading is as close to zero as possible within the limits specified in Table 4-4 for CURRENT ZERO.
- 23. Replace the 0V d-c reference applied to analog I/O port A2A5J6 pin 11 with a +10V ±0.1mV d-c reference voltage. Set the BOP to maximum positive output current by sending CAL:CEXT MAX. Measure the current by reading the voltage across the sense resistor. To adjust, send CAL:DATA commands as needed (see PAR. 4.3b) to adjust the BOP output until the DVM reads as close as possible above the nominal full scale value within tolerance specified in Table 4-4 for +FULL SCALE CURRENT.
- 24. Replace the +10V d-c reference applied to analog I/O port A2A5J6 pin 11 with a 0V ±0.1mV d-c reference voltage. Set the BOP to zero volts across the sense resistor (corresponding to zero current) by sending CAL:CGA ZERO. Send CAL:DATA commands as needed (see PAR. 4.3a) until the reading is as close to zero as possible within the limits specified in Table 4-4 for CURRENT ZERO.
- 25. Replace the 0V d-c reference applied to analog I/O port A2A5J6 pin 11 with a +10V ±0.1mV d-c reference voltage. Set the BOP to maximum positive output current by sending CAL:CGA MAX. Measure the current by reading the voltage across the sense resistor. To adjust, send CAL:DATA commands as needed (see PAR. 4.3b) to adjust the BOP output until the DVM reads as close as close to zero as possible within the limits specified in Table 4-4 for CURRENT ZERO.
- 26. Set the BOP to zero amperes output by sending CAL:CLIM ZERO., then connect 0V ±0.1mV d-c reference voltage from the external voltage source to ILIM+\_EXTERNAL and ILIM-\_EXTERNAL pins, pins 5 and 13, referenced to pin 12 (GND1) of the BOP analog I/O

- connector (A2A5J6). Then send the **CAL:ZERO** command. This enables the BOP to recognize that the voltage at the ILIM\_EXTERNAL pins is 0V.
- 27.Connect +10.0V ±0.1mV d-c reference voltage from the external voltage source to ILIM+\_EXTERNAL and ILIM-\_EXTERNAL, pins 5 and 13, referenced to pin 12 (GND1) of the BOP analog I/O connector (A2A5J6). Then send CAL:CLIM MAX, then CAL:ZERO commands. This enables the BOP to recognize that the voltage at the ILIM+\_EXTERNAL pin is 10.0V.
- 28. Set the BOP to minimum (maximum negative) output by sending CAL:VLIM MIN, then send the CAL:ZERO command. This enables the BOP to recognize that the voltage at the VLIM\_EXTERNAL pin is 10.0V.
- 29. Send CAL: ZERO to prepare for calibration of IOUT\_M\_UNIT (master output) control signal. Connect the DVM to pin 6 (IOUT\_M\_UNIT) referenced to pin 1 (SGND) of the PAR/SER CONTROL IN connector (A2A5J3). Set the BOP to zero output current by sending CAL:IOUT ZERO. Send CAL:DATA commands as needed (see PAR. 4.3b) to adjust the BOP output until the DVM reads 0V ±1mV.
- 30. Set the BOP to maximum positive output current by sending CAL: IOUT MAX. With the DVM still connected to pin 6 (IOUT\_M\_UNIT) referenced to pin 1 (SGND) of the PAR/SER CONTROL IN connector measure the voltage output using the DVM. Send CAL: DATA commands as needed (see PAR. 4.2.1a) until the DVM reading is +10V ±1.0mV.
- 31.Send CAL:ZERO to prepare for calibration of S\_IN\_PARALLEL (slave input) control signal. Connect a 0V ±0.1mV d-c reference to pin 3 (S\_IN\_PARALLEL) referenced to pin 1 (SGND) of the PAR/SER CONTROL IN connector (A2A5J3). Set the BOP to zero output current by sending CAL:PAR ZERO. Connect the DVM across the sense resistor to measure the BOP output current and send CAL:DATA commands as needed (see PAR. 4.3b) to adjust the BOP output current until the DVM reads as close to zero as possible within tolerance specified in Table 4-4 for CURRENT ZERO.
- NOTE: Accuracy of the 10V d-c reference must be ±0.1mV in order for the calibrated unit to meet published specifications.
- 32.Connect a +10V ±0.1mV d-c reference to pin 3 (S\_IN\_PARALLEL) referenced to pin 1 (SGND) of the PAR/SER CONTROL IN connector (A2A5J3). Set the BOP to maximum positive output current by sending CAL:PAR MAX. Measure the output current using the DVM. Send CAL:DATA commands as needed (see PAR. 4.3a) until the DVM reading is as specified in Table 4-3 for +FULL SCALE CURRENT.
- 33. Save the calibration levels by sending **CAL:SAVE 12/21/2003**. The characters at the end are optional and represent the calibration date of the power supply. The date entered in this manner is reported in the **\*idn?** query.

#### 4.4 CALIBRATION USING FRONT PANEL KEYPAD IN LOCAL MODE


The following paragraphs describe the screens and keys used in the calibration process.

#### 4.4.1 UNDERSTANDING THE CALIBRATION PROCESS

The following steps describe the calibration screens, and associated keys active during the calibration process. Refer to PAR. 4.4.2 for full calibration procedure.

4-10 BOP-1K 022108

- 1. From the power-up screen, press [5] to enter the General Setup menu, then highlight Calibration and press [7].
- 2. Enter the password (see PAR. 3.2.4.4), and press [1], The LCD shows main calibration screen (Figure 4-3) which includes explanations for the following function keys:
  - F1 VOLTAGE Selects the voltage calibration of the BOP.
  - [2] CURRENT Starts the calibration for the BOP in current mode.
  - F3 EXTRL CONTROLS Selects input and output signal calibration used for multiple units and the external protection.
  - F1 SAVE Save New Calibration Setting. The information in the DATE field is saved with the Calibration.
  - F5 or ENTER EXIT



3042519-3

### FIGURE 4-3. MAIN CALIBRATION SCREEN

- 3. Press either or calibrate Voltage or Current calibration, respectively. To calibrate multiple units refer to the Instruction Manual Included with the associated parallel or series connection cable kit. The LCD shows the explanations for the following function keys:
  - Internal Selects the voltage calibration of the BOP.
  - [2] GAIN Starts the calibration of the external gain mode of the power supply.
  - F3 EXTERNAL Starts the external reference calibration.
  - PROTECT Starts the protection limits calibration of the power supply.

- F5 or ENTER EXIT Exit Voltage or Current Calibration
- 4. Pressing [1], [2], [3], or [4] displays following explanations for the function keys:

# CAUTION: IF THE CALIBRATE ZERO FUNCTION IS AVAILABLE, PERFORM THIS FUNCTION FIRST, AS IT AFFECTS ALL OTHER OUTPUT CALIBRATIONS.

- Calibrate the Zero adjustment for this operational mode. IF THIS FUNCTION IS AVAILABLE, PERFORM THIS FUNCTION FIRST, AS IT AFFECTS ALL OTHER OUT-PUT calibrations.
- F2 Adjust the MAXIMUM (Positive) for this operational mode.
- F3 Adjusts the MINIMUM (Negative) for this operational mode
- PROTECT Adjusts External Protection limits. (Active for EXTERNAL screen only.)
- F5 or **ENTER** to exit this menu.
- 5. Selecting one of the above options begins calibrating the output. The screen describes the function of the active keys:
  - Fig. or clockwise rotation of the **ADJUST** control adjust the output by approximately 10 increments in the positive direction.
  - P2 or clockwise rotation of the **ADJUST** control while ppressed adjusts the output by one increment in the positive direction.
  - F3 or counterclockwise rotation of the **ADJUST** control adjusts the output by 10 increments in the negative direction.
  - [4] or counterclockwise rotation of the **ADJUST** control adjust the output by approximately 10 increments in the negative direction.
  - F5 Exits the active calibration and allows you to select other calibrations that are required.
  - [1] Increments the output D to A by 100, causing the output to increase.
  - **!** Decrements the output D to A by 100, causing the output to decrease.

## 4.4.2 CALIBRATION PROCEDURE USING LOCAL MODE

NOTES: 1. For ZERO calibration, adjust output to obtain value closest to zero.

- 2. For FULL SCALE calibration adjust the output to obtain the closest value above (absolute value) the nominal full scale value.
- 3. Set the unit for local sensing with GND Network in (see Figure 4-1) and disconnect load from BOP output.
- 4. When adjustment is needed refer to PAR. 4.4.1, step 5.

4-12 BOP-1K 022108

- 1. From the power-up screen, press to enter the General Setup menu, then highlight Calibration and press . Enter the password (see PAR. 3.2.4.4), and press . The LCD shows main calibration screen.
- 2. Press [ VOLTAGE, [ INTERNAL, [ 2 ZERO to set the BOP to zero volts output. Connect a Digital Voltmeter (DVM) to the BOP OUT S and COM S terminals to measure the output voltage. Adjust the BOP output as needed until the DVM reads as close to zero as possible within tolerance specified in Table 4-3 for VOLTAGE ZERO. Press [ 5 ] once.
- 3. Press [2] POSITIVE. Measure the voltage output using the DVM. Adjust as needed until the DVM reading is as close as possible above the nominal full scale value within the tolerance specified in Table 4-3 for +FULL SCALE VOLTAGE. Press [5] once.
- 4. Press [3] NEGATIVE to set the BOP to maximum negative output voltage and adjust as needed until the reading is as close as possible above the nominal full scale value within the limits specified in Table 4-3 for –FULL SCALE VOLTAGE. Press [5] twice.
- 5. Press [4] PROTECT, [2] POSITIVE to adjust the maximum positive voltage protection limit of the power supply while working in current mode. Adjust as needed until the reading is as close as possible above the nominal full scale value within the limits specified in Table 4-3 for +FULL SCALE VPR LIMIT. Press [5] once.
- 6. Press [3] NEGATIVE to adjust the maximum negative protection limit of the power supply. Adjust as needed until the reading is as close as possible above the nominal full scale value within the limits specified in Table 4-3 for –FULL SCALE VPR LIMIT. Press [5] three times.
- 7. Press [3] EXTRL CONTROLS, [4] EXTERN PROTECT, [7] ZERO to set the BOP to zero volts output. Connect 0V ±0.1mV d-c reference voltage from the external voltage source to the following pins of analog I/O connector (A2A5J6) referenced to pin 12 (GND1): VLIM+\_EXTERNAL (pin 14), VLIM-\_EXTERNAL (pin 6), ILIM+\_EXTERNAL (pin 13), ILIM-\_EXTERNAL (pin 5). Then press [7] ZERO. This enables the BOP to recognize that the voltage at the four \_EXTERNAL pins (14, 6, 13, and 5) is 0V. Press [7] once.
  - NOTE: Accuracy of the 10V d-c reference must be ±0.1mV in order for the calibrated unit to meet published specifications.
- 8. Replace 0V ±0.1mV d-c reference voltage at pins 14, 6, 13, and 5 with +10.0V ±0.1mV d-c reference voltage from the external voltage source referenced to pin 12 (GND1) of the analog I/O connector (A2A5J6), then press - MAXIMUM. This enables the BOP to recognize that the voltage at the four \_EXTERNAL pins (14, 6, 13, and 5) is 10.0V. Then press three times.
- 9. Disconnect +10.0V d-c reference voltage from pins 14, 6, 13 and 6 of analog I/O connector (A2A5J6). Connect a +0V ±0.1mV d-c reference voltage to EXT\_REF, pin 11, referenced to pin 12 (GND1), of the BOP analog I/O port (A2A5J6).
- 10. Press [1] VOLTAGE, [3] EXTERNAL, [1] ZERO to set the BOP to zero volts output. Adjust as needed until the DVM reads as close to zero as possible within the limits specified in Table 4-4 for VOLTAGE ZERO. Press [5] twice.
- 11. Press [2] GAIN, [7] ZERO to set the BOP to zero volts output. Adjust as needed until the DVM reads as close to zero as possible within the limits specified in Table 4-4 for VOLTAGE ZERO. Press [5] twice.

- 12.Connect +10.0V ±0.1mV d-c reference voltage from the external voltage source to EXT\_REF, pin 11, referenced to pin 4 (SGND) of Analog I/O Port connector (A2A5J6), Press F2 GAIN, F2 POSITIVE. Adjust as needed until the DVM reads as close to zero as possible within the limits specified in Table 4-3 for VOLTAGE ZERO. Press F5 twice.
- 13. Press [3] EXTERNAL, [2] POSITIVE. Adjust as needed until the DVM reads as close as possible above the nominal full scale value within tolerance specified in Table 4-3 for +FULL SCALE VOLTAGE. Press [5] three times.
- 14. Connect a 0V ±0.1mV d-c reference to pin 8 (S\_IN\_SERIAL) of the PAR/SER CONTROL IN connector (A2A5J3) referenced to pin 1 (use mating connector supplied with the unit, P/N 142-0488 to gain access to PAR/SER CONTROL IN connector pins). Press 3 EXTERNAL CONTROLS, 2 SERIES, and 1 ZERO to set the BOP output to zero volts. Adjust as needed until DVM reads within tolerance specified in Table 4-3 for VOLTAGE ZERO. Press 5 once when done.
- 15.Connect a -10.0V ±0.1mV d-c reference to pin 8 (S\_IN\_SERIAL) of the PAR/SER CONTROL IN connector (A2A5J3) referenced to pin 1. Press [2] POSITIVE to set the BOP to +10.0V output. Adjust as needed until DVM reads as close as possible to +10V. Press [5] three times when done.
- 16. Refer to Figure 4-2 to connect the C terminals of the Kelvin type sense resistor to the BOP and connect the DVM to the P (probe) terminals of the sense resistor ((LO terminal of DVM to common P terminal). Table 4-4 provides recommended sense resistor values for various BOP current outputs, as well as the formula for calculating expected measured values and tolerances for any sense resistor other than those recommended. Table 4-2 lists Kepco and Manufacturer part numbers for those sense resistors recommended.



The sense resistor will be dissipating full rated current of the BOP. If it is not to the touch, the sense resistor value, power rating and/or cooling are incorrect; refer to PAR. 4.4 and Table 4-2.

- 17. Press [2] CURRENT, [1] INTERNAL, [1] ZERO to set the BOP to zero volts across the sense resistor (corresponding to zero current). Adjust as needed until the reading is as close to zero as possible within the limits specified in Table 4-4 for CURRENT ZERO. Press [5] once.
- 18. Press [2] POSITIVE to set the BOP to maximum positive output current. Measure the current by reading the voltage across the sense resistor. Adjust as needed until the DVM reads as close as possible above the nominal full scale value within tolerance specified in Table 4-4 for +FULL SCALE CURRENT. Press [5] once.
- 19. Press [3] NEGATIVE to set the BOP to maximum negative output current. Continue to measure the output current of the supply using the DVM connected to the sense resistor. Adjust as needed until the DVM reads as close as possible above the nominal full scale value within tolerance specified in Table 4-4 for –FULL SCALE CURRENT. Press [5] twice.
- 20. Press [4] PROTECT, [2] POSITIVE to set to adjust the maximum positive current protection limit of the power supply in voltage mode. Adjust as needed until the DVM reads as close as possible above the nominal full scale value within tolerance specified in Table 4-4 for +FULL SCALE CPR LIMIT. Press [5] once.

4-14 BOP-1K 022108

- 21. Press [3] NEGATIVE to adjust the minimum (maximum negative) current protection limit of the power supply. Adjust as needed until the DVM reads as close as possible above the nominal full scale value within tolerance specified in Table 4-4 for –FULL SCALE CPR LIMIT. Press [5] twice.
- 22. Connect a +0V ±0.1mV d-c reference voltage to external reference, A2A5J6 pin 11, referenced to pin 12 (GND1) of the BOP analog I/O port.
- 23. Press [3] EXTERNAL, [1] ZERO to set the BOP to zero volts across the sense resistor (corresponding to zero current). Adjust as needed until the DVM reads as close to zero as possible within the limits specified in Table 4-4 for CURRENT ZERO. Press [5] twice.
- 24. Press [2] GAIN, [1] ZERO to set the BOP to zero volts across the sense resistor (corresponding to zero current). Adjust as needed until the DVM reads as close to zero as possible within the limits specified in Table 4-4 for CURRENT ZERO. Press [5] twice.
- 25. Connect +10.0V ±0.1mV d-c reference voltage from the external voltage source to External reference, pin 11, referenced to pin 4 (SGND) of the BOP Analog I/O Port connector (A2A5J6), Press [2] GAIN, [2] POSITIVE. Measure the current by reading the voltage across the sense resistor. Adjust as needed until the DVM reads as close to zero as possible within the limits specified in Table 4-4 for CURRENT ZERO. Press [5] twice.
- 26.Press EXTERNAL, POSITiVE. Measure the current by reading the voltage across the sense resistor. Adjust as needed until the DVM reads as close as possible above the nominal full scale value within tolerance specified in Table 4-4 for +FULL SCALE CURRENT. Press + three times.
- 27.Connect the DVM to pin 6 (IOUT\_M\_UNIT) referenced to pin 1 (SGND) of the PAR/SER CONTROL IN connector (A2A5J3). Press 3 EXTRL CONTROLS, 1 lout, and 1 ZERO to set the BOP output current to zero. Adjust as needed until DVM reads 0V ±1mV d-c. Press 5 once.
- 28.Press [2] POSITIVE. With DVM still connected to pin 6 (IOUT\_M\_UNIT) referenced to pin 1 (SGND) of the PAR/SER CONTROL IN connector, adjust as needed until DVM reads +10V ±1mV d-c. Press [5] twice.
- 29. Connect a 0V ±0.1mV reference to pin 3 (S\_IN\_PARALLEL) referenced to pin 1 (SGND) of the PAR/SER CONTROL IN connector (A2A5J3). Press [3] PARALLEL, and [7] ZERO to set the BOP output current to zero. Connect DVM across the sensing resistor. Adjust as needed until DVM reads as close to zero as possible within tolerance specified in Table 4-4 for CURRENT ZERO. Press [5] once.
- NOTE: Accuracy of the +10V d-c reference must be ±0.1mV d-c in order for the calibrated unit to meet published specifications.
- 30.Connect a +10.0V ±0.1mV d-c reference to pin 3 (S\_IN\_PARALLEL) of the PAR/SER CONTROL IN connector (A2A5J3). Press [2] POSITIVE to set the BOP to maximum output current. Adjust as needed until DVM reads as close as possible above the nominal full scale value within tolerance specified in Table 4-4 for +FULL SCALE CURRENT. Press [5] three times.
- 31. Save the calibration levels by first using the keys or the **ADJUST** control to enter data such as the calibration date, e.g., **12/21/2004** in the ASCII area of the display. The date entered in this manner is reported in the \*idn? query. Then press [4] SAVE.

#### 4.4.3 CALIBRATION USING VISA DRIVER SOFT PANEL

Refer to help text included with VISA Driver. Calibration of series-connected or parallel-connected configurations is not supported by the demonstration program supplied with the VISA Driver soft panel, stand-alone calibrations may be performed using the VISA driver soft panel.

#### 4.5 CALIBRATION STORAGE

The BIOPO maintains the calibration tables in Flash Memory until a PACK is executed. There are six calibration areas maintained in Flash Memory: Working, Prior, Oldest, Factory, Master, and First.

The calibration can be copied to another area using the CAL:DUMP? and CAL:COPY command. The syntax is as follows: CAL:DUMP? [source];:CAL:COPY [destination], where [source] and [destination] refer to the areas of Flash memory where calibration data is stored, designated as: WORKing, PRIor, OLDest, FACTory, MASTer, FIRst. Source refers to the calibration area that is to be copied, destination to the area that the calibration will be copied into.

The ability to save to the FACTORY area is prohibited. If a user needs to overwrite the factory calibration, a special firmware needs to be created to provide a special password for this capability. Each customer that requests this capability will be provided a password that the company can specify. it must contain at least one alpha, one numeric and one punctuation character (!@#\$\%^\&\*) and be at least 6 characters long and not longer than 20 characters in length. All alpha data must be upper case and no control nor space characters are allowed.

The Master calibration should never be overwritten. Factory, Master, and First are set to the same values when the BOP is calibrated at the factory. The Working calibration is the active calibration. Each time a CAL:SAV is executed, the values are saved in the Working (active) area. At the same time, the values previously stored in Working are moved to Prior, and the values previously stored in Prior are moved to Oldest. The values previously stored in Oldest are no longer available. Table 4-5 illustrates calibration storage and the use of the CAL:DUMP? query and CAL:COPY command.

**TABLE 4-5. CALIBRATION STORAGE** 

COMMAND	WORKing	PRIor	OLDest	FACTory	MASTer	FIRst
1. CAL:SAVE	Cal 1 values			Factory cal.	Master cal.	First cal.
2. CAL:SAVE	Cal 2 values	Cal 1 values		No Change	No Change	No Change
3. CAL:SAVE	Cal 3 values	Cal 2 values	Cal 1 values	No Change	No Change	No Change
4. CAL:SAVE	Cal 4 values	Cal 3 values	Cal 2 values	No Change	No Change	No Change
5. CAL:DUMP? FACTory;:CAL:COPY WORKing	Factory cal.	Cal 4 values	Cal 3 values	No Change	No Change	No Change
6. CAL:DUMP? PRIor;:CAL:COPY WORKing	Cal 4 values	Factory cal.	Cal 4 values	No Change	No Change	No Change

4-16 BOP-1K 022108

## APPENDIX A - SCPI COMMON COMMAND/QUERY DEFINITIONS

#### **A.1** INTRODUCTION

This appendix defines the SCPI common commands and gueries used with the BOP power supply. Common commands and queries are preceded by an asterisk (\*) and are defined and explained in paragraphs A.2 through A.18, arranged in alphabetical order. Table A-1 provides a guick reference of all SCPI common commands and gueries used in the Interface Card.

TABLE A-1. IEEE 488.2 COMMAND/QUERY INDEX

COMMAND	PAR.	COMMAND	PAR.
*CLS	A.2	*RST	A.11
*ESE, ?	A.3, A.4	*SAV	A.12
*ESR?	A.5	*SRE, ?	A.13, A.14
*IDN?	A.6	*STB?	A.15
*OPC, ?	A.7, A.8	*TRG	A.16
*OPT?	A.9	*TST?	A.17
*RCL	A.10	*WAI	A.18

#### \*CLS — CLEAR STATUS COMMAND A.2

Syntax: \*CLS

Description: Clears status data. Clears the error queue of the instrument. Forces power supply to "operation complete idle" and "operation complete guery" state. Clears all Event Registers summarized in Status Byte Register without affecting the corresponding Enable Registers: Standard Event Status Register (ESR), Operation Status Event Register, Questionable Status Event Register, and Status Byte Register (STB). Related commands: \*OPC, \*OPC?. (See example, Figure A-1.)

#### A.3 \*ESE — STANDARD EVENT STATUS ENABLE COMMAND

\*ESE

\*ESE <integer> where <integer> = positive whole number: 0 to 255 per Table A-2. Syntax:

Default Value: 0

Description: This command programs the standard Event Status Enable register bits. The contents function as a mask to determine which events of the Event Status Register (ESR) are allowed to set the ESB (Event Summary Bit) of the Status Byte Register. Enables the Standard events to be summarized in the Status Byte register (1 = set = enable function, 0 = reset = disable function). All of the enabled events of the standard Event Status Enable register are logically ORed to cause ESB (bit 5) of the Status Byte Register to be set (1 = set = enable, 0 = reset = disable). (See example, Figure A-1.)

TABLE A-2. STANDARD EVENT STATUS ENABLE REGISTER AND STANDARD **EVENT STATUS REGISTER BITS** 

CONDITION	NU	NU	CME	EXE	DDE	QUE	NU	OPC
BIT	7	6	5	4	3	2	1	0
VALUE	128	64	32	16	8	4	2	1

NILI (Not Used) CME Command Error EXE **Execution Error** DDE Device Dependent Error QUE Query Error OPC Operation Complete

A-1 BIT 4886 022108

#### A.4 \*ESE? — STANDARD EVENT STATUS ENABLE QUERY

\*ESE?

Syntax: \*ESE? Return value: Integer> value per Table A-2.

Description: Returns the mask stored in the Standard Event Status Enable Register. Contents of Standard

Event Status Enable register (\*ESE) determine which bits of Standard Event Status register (\*ESR) are enabled, allowing them to be summarized in the Status Byte register (\*STB). All of the enabled events of the Standard Event Status Enable Register are logically ORed to cause ESB (bit 5) of the Status Byte Register to be set (1 = set = enable function, 0 = reset = disable function). (See example,

Figure A-1.)

### A.5 \*ESR? — EVENT STATUS REGISTER QUERY

\*ESR?

Syntax: \*ESR?

Return value: <integer> (Value = contents of Event Status register as defined in Table A-2.)

Description: Causes the power supply to return the contents of the Standard Event Status register. After it has been read, the register is cleared. The Standard Event Status register bit configuration is defined in Table A-2 (1 = set, 0 = reset). The error bits listed in Table A-2 are also related to error codes produced during parsing of messages and to errors in the power supply (see PAR. B.104)

- Any 1xx type error sets the Command error bit (5) see.
- Any 2xx type error sets the Execution error bit (4).
- Any 3xx type error sets the Device error bit (3). The Device error bit will be set when Current Error
  or Voltage Error is detected and the corresponding Status Questionable bit is set (see PAR. B.28).
- Any 4xx type error sets the Query error bit (2).

Related Commands: \*CLS, \*ESE, \*OPC. (See example, Figure A-1.)

#### A.6 \*IDN? — IDENTIFICATION QUERY

\*IDN?

Syntax: \*IDN?

Return value: Character string

Description: **Identifies the instrument.** This query requests identification. The power supply returns a string which contains the manufacturer name, the model, the serial number and the firmware level. The

which contains the manufacturer name, the model, the serial number and the firmware level. The character string contains the following fields: <Manufacturer>, <Model>, <Voltage>, <Current>, <Serial Number>, <Main revision>-<Flash revision> where: <Manufacturer> = KEPCO, <Model> = BOP 1000W, <Serial Number> = SSSSSS <date> = (string of up to 12 contiguous characters denoting

calibration date) <Main revision=n.m, e.g, 1.0) > (See example, Figure A-1.)

### A.7 \*OPC — OPERATION COMPLETE COMMAND

\*OPC

Syntax: \*OPC

Description: Causes power supply to set status bit 0 (Operation Complete) when pending operations are

complete This command sets Standard Event Status Register bit 0 (see Table A-2) to "1" when all previous commands have been executed and changes in output level have been completed. This command does not prevent processing of subsequent commands, but bit 0 will not be set until all pending operations are completed. (1 = set = enable function, 0 = reset = disable function). (See example, Figure A-1.) As an example, the controller sends command(s), then sends \*OPC. If controller then sends \*ESR?, the power supply responds with either a "0" (if the power supply is busy executing the programmed commands), or a "1" (if the previously programmed commands are complete). (See exam-

ple, Figure A-1.)

A.8 \*OPC? — OPERATION COMPLETE QUERY

\*OPC?

Syntax: \*OPC?

Return value: <1> (ASCII) placed in output queue when power supply has completed operation.

Description:

Indicates when pending operations have been completed. When all pending operations are complete (all previous commands have been executed and changes in output level have been completed) a "1" is placed in the Output Queue. Subsequent commands are inhibited until the pending operations are completed. \*OPC? is intended to be used at the end of a command line so that the application program can monitor the bus for data until it receives the "1" from the power supply Output Queue. (See example, Figure A-1.)

\*CLS Power supply clears status data.

\*ESE 60 Power supply enables bits 5, 4, 3 and 2, allowing command error, execution

error, device dependent error and guery error to set the Event Status

Summary bit when an STB command is executed.

\*ESE? Returns 60. (value of the mask) verifying that bits 5. 4. 3 and 2 are enabled.

\*ES Unknown command will set command error (Bit 5).

\*ESR? Returns 32 (bit 5 set), indicating Command Error has occurred since the last

time the register was read.

\*IDN? Power supply returns: KEPCO, BOP\_1000W 36-28 123456 1.43.
\*OPC Allows status bit 0 to be set when pending operations complete

VOLT 21;CURR 3 If unit is in voltage mode, sets output voltage to 21V, output current protection

limit to 3A.

\*ESR Returns 129 (128 + 1, power on, bit 7 = 1, operation complete, bit 1 = 1).

\*ESR Returns 0 (event status register cleared by prior \*ESR?).

VOLT 15; CURR 5; \*OPC? Sets output voltage to 15V, output current protection limit to 5A, puts "1" on

output bus when command operations are complete.

\*RST Power supply reset to power on default state.

\*SRE 40 When ESB or QUES bits are set (Table A-3), the Request for Service bit will

be set.

\*SRE? Returns the value of the mask (40).

\*STB? For example, the Power supply responds with 96 (64 + 32) if MSS and the

Event Status Byte (Table A-3) summary bit have been set. The power

supply returns 00 if no bits have been set.

OUTP ON Programmed voltage will be applied to output terminals.

VOLT 25 Power supply voltage commanded to 25V.

VOLT:TRIG 12 Programs power supply voltage to 12V when \*TRG received.

INIT Trigger event is initialized.

\*TRG Power supply reverts to commanded output voltage of 12V.

\*\* LOAD DISCONNECTED

\*TST? Power supply executes self test and responds with 0 if test completed

successfully, with 1 if test failed.

FIGURE A-1. GPIB COMMANDS

BIT 4886 022108 A-3

#### A.9 \*OPT? — OPTIONS QUERY

\*OPT?

Syntax: \*OPT?

Returns string determined by power supply model.

Description: Causes the power supply to return an ASCII string which defines the functionality of the power

supply. The functionality is defined as follows:

STRING DATA	MEANING
CAL	Support for CALibrate is present.
RL1	Commands sent over GPIB cause unit to enter remote mode.
MEM	Indicates the number of memory steps supported.
LST	Indicates the number of LIST steps supported.

#### A.10 \*RCL — RECALL COMMAND

\*RCL

Syntax: \*RCL <integer> (1 to 99)

Description: Restores power supply to previously defined levels of output voltage, output current and trig-

**gers.** This command selects one of the 99 power supply memory locations, each of which stores values for output current and output voltage. Executing a \*RCL recalls the stored settings (see \*SAV, PAR. A.12, for details) from the specified location (whether stored locally or using SCPI commands)

and applies them to the unit.

#### A.11 \*RST — RESET COMMAND

\*RST

Syntax: \*RST

Description: Resets power supply to the power on default state. The power supply output set to power-on default state (see PAR 3.3.7). The factory settings for power on default are: output set to off and the

default state (see PAR. 3.3.7). The factory settings for power-on default are: output set to off and the power supply is programmed as follows: CURR[:LEV][:IMM] = 0, VOLT[:LEV][:IMM] = 0, MODE = VOLT for all load types (except battery where MODE = CURR). A front panel setting and the load type influence how the unit responds to this command; refer to PAR. 3.5.3.1.3 and Table 3-17 for details. After sending \*RST it is necessary to send OUTPut ON for programmed values to appear at

the output.

#### A.12 \*SAV — SAVE COMMAND

\*SAV

Syntax: \*SAV <integer> (1 to 99)

Description: Saves the present state of output voltage, output current and trigger values, to the specified memory location. This command stores the present state of the power supply to one of 99 memory locations in Flash Memory (see PAR. 3.6.3.7). The following parameters are stored by \*SAV: FUNC:MODE, VOLT:MODE, CURR:MODE, CURR:LIM, VOLT:LIM, VOLT:PROT, and CURR:PROT.

Settings stored are:

• Mode of operation (voltage or Current) FUNC:MODE <>

Main channel reference type (internal or external) and setting (if internal)
 VOLT:MODE <> or CURR:MODE <>, VOLT <> or CURR <>

- Protection channel reference type (internal or external) and setting (if internal)
   VOLT:PROT:MODE <> or CURR:PROT:MODE <>, VOLT <> or CURR <>
- Output status (on or off) OUTP < >

The stored values can be restored by the \*RCL command. See PAR. 3.5.2.2 and Figure 3-16 for special programming considerations.

### A.13 \*SRE — SERVICE REQUEST ENABLE COMMAND

\*SRE

Syntax: \*SRE<integer> where <integer> = value from 0 - 255 per Table A-3, except bit 6 cannot be pro-

grammed.

Description: Sets the condition of the Service Request Enable register. The Service Request Enable register

determines which events of the Status Byte Register are summed into the MSS (Master Status Summary) and RQS (Request for Service) bits. RQS is the service request bit that is cleared by a serial poll, while MSS is not cleared when read. A "1" (1 = set = enable, 0 = reset = disable) in any Service Request Enable register bit position enables the corresponding Status Byte bit to set the RQS and MSS bits. All the enabled Service Request Enable register bits then are logically ORed to cause Bit 6 of the Status Byte Register (MSS/RQS) to be set. Related Commands: \*SRE?, \*STB?. (See exam-

ple, Figure A-1.)

### TABLE A-3. SERVICE REQUEST ENABLE AND STATUS BYTE REGISTER BITS

CONDITION	OPER	MSS RQS	ESB	MAV	QUES	ERR QUE	NU	NU
BIT	7	6	5	4	3	2	1	0
VALUE	128	64	32	16	8	4	2	1

OPER MSS RQS ESB MAV QUES ERR QUE Operation Status Summary Master Status Summary Request for Service Event Status Byte summary Message available QUEStionable Status Summary 1 or more errors occurred (see PAR. B.104) (Not Used)

### A.14 \*SRE? — SERVICE REQUEST ENABLE QUERY

\*SRE?

Syntax: \*SRE? Response: <integer> = value from 0 - 255 per Table A-3.

Description: **Reads the Service Enable Register.** Used to determine which events of the Status Byte Register are programmed to cause the power supply to generate a service request (1 = set = function enabled, 0 =

reset = function disabled). Related Commands: \*SRE, \*STB? (See example, Figure A-1.)

### A.15 \*STB? — STATUS BYTE REGISTER QUERY

\*STB?

Syntax: \*STB? Response: <integer> value from 0 to 255 per Table A-3.

Description: Reads Status Byte Register without clearing it. This Query reads the Status Byte Register (bit 6 = MSS) without clearing it (1 = set = function enabled, 0 = reset = function disabled). The register is cleared only when subsequent action clears all set bits. MSS is set when the power supply has one ore more reasons for requesting service. (A serial poll also reads the Status Byte Register, except that bit 6 = RQS, not MSS; and RQS will be reset.) Related Commands: \*SRE, \*SRE?. (See example, Figure A-1.)

### A.16 \*TRG — TRIGGER COMMAND

\*TRG

Syntax: \*TRG

Description: Triggers the power supply to be commanded to preprogrammed values of output current and

**voltage.** When the trigger is armed (checked by examining WTG bit in Status Operational Condition register) \*TRG generates a trigger signal. The trigger will change the output of the power supply to the output voltage and current levels specified by VOLT:TRIG and CURR:TRIG commands and clear the WTG bit in the Status Operation Condition register. If INIT:CONT 1 has been issued, the trigger subsystem is immediately rearmed for subsequent triggers, and the WTG bit is again set to 1. \*TRG or GET are both addressed commands (only devices selected as listeners will execute the command). If output is set to OFF, \*TRG is ignored. Related Commands: ABOR, INIT, TRIG, CURR:TRIG,

VOLT:TRIG. (See example, Figure A-1.)

BIT 4886 022108 A-5

#### A.17 \*TST? — SELF TEST QUERY

\*TST? Syntax: Returned value: 0 or 1 (0 = pass test, 1 = fail test)

Description:

Power Supply test. This query causes the power supply to do a self test and provide the controller with pass/fail results. A 0 is returned if the unit passes the test. If the unit fails, a number from 1 through 1023 is returned to indicate the cause of the error. The test executes each of the subtests even when any one fails. If any test fails an error code bit is set which is returned to the user. The error codes returned are listed in Table A-4

TABLE A-4. BUILT-IN TEST ERROR CODES

TEST	TEST ACTIVE		ODES	MEANING
*tst?	DIAG:TST?	BIT	VALUE	MEANING
Yes	Yes		0	Pass (No error)
Yes	Yes	0	1	ROM error
Yes	Yes	1	2	RAM error
Yes	Yes	2	4	FLASH error Perform calibration to correct
Yes	Yes	4	16	Analog Communication error
No	Yes	5	32	Loop Back Test error
No	Yes	6	64	Max Voltage Output error
No	Yes	7	128	Min Voltage Output error

### A.18 \*WAI — WAIT-TO-CONTINUE COMMAND

\*WAI

Syntax: \*WAI Response:

Description: Causes the power supply to wait until all previously issued commands and queries are complete before executing subsequent commands or queries. This command can be used to guarantee sequential execution of commands and queries. When all pending operations are complete (all previous commands have been executed, changes in output level have been completed), the WAI command is completed and execution of subsequent commands can continue.

A-6 BIT 4886 022108

### APPENDIX B - SCPI COMMAND/QUERY DEFINITIONS

### **B.1 INTRODUCTION**

This appendix defines the SCPI subsystem commands and queries used with the BOP power supply. Subsystem commands are defined in PAR. B.3 through B.120, arranged in groups as they appear in the tree diagram, Figure 3-18. Table B-1 provides a quick reference of all SCPI subsystem commands and queries used in the BOP.

TABLE B-1. SCPI SUBSYSTEM COMMAND/QUERY INDEX

COMMAND	PAR.	COMMAND	PAR.
ABOR	B.3	[SOUR:]CURR:PROT:MODE, ?	B.53, B.54
CAL	B.4	[SOUR:]CURR:PROT:NEG, ?	B.55, B.56
INIT[:IMM]	B.5	[SOUR:]CURR:PROT:POS, ?	B.57, B.58
INIT:CONT, ?	B.6, B.7	[SOUR:]CURR:PROT:LIM[:BOTH], ?	B.59, B.60
MEAS:CURR?	B.8	[SOUR:]CURR:PROT:LIM:NEG, ?	B.61, B.62
MEAS:VOLT?	B.9	[SOUR:]CURR:PROT:LIM:POS, ?	B.63, B.64
MEM:REL	B.10	[SOUR:]CURR:TRIG, ?	B.65, B.66
MEM:UPD	B.11	[SOUR:]VOLT	B.67, B.68
OUTP[:STAT], ?	B.12, B.13	[SOUR:]VOLT:LIM[:BOTH], ?	B.69, B.70
OUTP:MODE, ?	B.14, B.15	[SOUR:]VOLT:LIM:NEG, ?	B.71, B.72
[SOUR:]FUNC:MODE, ?	B.16, B.17	[SOUR:]VOLT:LIM:POS, ?	B.73, B.74
[SOUR:]FUNC:MODE:TRIG, ?	B.18, B.19	[SOUR:]VOLT:MODE, ?	B.75, B.76
[SOUR:]LIST:CLE	B.20	[SOUR:]VOLT:PROT[:BOTH], ?	B.77, B.78
[SOUR:]LIST:COUN, ?	B.21, B.22	[SOUR:]VOLT:PROT:MODE, ?	B.79, B.80
[SOUR:]LIST:CURR, ?	B.23, B.24	[SOUR:]VOLT:PROT:NEG, ?	B.81, B.82
[SOUR:]LIST:CURR:APPL	B.25	[SOUR:]VOLT:PROT:POS, ?	B.83, B.84
[SOUR:]LIST:CURR:SWE, ?	B.26, B.27	[SOUR:]VOLT:PROT:LIM[:BOTH], ?	B.85, B.86
[SOUR:]LIST:POIN?	B.28	[SOUR:]VOLT:PROT:LIM:NEG, ?	B.87, B.88
[SOUR:]LIST:DWEL, ?	B.29, B.30	[SOUR:]VOLT:PROT:LIM:POS, ?	B.89, B.90
[SOUR:]LIST:DWEL:POIN?	B.31	[SOUR:]VOLT:TRIG	B.91, B.92
[SOUR:]LIST:QUER, ?	B.32, B.33	STAT:OPER:COND?	B.93
[SOUR:]LIST:RES?	B.34	STAT:OPER:ENAB, ?	B.94, B.95
[SOUR:]LIST:VOLT, ?	B.35, B.36	STAT:OPER[:EVEN]?	B.96
[SOUR:]LIST:VOLT:APPL	B.37	STAT:PRES	B.97
[SOUR:]LIST:VOLT:SWE, ?	B.38, B.39	STAT:QUES[:EVEN]?	B.98
[SOUR:]LIST:VOLT:POIN?	B.40	STAT:QUES:COND?	B.99
[SOUR:]CURR, ?	B.41, B.42	STAT:QUES:ENAB, ?	B.100, B.101
[SOUR:]CURR:LIM[:BOTH], ?	B.43, B.44	SYST:COMM:GPIB:ADDR, ?	B.102, B.103
[SOUR:]CURR:LIM:NEG, ?	B.45, B.46	SYST:ERR?	B.104
[SOUR:]CURR:LIM:POS, ?	B.47, B.48	SYST:ERR:CODE?	B.105, B.106
[SOUR:]CURR:MODE, ?	B.49, B.50	SYST:KEYB, ?	B.107, B.108
[SOUR:]CURR:PROT[:BOTH], ?	B.51, B.52	SYST:PASS:CEN	B.109

TABLE B-1. SCPI SUBSYSTEM COMMAND/QUERY INDEX (CONTINUED)

COMMAND	PAR.	COMMAND	PAR.			
SYST:PASS:CDIS	B.110	SYST:SEC	B.115			
SYST:PASS:NEW	B.111	SYST:SET, ?	B.116, B.117			
SYST:PASS:STAT	B.112	SYST:VERS?	B.118			
SYST:REM, ?	B.113, B.114	TRIG:SOUR, ?	B.119			
NOTE: Commands listed above that are followed by ", ?" have a related query.						

### **B.2 NUMERICAL VALUES**

The SCPI data parser on the BOP supports a maximum of 8 digits after the decimal point and a maximum integer of  $4 \times 10^8$ . Any values greater than these are not processed by the device and no error is generated. The largest string that can be received or transmitted by the BOP is 253 characters. All numerical data is returned in scientific notation, digits with decimal point and Exponent, e.g., 2.71E1 for 27.1.

The BOP's SCPI data parser for all **decimal** values supports a maximum of eight digits after the decimal point and a maximum integer of  $4 \times 10^8$ . Any values greater than these are not processed by the device and no error is generated.

The unit also supports keywords of MAXimum and MINImum to set the numeric entry to the most positive and negative allowable values, respectively. For example, If the user has established the volt:limit to be 6, sending the command VOLT MAX causes the output to be set to 6 volts. This syntax can be very useful in the setting of a limit, e.g., VOLT:PROT:LIM MAX sets the positive voltage protection limit to the maximum voltage (E<sub>O</sub>max + 1%) and the negative voltage protection limit to (-1.01 x E<sub>O</sub>max).

B.3 ABORT COMMAND ABOR

Syntax: Short Form: ABOR Long Form: ABORt

Description: Cancels previously stored trigger levels, resets WTG. The ABORt command cancels any pending trigger levels previously stored by the CURR:TRIG or VOLT:TRIG commands. The pending level is set

equal to the corresponding immediate value. ABORt also resets the WTG (Wait TriGger) bit in the Operation Condition status register. If INIT:CONT ON has been programmed, the trigger system rearms itself immediately after ABORt, thereby setting WTG. WTG is bit 5 in the STATUS OPERATION CONDITION register. The ABORt is executed each time power is turned on. Related Commands:

INIT, \*RST, \*TRG. (See example, Figure B-1.)

### **B.4 CAL COMMANDS AND QUERIES**

CAL

CAL commands and queries are used to perform calibration of the unit via the control interface. These commands must be issued in a specific sequence in order to properly calibrate the unit. To use these commands, refer to Kepco's website (www.kepcopower.com/drivers) and download the LabWindows/CVI Version 5 driver for BOP or refer to PAR. 4.3.1. This file provides remote calibration capability and uses the following supported commands and queries:

CAL:CEXT command

CAL:CGA command

CAL:CLIM command

CAL:CPR command

CAL:CURR[:DATA] command

CAL:DATA value command

**CAL:DPOT** command

CAL:SAVE command

CAL:STAT command and query

**CAL:VEXT** command

CAL:VGA command

CAL:VLIM command

CAL:VOLT[:DATA] command

CAL:VPR command

CAL:ZERO command

B-2 BOP-1K 022108

### B.5 INITiate[:IMMediate] COMMAND

INIT[:IMM]

Syntax: Short Form: INIT:[IMM] Long Form: INITiate[:IMMediate]

Description: **Enables a single trigger.** This command enables a single trigger. A \*TRG command completes the

sequence. Upon receipt of the \*TRG command, the power supply will return to the commanded values of voltage and current established by the VOLT:TRIG and CURR:TRIG commands. After a \*TRG command has been received, subsequent \*TRG commands have no effect unless preceded by INIT or

INIT: CONT ON. Related Commands: \*TRG, TRIG. (See example, Figure B-1.)

### **B.6 INITiate:CONTinuous COMMAND**

INIT: CONT

INIT: CONT?

MEAS:CURR?

MEAS:VOLT?

Syntax: Short Form: INIT:CONT  $\{ON \mid OFF\}$  or  $\{1 \mid 0\}$  (1 = on, 0 = off)

Long Form: INITiate:CONTinuous {ON | OFF} or {1 | 0} (1 = on, 0 = off)

Description: INIT:CONT ON enables continuous triggers.; INIT:CONT OFF disables continuous triggers. If

INIT:CONT is OFF, then INIT[:IMM] arms the trigger system for a single trigger. If INIT:CONT is ON, then the trigger system is continuously armed and INIT[:IMM] is redundant. Executing \*RST command

sets INIT:CONT to ON. (See example, Figure B-1.)

### **B.7 INITiate:CONTinuous QUERY**

Syntax: Short Form: INIT:CONT? Long Form: INITiate:CONTinuous?

Return Value: 1 or 0

Description: Determines whether continuous triggers are enabled or disabled. Power supply returns value of

INIT:CONT flag: "1" = continuous triggers are enabled (INIT:CONT ON); "0" = continuous triggers dis-

abled (INIT:CONT OFF). (See example, Figure B-1.)

### B.8 MEASure[:SCALar]:CURRent[:DC]? QUERY

Syntax: Short Form: MEAS[:SCAL]:CURR[:DC]?

Long Form: MEASure[:SCALar]:CURRent[:DC]?

Return Value: <num value> (digits with decimal point and Exponent)

Description: **Measures actual current.** This query returns the actual value of output current as determined by the

programmed value of voltage and current and load conditions. During calibration this command

returns the measurement tolerance (See example, Figure B-1.)

### B.9 MEASure[:SCALar]:VOLTage[:DC]? QUERY

Syntax: Short Form: MEAS[:SCAL]:VOLT[:DC]?

Long Form: MEASure[:SCALar]:VOLTage[:DC]?

Return Value: <num value> (digits with decimal point and Exponent)

Description: Measures actual voltage. This query returns the actual value of output voltage (measured at the

sense terminals) as determined by the programmed value of voltage and current and load conditions.

(See example, Figure B-1.)

Short Form: MEM:REL

### **B.10 MEMory:RELoad COMMAND**

Syntax:

Long Form: MEMory:RELoad

Description: Restores variables to power-up state by reloading all saved variables with data from non-vola-

tile RAM.

### **B.11 MEMory: UPDate COMMAND**

MEM:UPD

MEM:REL

Syntax: Short Form: MEM:UPD {INT | REF | LIM | SER | CONT | OUTP}

Long Form: MEMory:UPDate {INTerface | SERial | LIMits | REFerence | CONTrast | OUTPut}

Description: Saves selected variables. MEM:UPD INT saves GPIB address, Language (SCPI or CIIL) and all

SYST:SET (PAR. B.116) variables. MEM:UPD REF saves Reference Input state (Fixed, External, or Ext Ref LvI) and the Protection Limit reference state (Fixed, External or Lesser) described in Table 3-15. MEM:UPD SER saves the serial communication state, baud rate, pace control and echo information. MEM:UPD LIM saves limits for voltage and current and the maximum allowable protection values for voltage and current. MEM:UPD CONT saves the display contrast and background settings for the next power-up cycle. MEM:UPD OUTP saves the power supply on/off state and the mode of operation. Related commands: SYST:COMM:GPIB:ADDR, SYST:LANG, SYST:SET, VOLT:LIM, CURR:LIM, CURR:PROT:LIM, VOLT:PROT:LIM, DISP:COL, DISP:CONT. See PAR. 3.5.2.2 and Figure 3-16 for

special programming considerations.

BOP-1K 022108

NOTES: 1. The power supply is assumed to be operating in constant voltage mode.

2 Examples below are intended only to illustrate command functions. Refer to PAR. 3.5.2 for programming techniques to optimize performance.

OUTP ON Turns the output on.

VOLT 21; CURR 1.5 Power supply output programmed to go to 21V, current limit 1.5A

INIT:CONT ON Continuous triggers enabled. INIT:CONT? Power supply returns "1."

VOLT:TRIG 15;CURR:TRIG 3 Power supply output programmed to return to 15V, current limit

3A upon receipt of trigger.

\*TRG Power supply output returns to 15V,current limit 3A.

VOLT 21; CURR 5E-2 Power supply output programmed to go to 21V, current limit 0.05A

MEAS:VOLT? If actual value of output voltage is 20.9V, power supply

returns 2.09E1 within the limits of readback accuracy. If actual value of output current is 0.0483A, power supply

MEAS:CURR? If actual value of output current is 0.0483A, power supply returns 4.83E-2 within the limits of readback accuracy.

FUNC:MODE CURR Establishes constant current mode as power supply operating mode.

VOLT 21; CURR 1.1 Power supply programmed to voltage limit 21V, 1.1A.

CURR? Returns 1.1.

FUNC:MODE VOLT Establishes constant voltage mode as power supply operating mode.

CURR:TRIG? Returns 3 (current value established by CURR:TRIG). VOLT:TRIG? Returns 15 (voltage value established by VOLT:TRIG). \*TRG Power supply output returns to 15V, current limit 3A.

INIT:CONT 0 Triggers disabled.

INIT:CONT? Power supply returns "0."

VOLT 0 Power supply output programmed to go to 0V.

MEAS:VOLT? Returns 0 within the limits of readback accuracy (measured output

voltage).

VOLT? Returns 0 within the limits of readback accuracy (programmed output

voltage).

CURR? Returns 3 (programmed current).

MEAS:CURR? Returns 0 within the limits of readback accuracy (measured output

current).

### FIGURE B-1. PROGRAMMING THE OUTPUT

### B.12 OUTPut[:STATe] COMMAND

**OUTP** 

Syntax: Short Form: OUTP[:STAT] <boolean> Long Form: OUTPut[:STATe] <boolean>

<br/><boolean>=(0 or OFF, 1 or ON)

Description: **Enables or disables the power supply output.** The factory default for power-up is Local mode, the output is on and the front panel controls affect the unit's operation; however note that the factory default for power-up can be changed from the front panel (see PAR. 3.3.7). Upon entering Remote mode, the output status is not affected.

For passive loads, when OUTP OFF is executed, the programmed values of voltage and current are saved, then voltage and current are programmed as follows: when the unit is operating as a voltage source, voltage is programmed to zero and current protect is programmed to a low value; when operating as a current source, current is programmed to zero and voltage protect is programmed to a low value. When OUTP ON is executed, the power supply output is restored to the previously saved programmed values. The saved values of voltage and current can be viewed by VOLT? and CURR? queries.

For active loads (inductive, capacitive, battery or other electronic loads) programming the appropriate settings for mode, voltage and current is recommended instead of using the OUTP OFF command. Follow the guidelines presented in Table 3-6 to understand how the unit responds to OUTP OFF.

instead of using OUTP OFF, program the unit to current mode using the FUNC:MODE command, then program output current to zero.

Related Commands: FUNC:MODE, OUTP?.

B-4 BOP-1K 022108

B.13 OUTPut[:STATe] QUERY

OUTP?

Syntax: Short Form: OUTP[:STAT]? Long Form: OUTPut[:STATe]?

Return Value: <int value> (0 or 1)

Description: Indicates whether power supply output is enabled or disabled. Returns 0 if output disabled,

returns 1 if output enabled. Related Commands: OUTP.

**B.14 OUTPut:MODE COMMAND** 

**OUTP:MODE** 

OUTP:MODE?

FUNC:MODE

Syntax: Short Form: OUTP:MODE {ACTIVE | RESISTIVE | BATTERY}

Long Form: OUTPut:MODE {ACTIVE | RESISTIVE | BATTERY}

Description: Determines how the unit functions when output is turned off depending on the type of load in

use: active, resistive or battery. See PAR. 3.3.6 for description of ACTIVE, RESISTIVE and BAT-

TERY modes.

**B.15 OUTPut:MODE? QUERY** 

Syntax: Short Form: OUTP:MODE? Long Form: OUTPut:MODE]?

Return Value: ACTIVE | RESISTIVE | BATTERY

Description: Indicates whether power supply is configured for ACTIVE, RESISTIVE or BATTERY type loads.

See PAR. 3.3.6 for description of ACTIVE, RESISTIVE and BATTERY modes. Related Commands:

OUTP:MODE.

**B.16** [SOURce:]FUNCtion:MODE COMMAND

Syntax: Short Form: FUNC:MODE {VOLT | CURR} Long Form: [SOURce:]FUNCtion:MODE {VOLT | CURR}

Description: Establishes the operating mode of the power supply. VOLT = Constant Voltage mode (CV). CURR

= Constant Current mode (CC). FUNC:MODE VOLT commands power supply to Voltage mode, FUNC:MODE CURR commands power supply to Current mode. Commanded mode establishes parameters (voltage or current) monitored for error conditions. Actual mode depends upon load conditions. When commanded to Voltage mode, if load conditions cause the power supply to try to exceed the current limit, the unit will flag an error condition. When commanded to Current mode, if load conditions cause the power supply to try to exceed the voltage limit, the unit will flag an error condition.

B.17 [SOURce:]FUNCtion:MODE? QUERY

FUNC:MODE?

Syntax: Short Form: FUNC:MODE? Long Form: [SOURce:]FUNCtion:MODE?

**Return value:** 0 (voltage mode) or 1 (current mode)

Description: Returns the operating mode of the power supply. 0 = Constant Voltage mode (CV). 1 = Constant

Current mode (CC).

B.18 [SOURce:]FUNCtion:MODE:TRIGger COMMAND

Syntax: Short Form: FUNC:MODE:TRIG {VOLT | CURR}

Long Form: [SOURce:]FUNCtion:MODE:TRIGger {VOLT | CURR}

Description: Establishes the operating mode of the power supply when a TRIGger command is sent. VOLT =

 $\label{local_constant_constant} Constant\ \ Current\ mode\ (CC).\ FUNC: MODE: TRIG\ VOLT\ commands\ power\ supply\ to\ Voltage\ mode\ when\ a\ TRIGger\ command\ is\ sent,\ FUNC: MODE: TRIG\ CURR\ command\ com$ 

commands power supply to Current mode when a TRIGger command is sent.

B.19 [SOURce:]FUNCtion:MODE:TRIGger? QUERY

FUNC:MODE:TRIG?

FUNC:MODE:TRIG

Syntax: Short Form: FUNC:MODE:TRIG? Long Form: [SOURce:]FUNCtion:MODE:TRIGger?

**Return value:** 0 = voltage mode or 1 = current mode

Description: Returns the operating mode which the power supply will enter when a trigger command is

sent. VOLT = Constant Voltage mode (CV). CURR = Constant Current mode (CC).

B.20 [SOURce:]LIST:CLEar COMMAND

LIST:CLE

Syntax: Short Form: LIST:CLE Long Form: LIST:CLEar>

Description: Clears all list entries by setting all pointers to 0. Also sets LIST:DIR to UP, LIST:GEN to DSEQ,

Related Commands: All LIST commands (See example, Figure B-2.)

### **B.21** [SOURce:]LIST:COUNt COMMAND

LIST:COUN

Syntax: Short Form: LIST:COUN<int value 0 to 255> Long Form: LIST:COUNt> <int value 0 to 255>

Description: **Establishes how many times the list is executed.** Allows user to establish how many times the list (established by LIST:GEN DSEQ or LIST:GEN SEQ and LIST:SEQ) is executed. The order (beginning to end or end to beginning) is determined by LIST:DIR. For LIST:COUN 0, the unit will execute the sequence indefinitely until either a VOLT:MODE FIXED, or PROG:STOP command is received. Com-

mands: LIST:GEN, LIST:SEQ, LIST:DIR. (See example, Figure B-2.)

### B.22 [SOURce:]LIST:COUNt? QUERY

LIST:COUN?

Syntax: Short Form: LIST:COUNT? Long Form: LIST:COUNt?

Return Value: <int\_value>

Description: Identifies how many times the list will be executed. Returns value set by LIST:COUN command.

(See example, Figure B-2.)

### B.23 [SOURce:]LIST:CURRent COMMAND

LIST:CURR

Syntax: Short Form: LIST:CURR <exp\_value>, <exp\_value>, . . . (to max of 5900 data points for global dwell

time)

Long Form: LIST:CURRent <exp\_value>, <exp\_value>, . . . (to max of 5900 data points for global

dwell time)

<exp\_value> = digits with decimal point and Exponent, e.g., 2.71E1 for 27.1

Description: Adds the current value (in Amps) to list. This command sequentially adds LIST:CURRent values to the main channel List Data Table locations illustrated in Table B-2. Starting location is indicated by LIST:CURR:POIN? The maximum number of entries is 2950,3933 or 5900. Since the input buffer of the BOP has a limit of 253 characters, multiple commands are necessary to complete the full 3933 entries of the list. If LIST:VOLT has any entries, an error message: -221,"Settings conflict" is posted in

the error queue. Related Commands: LIST:CURR:POIN?. (See example, Figure B-2.)

### **TABLE B-2. LIST DATA TABLE**

Location (DSEQ)	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	 5900
Main Channel (commanded mode) LIST:CURRent or LIST:VOLTage																			
LIST:DWELI																			

NOTE: FUNC:MODE determines whether main channel is for voltage or current. FUNC:MODE CURR must precede LIST:CURR commands, FUNC:MODE VOLT must precede LIST:VOLT commands

### B.24 [SOURce:]LIST:CURRent? QUERY

LIST:CURR?

Syntax: Short Form: LIST:CURR? Long Form: LIST:CURRent?

Return Value: <value1>, <value2>, . . . to <value16>

Description: Identifies the parameters (main channel) entered for the list. Starting at location established by

LIST:QUERy, returns comma-separated list of up to 16 values indicating the main channel parameters entered. i.e., the contents of main channel locations of Table B-2. Related Commands: LIST: CURR, LIST:QUERy. If LIST:VOLT has any entries, an error message: -221,"Settings conflict" is posted in the

error queue. (See example, Figure B-2.)

B-6 BOP-1K 022108

### B.25 [SOURce:]LIST:CURR:APPLy COMMAND

LIST:CURR:APPL

Syntax: Short Form: LIST:CURR:APPL <type>,<value1>,<value2>[,<value3>]

Long Form: LIST:CURRent:APPLy <type>,<value1>, <talue2>[, <talue3>]
Where <type> is {SQUARE | RAMP+ | RAMP- | TRIANGLE | SINE | LEVEL}

<value1> is frequency (or period (duration) for LEVEL <value2> is p-p amplitude (or amplitude (offset) for LEVEL <value3> is offset (optional, default is 0, not applicable to LEVEL)

Description: Causes the unit to add a series of points to both the list:curr array and the list:dwell array to make either a level or a waveform of one of five types. Refer to table 3-11 for a description of the

make either a level or a waveform of one of five types. Refer to table 3-11 for a description of the waveform types. The waveform type specified is generated at the frequency specified with a peak-to-peak amplitude centered on zero. If the optional offset value is specified, the center of the generated series of points is moved off zero. The apply generator takes into account the soft limits for the current

channel and insures the generated array does not exceed the unit's capabilities.

### B.26 [SOURce:]LIST:CURRent:SWEep COMMAND

Syntax: Short Form: LIST:CURR:SWE <value1>,<value2>

Long Form: LIST:CURRent:SWEep <value1>,<value2>

Where <value1> is start angle. Valid from 0 to 359.99 degrees. <value2> is stop angle. Valid from 0.01 to 360.00 degrees

Description: Allows the user to provide a starting angle for either triangle and sine waveforms and an optional stop angle. If the stop angle is not supplied, the unit defaults to 360 degrees. This command

should be placed at the beginning of the waveform program to be applicable to all sine and triangle

waveform segments.

### B.27 [SOURce:]LIST:CURRent:SWEep? QUERY

LIST:CURR:SWE?

LIST:CURR:SWE

Syntax: Short Form: LIST:CURR:SWE? Long Form: LIST:CURRent:SWEep?

Return Value: <value1>, <value2>(0.01 to 360)

Description: Returns start <value1> and stop <value2> angle in degrees for either triangle and sine wave-

forms.

#### B.28 [SOURce:]LIST:CURRent:POINts? QUERY

LIST: CURR: POIN?

Syntax: Short Form: LIST:CURR:POIN? Long Form: LIST:CURRent:POINts?

Return Value: <n> where n = number of points

Description: Identifies the total number of points present in a list and the next location to be filled by LIST:CURR command. The LIST:CURR pointer is initially at 0 via LIST:CLE. For each data point

entered by a LIST:CURR command the list pointer is incremented If LIST:CURR:POIN? returns 5, the LIST:CURR pointer is at 5 indicating there are 6 data points comprising the list. If LIST:VOLT has any entries, an error message: -221,"Settings conflict" is posted in the error queue.Related Commands:

LIST:CURR. (See example, Figure B-2.)

### B.29 [SOURce:]LIST:DWELI COMMAND

LIST: DWEL

Long Form: LIST:DWELI <value> (0.0001 to 0.0334),<value>,<value>, . . . to maximum of 5900 values.

Description: **Determines how long the main channel parameters will be active.** Sets time value (from 0.000093 to 0.034) in seconds for List:Dwell locations illustrated in Table B-2. These locations are associated with the corresponding main channel locations illustrated in Table B-2. The main channel is determined by FUNC:MODE, either current (FUNC:MODE CURR) or voltage (FUNC:MODE VOLT) If LIST:DWEL is entered for only location 0, that time duration will apply to all steps when either VOLT:MODE LIST or CURR:MODE LIST is executed. Related Commands: VOLT:MODE,

FUNC:MODE, LIST:CURR, LIST:VOLT, LIST:DWEL?. (See example, Figure B-2.)

### B.30 [SOURce:]LIST:DWELI? QUERY

LIST:DWEL?

Syntax: Short Form: LIST:DWEL? Long Form: LIST:DWELI?

Return Value: <value>

Description: Identifies the dwell times entered for the list. Starting at location established by LIST:QUERy,

returns comma-separated list of up to 16 values indicating the dwell time parameters entered. i.e., the contents of LIST:DWEL locations of Table B-2. Related Commands: LIST: DWEL, LIST:QUERy. (See

example, Figure B-2.)

B.31 [SOURce:]LIST:DWELI :POINts? QUERY

LIST:DWEL:POIN?

Syntax: Short Form: LIST:DWEL:POIN? Long Form: LIST:DWELI:POINts?

Return Value: <value> (0 to 5900)

Description:Identifies the number of locations for which time values have been entered and the next loca-

tion to be filled by a LIST:DWEL command. If LIST:DWEL:POIN? returns 6, dwell times have been entered for locations 0 through 5 and location 6 is the next to be filled by a LIST:DWEL command.

LIST:DWEL, LIST:DWEL:POIN. (See example, Figure B-2.)

NOTES: Examples below are intended only to illustrate command functions. Refer to PAR. 3.5.2 for pro-

gramming techniques to optimize performance.

LIST:CLEAR Initializes the list process.

LIST:RES? Returns 0.000093,0.034000,nnnn (where nnnn = total number of points

available).

LIST: VOLT: POINTS? Returns 0. LIST: VOLT: POINTS? MAX Returns 5900.

LIST:VOLT:APPLY SINE,15,10 Causes the BOP to generate points.for 15Hz sine wave, 10V p-p. LIST:VOLT:POIN? Returns 960 - indicating the unit used 960 points for the sine wave.

LIST:VOLT:POIN? MAX Returns 3933 - indicating up to 3933 points can be used.

LIST:DWEL:POIN? Returns 960 - indicating 960 points have been assigned dwell times.

LIST:DWEL? Returns 1.38e-4 indicating the unit used

138 microseconds per division (automatically selected as the best possible

dwell for the waveform).

FUNC:MODE VOLT Initializes the power supply mode to be voltage.

LIST:CLEAR Initializes the list processor to add entries, clears main channel (LIST:CURR

or LIST:VOLT) and LIST:DWEL data tables (Table B-2).

LIST:VOLT -20,-18,-16,-14,-12,-10,-8,-6,-4,-2,0

Starting at location 0 (-20), up to location 10 (0), fills the list with 11 data

points.

LIST:VOLT:POIN? Returns 11. Indicates that 11 data points have been entered, and location

11 is the next location to be filled (for the 12th data point.

NOTE: See PAR. B.2 for format and accuracy of all numerical data returned.

LIST:QUERY? Returns 0 (pointer cleared by LIST:CLE).

LIST: VOLT? Returns -20,-18,-16,-14,-12,-10,-8,-6,-4,-2,0 (the contents of locations 0

through 10). (See PAR. B.2 for format and accuracy of numerical data.)

list:volt 2,4,6,8,10,12,14,16,18,20

Adds 10 points to the list (location 11 through 20). List now has 21 points.

LIST:VOLT:POIN? Returns 21 (the next location to be filled by LIST:VOLT).

LIST:COUNT 100 Specifies that when VOLT:MODE LIST is issued, the user-determined

sequence will be executed 100 times. (44 steps in the list will be executed

100 times)

CURR 1;VOLT -20 initializes the BOP output

OUTPUT ON Turns the output on (BOP now provides -20 volts)

LIST:DWELL .010 Sets the time duration for location 0 to be 0.010 second (Since dwell times

for the rest of the locations in the list are not entered before running the list,

the dwell time will be 0.010 second for all locations.

#### FIGURE B-2. USING LIST COMMANDS AND QUERIES (SHEET 1 OF 2)

B-8 BOP-1K 022108

**B.32** [SOURce:]LIST:QUERy COMMAND

LIST: QUER

Syntax: Short Form: LIST:QUER <int\_value>

Long Form: LIST:QUERy <int value>

int value = <n> where n = first location to be gueried.

Description: Determines first location to be queried by LIST:VOLT?, LIST:CURR? or LIST:DWEL? queries.

Related Commands: LIST:VOLT?, LIST:CURR?, LIST:DWEL?. LIST:QUER?. (See example, Figure B-2.)

B.33 [SOURce:]LIST:QUERy? QUERY

LIST:QUER?

Syntax: Short Form: LIST:QUER? Long Form: LIST:QUERy?

Return Value: <int value>

Description: Identifies first location to be queried by LIST:VOLT?, LIST:CURR?, LIST:DWEL? queries.

Related Commands: LIST:QUER, LIST:CURR?, LIST:DWEL?. LIST:QUER?. (See example, Figure B-2.)

VOLT:MODE LIST Executes the list. For 240 milliseconds the BOP outputs -20V, then output a

staircase triangle wave from -20V to +20V and back down to -20V. This staircase will have a uniform spacing between voltage changes of 10 milli-

seconds and will repeat 100 times.

VOLT? Returns +20 (the last step in the list set the unit to +20V.

LIST:COUNT? Returns 100.

LIST:COUNT 10 Determines that the list will be repeated 10 times when executed.

LIST:COUNT? Returns 10.

VOLT:MODE LIST Initiates execution of the list. The unit outputs a sawtooth waveform that

increases from -20V to +20V and repeats 10 times. There is an abrupt change from +20V to -20V each time the list transitions from location 20 to

location 0.

VOLT? Returns 20, (the last step in the list set the unit to 20V.

LIST:DWELL .01,.01,.01,.01,.01,.01,.01,.01

Enters dwell time of 0.01 seconds in locations 1 through 9.

LIST:DWELL .03 Enters dwell time of 0.03 second in location 10.

VOLT:MODE LIST the list is not executed, the unit returns error -221,Settings Error indicating

the lists are not balanced.

LIST:DWELL:POINTS? Returns 11 to indicate the dwell list has 11 entries LIST:VOLT:POINTS? Returns 21 to indicate the voltage list has 21 entries.

LIST:DWELL .01,.01,.01,.01,.01,.01,.01,.01,.01

Dwell times are entered in locations 11 through 20.

DWELL:POINTS? Returns 21 indicating there are now 21 step dwell times on the list.

LIST:QUER? Returns 0 indicating list queries will start from location 0

LIST:QUER 9 Causes list queries to start at location 18

LIST:DWEL? Returns 01,.03,.01,.01,.01,.01,.01,.01,.01,.01,.01(the dwell times for

locations 9 through 20.

LIST COUNT 0 List will repeat indefinitely.

VOLT:MODE LIST The list is executed. Stair case wave now consists of 21 steps of .01 sec-

onds except for the 0V step (location 10) which outputs 0V for 0.03 second.

LIST:DWEL? Returns error -221, Settings Error because a LIST command cannot be exe-

cuted while the LIST is still being executed.

VOLT:MODE FIX Stops execution of the list

LIST:VOLT:APPLY SINE,60,20 Adds a 60Hz, 20V p-p sine wave to the current waveform VOLT:MODE:LIST Unit outputs the staircase and then the sine wave.

\*RST Unit stops generating the waveform.

FIGURE B-2. USING LIST COMMANDS AND QUERIES (SHEET 2 OF 2)

### B.34 [SOURce:]LIST:RESolution? QUERY

LIST:RES?

Syntax: Short Form: LIST:RES? Long Form: LIST:RESolution?

Return Value: <value1>,<value2>,<value3>

(where <value1> and <value2> = clock period, <value3> = number of points to be used)

Description: Identifies whether resolution is set to minimum (3840) or maximum (5900) and indicates the clock period. The resolution (3840 or 5900) determines the maximum number of points that will be used for the waveform. <value1> and <value2> indicate the boundaries of acceptable dwell times: e.g., if LIST:RES? returns either 0.000093,0.034000,3840 or 0.034000,0.000093,3840 dwell times

faster than 93 microseconds and slower than 34 milliseconds will not be accepted.

### B.35 [SOURce:]LIST:VOLTage COMMAND

LIST: VOLT

Short Form: LIST:VOLT[:LEV] <exp\_value>, <exp\_value>, . . . (to max of 5800 data points)

Long Form: LIST:VOLTage[:LEVel] <exp\_value>, <exp\_value>, . . . (to max of 5800 data points)

<exp\_value> = digits with decimal point and Exponent, e.g., 2.71E1 for 27.1

Description: Adds the voltage value (in Amps) to list. This command sequentially adds LIST:VOLTage values to the main channel List Data Table locations illustrated in Table B-2. LIST:CLE sets starting location to 0. Next location indicated by LIST:VOLT:POIN? The maximum number of entries is 2900, 3865, or 5800. Since the input buffer of the BOP has a limit of 253 characters, multiple commands are necessary to complete the full 3865 entries of the list. If LIST:CURR has any entries, an error message: -221,"Settings conflict" is posted in the error queue. Related Commands: LIST:VOLT:POIN?, FUNC:MODE,

LIST:CLE, \*RST. (See example, Figure B-2.)

### B.36 [SOURce:]LIST:VOLTage? QUERY

LIST: VOLT?

Syntax: Short Form: LIST:VOLT? Long Form: LIST:VOLTage? Return Value: <value1>, <value2>, . . . to <value16>

Description: **Identifies the parameters (main channel) entered for the list.** Starting at location established by LIST:QUERy, returns comma-separated list of up to 16 values indicating the main channel parameters entered. i.e., the contents of the main channel locations of Table B-2. Related Commands: LIST: VOLT, LIST:QUERy. If LIST:CURR has any entries, an error message: -221,"Settings conflict" is

posted in the error queue. (See example, Figure B-2.)

### B.37 [SOURce:]LIST:VOLT:APPLy COMMAND

LIST:VOLT:APPL

Syntax: Short Form: LIST:VOLT:APPL <type>,<value1>,<value2>[,<value3>]

Long Form: LIST:VOLTage:APPLy <type>,<value1>,<value2>[,<value3>]
Where <type> is {SQUARE | RAMP+ | RAMP- | TRIANGLE | SINE | LEVEL}

<value1> is frequency (or period (duration) for level)
<value2> is p-p amplitude (or amplitude (offset) for level)
<value3> is offset (optional, default is 0, not applicable to level)

Description: Causes the unit to add a series of points to both the list:volt array and the list:dwell array to make either a level or a waveform of one of five types. Refer to table 3-11 for a description of the waveform types. The waveform type specified is generated at the frequency specified with a peak-to-peak amplitude centered on zero. If the optional offset value is specified, the center of the generated series of points is moved off zero. The apply generator takes into account the soft limits for the voltage channel and insures the generated array does not exceed the unit's capabilities.

### B.38 [SOURce:]LIST:VOLTage:SWEep COMMAND

LIST: VOLT: SWE

Syntax: Short Form: LIST:VOLT:SWE <>,

Long Form: LIST:VOLTage:SWEep <value1>,<value2>

Where <value1> is start angle. Valid from 0 to 359.99 degrees. <value2> is stop angle. Valid from 0.01 to 360.00 degrees

Description: Allows the user to provide a starting angle for either triangle and sine waveforms and an optional stop angle. If the stop angle is not supplied, the unit defaults to 360 degrees. This command should be placed at the beginning of the waveform program to be applicable to all sine and triangle waveform segments.

B-10 BOP-1K 022108

### B.39 [SOURce:]LIST:VOLTage:SWEep? QUERY

LIST:VOLT:SWE?

Syntax: Short Form: LIST:VOLT:SWE? Long Form: LIST:VOLTage:SWEep?

Return Value: <value1>, <value2>(0.01 to 360)

Description: Returns start <value1> and stop <value2> angle in degrees for either triangle and sine wave-

forms.

### B.40 [SOURce:]LIST:VOLTage:POINts? QUERY

LIST: VOLT: POIN?

Syntax: Short Form: LIST:VOLT:POIN? Long Form: LIST:VOLTage:POINts?

Return Value: <n> where n = number of points used

Description: Identifies the total number of points in a list and the next location to be filled by LIST:VOLT command. The LIST:VOLT pointer is initially at 0 via \*RST or LIST:CLE. For each data point entered by a LIST:VOLT command the list pointer is incremented If LIST:VOLT:POIN? returns 5, the LIST:VOLT pointer is at 5 indicating there are 5 data points comprising the list (locations 0 though 4) and location 5 is the next to be filled. If LIST:CURR has any entries, an error message: -221,"Settings conflict" is posted in the error queue. Related Commands: LIST:VOLT. (See example, Figure B-2.)

### B.41 [SOURce:]CURRent[:LEVel][:IMMediate][:AMPlitude] COMMAND

**CURR** 

Syntax: Short Form: [SOUR:]CURR[:LEV][:IMM][:AMP] <exp value>

Long Form: [SOURce:]CURRent[:LEVel][:IMMediate][:AMPlitude] <exp\_value> <exp\_value> = digits with decimal point and Exponent, e.g., 2.71E1 for 27.1

Description: **Sets programmed current level at power supply output.** This command programs output current to a specific value; actual output current will depend on load conditions. Any data that exceeds I<sub>MAX</sub> causes error message -222 "data out range" to be posted to the error queue (See example, Figure B-

1.)

### B.42 [SOURce:]CURRent[:LEVel][:IMMediate][:AMPlitude] QUERY

**CURR?** 

Syntax: Short Form: [SOUR:]CURR[:LEV][:IMM][:AMP]? MIN, MAX

Long Form: [SOURce:]CURRent[:LEVel][:IMMediate][:AMPlitude]? MIN, MAX

Return Value:<exp value> = digits with decimal point and Exponent, e.g., 2.71E1 for 27.1

Description: Returns either the programmed value, maximum value, or minimum value of current. The CURR? query returns the programmed value of current. Actual output current will depend on load conditions. The CURR?MAX query returns the maximum positive current allowed for a particular model. CURR? MIN returns minimum negative current allowed for power supply (always negative). Related

Commands: CURR. (See example, Figure B-1.)

### B.43 [SOURce:]CURRent[:LEVel]:LIMit[:BOTH] COMMAND

CURR:LIM[:BOTH]

Syntax: Short Form: [SOUR:]CURR[:LEV]:LIM[:BOTH] <value>

Long Form: [SOURce:]CURRent[:LEVel]:LIMit[:BOTH] <value>

where <value> is between zero and INOM

Description: Establishes the software limit <value> for output current, i.e., sets the maximum value of output current that the unit will be allowed to source and sink. Requires MEM:UPD (PAR. B.11) to save for power

up. See PAR. 3.5.2.2 and Figure 3-16 for special programming considerations. (See Figure B-3)

BOP-1K 022108

NOTES: 1. This example assumes a BOP 36-28MG power supply is operating in constant current (CC) mode.

2 Examples below are intended only to illustrate command functions. Refer to PAR. 3.5.2 for programming techniques to optimize performance.

CURR:LIM? Returns 28,28 (positive and negative defaults for max

current in current mode).

CURR:LIMIT:POS 10;NEG 2 Establishes the maximum positive and negative current values

that can be set in current mode.

func:mode volt Sets power supply in voltage mode.

volt 15;curr 2 Allows the power supply to provide 15 volts positive with the

ability to source or sink up to 2 amperes. The display shows:

15.000 2.000 2.000.

CURR 10 Since the BOP is operating in voltage mode, sets the current

capability (current protect) to 10 amperes. The display shows:

15.000 10.000 10.000

curr:prot? Returns 10,10

CURR:prot:neg 1 Limits the negative current capability to 1 ampere.

CURR:PROT:LIM:NEG 5 Prevents CURR:PROT:NEG setting from exceeding

5 amperes

curr:prot? Returns 10,1 (the actual positive (10) and negative (1)

protection levels for the current.

---- Turn BOP POWER off and then on.

curr:lim? Returns 28,28 the factory default levels (all the above

changes have been lost). To lock in the changed limits, the user

CURR:LIM[:BOTH]?

CURR:LIM:NEG

must send :MEMORY:UPDATE LIMITS.

CURR:PROT:LIM:POS 28.3;neg 28 Establishes new max current protect limits (positive 28.3 and

negative 28.

CURR 28 Establishes the positive protect to be 28 amperes and the

negative protection remains 28 amperes.

curr:prot? returns 28,28

func:mode curr Changes the mode of operation of the power supply to current

mode.

#### FIGURE B-3. SETTING LIMITS

### B.44 [SOURce:]CURRent[:LEVel]:LIMit[:BOTH]? QUERY

Syntax: Short Form: [SOUR:]CURR[:LEV]:LIM[:BOTH]?

Long Form: [SOURce:]CURRent[:LEVel]:LIMit[:BOTH]?

Returns <value>, <value>

Description: Identifies the positive software limit, followed by the negative software limit value of output current that

the unit can source or sink.

Syntax:

### B.45 [SOURce:]CURRent[:LEVel]:LIMit::NEG COMMAND

Short Form: [SOUR:]CURR[:LEV]:LIM:NEG <value>

Long Form: [SOURce:]CURRent[:LEVel]:LIMit:NEGative <value>

Description: Establishes the negative software limit <value> for output current, i.e., sets the maximum value of out-

put current that the unit will be allowed to source (quadrant 3, Figure 1-2) or sink (quadrant 2) to the value specified by the user. Requires MEM:UPD (PAR. B.11) to save for power up. See PAR. 3.5.2.2

and Figure 3-16 for special programming considerations.

B-12 BOP-1K 022108

### B.46 [SOURce:]CURRent[:LEVel]:LIMit:NEG? QUERY

Syntax: Short Form: [SOUR:]CURR[:LEV]:LIM:NEG?

Long Form: [SOURce:]CURRent[:LEVel]:LIMit:NEGative?

Returns <value>

Description: Identifies the negative software limit value of output current that the unit can source (quadrant 3, Fig-

ure 1-2) or sink (quadrant 2).

### B.47 [SOURce:]CURRent[:LEVel]:LIMit:POS COMMAND

Syntax: Short Form: [SOUR:]CURR[:LEV]:LIM:POS <value>

Long Form: [SOURce:]CURRent[:LEVel]:LIMit:POSitive <value> where <value> is between zero and the rated (nominal) output voltage

Description: Establishes the positive software limit <value> for output current, i.e., sets the maximum value of output current that the unit will be allowed to source (quadrant 1, Figure 1-2) or sink (quadrant 4) to the

value specified by the user. Requires MEM:UPD (PAR. B.11) to save for power up. See PAR. 3.5.2.2

and Figure 3-16 for special programming considerations.

### B.48 [SOURce:]CURRent[:LEVel]:LIMit::POS? QUERY

Syntax: Short Form: [SOUR:]CURR[:LEV]:LIM:POS?

Long Form: [SOURce:]CURRent[:LEVel]:LIMit:Positive?

Returns <value>

Description: Identifies the positive software limit value of output current that the unit can source (quadrant 1, Figure

1-2) or sink (quadrant 4).

### B.49 [SOURce:]CURRent:MODE COMMAND

CURR:MODE

CURR:MODE?

**CURR:LIM:NEG?** 

CURR:LIM:POS

CURR:LIM:POS?

Syntax: Short Form: [SOUR:]CURR:MODE (FIX | LIST | TRAN <nn> | EXT | GAIN)

Long Form: [SOURce:]CURRent:MODE (FIXed | LIST | TRANsient <nn> | EXTernal | GAIN)

nn = <value> = time in seconds for transient (from 0.035 to 1)

Description: Allows the user to execute or stop a list, to execute a transient or to use an external reference.

The default mode is FIXed: the power supply executes commands normally, and LIST commands can be issued to establish the parameters and sequence of a list. This command affects the *main channel*, whether voltage or current.

When CURR:MODE LIST is issued, a list is executed (See LIST commands and Figure B-2). While the list is being executed, LIST commands are not accepted and will produce a command error.

Issuing CURR:MODE FIX while the list is running will stop the execution of the list and return power supply to settings in effect prior to running the list. If the list runs to completion, the settings of the last step of the list will be in effect.

CURR:MODE TRAN nn causes the next CURR: or VOLT: command to produce a transient pulse of nn seconds duration. (Similar to VOLT:MODE TRAN (see PAR. B.75 for examples). If the time nn exceeds 1 second, error message -222 "dwell or frequency out range" is posted to the error queue.

CURR:MODE EXT Configures the unit to use an external reference to change the output current.

CURR:MODE GAIN Configures the unit to use an external reference to provide a proportional output current

Related Commands: LIST commands. (See example, Figure B-2.)

### B.50 [SOURce:]CURRent:MODE? QUERY

Syntax:

Short Form: [SOUR:]CURR[:LEV]:MODE?

Long Form: [SOURce:]CURRent[:LEVel]:MODE?

Return value: FIXED, LIST, TRANSIENT, EXTERNAL or GAIN

Description: Identifies active current mode. Returns LIST while list is being executed. Returns TRANSIENT after

CURR:MODE:TRAN command has been issued, but before CURR: or \*TRG command executes the transient. Returns FIXED while in fixed (default) mode of operation. Returns EXT or GAIN when external reference is to be used to either program output current or provide proportional output current, respectively. **Related Commands:** LIST commands. (Similar to VOLT:MODE?, see Figure B-2.)

### B.51 [SOURCe:]CURRent[:LEVel]:PROTect[:BOTH] COMMAND CURR:PROT[:BOTH]

Syntax: Short Form: [SOUR:]CURR[:LEV]:PROT:BOTH <value>

Long Form: [SOURce:]CURRent[:LEVel]:PROTect:BOTH <value>

where <value> is between minimum (box) value (Figure 1-2) and 1% above rated (nominal) output

current.

Description: Establishes both the positive and negative protection limits for current, the maximum current the unit is

set up to source and sink; maximum is 1% greater than rated output current.

### B.52 [SOURce:]CURRent[:LEVel]:PROTect[:BOTH] QUERY CURR:PROT[:BOTH]?

Syntax: Short Form: [SOUR:]CURR[:LEV]:PROT[:BOTH]?

Long Form: [SOURce:]CURRent[:LEVel]:PROTect[:BOTH]?

Returns <value>, <value>

Description: Identifies the protection limits for current (source, sink), the maximum current the unit will source.or

sink

### B.53 [SOURce:]CURRent[:LEVel]:PROTect:MODE COMMAND CURR:PROT:MODE

Syntax: Short Form: [SOUR:]CURR[:LEV]:PROT:MODE (EXT | FIX | LESS |)

Long Form: [SOURce:]CURRent[:LEVel]:PROTect:MODE (EXTernal | FIXed | LESSer |)

Description: Determines how current protection limits are controlled.

 ${\sf FIXED-Allows\ the\ limits\ to\ be\ controlled\ by\ digital\ signals\ from\ either\ the\ keypad\ (if\ the\ unit\ is\ in\ local\ properties)}$ 

mode) or SCPI command (if the unit is in remote mode).

EXTERNAL: Allows the limits to be controlled by analog signals applied to the analog port; limits set

from the keypad or SCPI command have no effect (see PAR. 3.3.6.1).

LESSER LIMIT: Allows protect limit to be automatically selected from either 1) the external analog limit CURRent applied to the Analog I/O port or 2) the value set from the keypad or SCPI command).

Whichever limit has a lower absolute value (closest to zero) has effect

### B.54 [SOURce:]CURRent[:LEVel]:PROTect:MODE? QUERY CURR:PROT:MODE?

Syntax: Short Form: [SOUR:]CURR[:LEV]:PROT:MODE?

Long Form: [SOURce:]CURRent[:LEVel]:PROTect:MODE?

Returns FIX, EXT or EXTR

Description: Identifies how current protection limits are controlled: FIX for Fixed, EXT for external, LESS for the lesser of the internal (fixed) and external current protection limits (See PAR. B.53 for details).

### B.55 [SOURce:]CURRent[:LEVel]:PROTect:NEGative COMMAND CURR:PROT:NEG

Syntax: Short Form: [SOUR:]CURR[:LEV]:PROT:NEG <value>

Long Form: [SOURce:]CURRent[:LEVel]:PROTect:NEGative <value>

where <value> is between minimum (box) value (Figure 1-2) and 1% above rated (nominal) output

urrent.

Description: Establishes the negative protection limit for current, maximum is 1% greater than rated (nominal) out-

put current.

### B.56 [SOURce:]CURRent[:LEVel]:PROTect:NEGative? QUERY CURR:PROT:NEG?

Syntax: Short Form: [SOUR:]CURR[:LEV]:PROT:NEG?

Long Form: [SOURce:]CURRent[:LEVel]:PROTect:NEGative?

Returns <value>

Description: Identifies the negative protection limit for current.

### B.57 [SOURCe:]CURRent[:LEVel]:PROTect:POSitive COMMAND CURR:PROT:POS

Syntax: Short Form: [SOUR:]CURR[:LEV]:PROT:POS <value>

Long Form: [SOURce:]CURRent[:LEVel]:PROTect:POSitive <value>

where <value> is between minimum (box) value (Figure 1-2) and 1% above rated (nominal) output

CURR:PROT:POS?

current.

Description: Establishes the positive protection limit for current, maximum is 1% greater than rated output current.

### B.58 [SOURce:]CURRent[:LEVel]:PROTect:POSitive? QUERY

Syntax: Short Form: [SOUR:]CURR[:LEV]:PROT:POS?

Long Form: [SOURce:]CURRent[:LEVel]:PROTect:POSitive?

Returns <value>

Description: Identifies the positive protection limit for current.

B-14 BOP-1K 022108

### B.59 [SOURce:]CURRent[:LEVel]:PROTect:LIMit[:BOTH] COMMAND

CURR:PROT:LIM[:BOTH]

Syntax: Short Form: [SOUR:]CURR[:LEV]:PROT:LIM[:BOTH] <value>

Long Form: [SOURce:]CURRent[:LEVel]:PROTect:LIMit:[BOTH <value>

where <value> is between minimum (box) value (Figure 1-2) and 1% above rated (nominal) output

current.

Description: Establishes the maximum value possible for both the positive and negative protection limits for cur-

rent. Requires MEM:UPD (PAR. B.11) to save for power up. See PAR. 3.5.2.2 and Figure 3-16 for spe-

cial programming considerations.

B.60 [SOURce:]CURRent[:LEVel]:PROTect:LIMit[:BOTH]? QUERY

CURR:PROT:LIM:[:BOTH]?

Syntax: Short Form: [SOUR:]CURR[:LEV]:PROT:LIM[:BOTH]?

Long Form: [SOURce:]CURRent[:LEVel]:PROTect:LIMit[:BOTH]?

Returns <exp value>,<exp value>

Description: Identifies the maximum value possible for protection limits for current (positive, negative); maximum is

1% greater than rated output current.

B.61 [SOURce:]CURRent[:LEVel]:PROTect:LIMit:NEGative COMMAND

CURR:PROT:LIM:NEG

Syntax: Short Form: [SOUR:]CURR[:LEV]:PROT:LIM:NEG <exp\_value>

Long Form: [SOURce:]CURRent[:LEVel]:PROTect:LIMit:NEGative <exp\_value>

where <value> is between minimum (box) value (Figure 1-2) and 1% above rated (nominal) output

current.

Description: Establishes the minimum (maximum absolute) value possible for the negative protection limit for cur-

rent. This may be set up to 1% greater than rated current. Requires MEM:UPD (PAR. B.11) to save for  $\ensuremath{\mathsf{N}}$ 

power up. See PAR. 3.5.2.2 and Figure 3-16 for special programming considerations.

B.62 [SOURce:]CURRent[:LEVel]:PROTect:LIMit:NEGative? QUERY

CURR:PROT:LIM:NEG?

Syntax: Short Form: [SOUR:]CURR[:LEV]:PROT:LIM:NEG?

Long Form: [SOURce:]CURRent[:LEVel]:PROTect:LIMit:NEGative?

Returns: <exp\_value>

Description: Identifies the minimum (maximum absolute) value possible for the negative protection limit for current.

B.63 [SOURce:]CURRent[:LEVel]:PROTect:LIMit:POSitive COMMAND

CURR:PROT:LIM:POS

Syntax: Short Form: [SOUR:]CURR[:LEV]:PROT:LIM:POS <exp\_value>

Long Form: [SOURce:]CURRent[:LEVel]:PROTect:LIMit:POSitive <exp value>

where <value> is between minimum (box) value (Figure 1-2) and 1% above rated (nominal) output

current.

Description: Establishes the maximum value possible for the positive protection limit for current. This may be set

up to 1% greater than rated current. Requires MEM:UPD (PAR. B.11) to save for power up. See PAR.

3.5.2.2 and Figure 3-16 for special programming considerations.

B.64 [SOURce:]CURRent[:LEVel]:PROTect:LIMit:POSitive? QUERY

**CURR:PROT:LIM:POS?** 

Syntax: Short Form: [SOUR:]CURR[:LEV]:PROT:LIM:POS?

Long Form: [SOURce:]CURRent[:LEVel]:PROTect:LIMit:POSitive?

Returns: <exp value>

Description:Identifies the maximum value possible for the positive protection limit for current.

B.65 [SOURce:]CURRent[:LEVel]:TRIGgered[:AMPlitude] COMMAND

Short Form: [SOUR:]CURR[:LEV]:TRIG[:AMP] <exp value> Syntax:

> Long Form: [SOURce:]CURRent[:LEVel]:TRIGgered[:AMPlitude] <exp value> <exp value> = digits with decimal point and Exponent, e.g., 2.71E1 for 27.1

Description: Programs current value to be transferred to output by \*TRG (trigger) commands. This command

can be used to reset many power supplies to preselected parameters by issuing a single \*TRG command. Actual output current will depend on load conditions. If the value exceeds the maximum for the model being programmed, error message -222,"Data out of range" is posted in output queue. Related

Commands: CURR, \*TRG, TRIG

CURR:TRIG? B.66 [SOURce:]CURRent[:LEVel]:TRIGgered[:AMPlitude]? QUERY

Short Form: [SOUR:]CURR[:LEV]:TRIG[:AMP]? Syntax:

Long Form: [SOURce:]CURRent[:LEVel]:TRIGgered[:AMPlitude]?

Return Value: <exp\_value> = digits with decimal point and Exponent, e.g., 2.71E1 for 27.1

Description: Returns the current value established by CURR:TRIG command.

B.67 [SOURce:]VOLTage[:LEVel][:IMMediate][:AMPlitude] COMMAND

VOLT

VOLT?

VOLT:LIMI:BOTH1?

VOLT:LIM:NEG

**CURR:TRIG** 

Short Form: [SOUR:]VOLT[:LEV][:IMM][:AMP] <exp value> Syntax:

Long Form: [SOURce:]VOLTage[:LEVel][:IMMediate][:AMPlitude] <exp value> <exp value> = digits with decimal point and Exponent, e.g., 2.71E1 for 27.1

Description: Sets programmed voltage level at power supply output. This command programs output voltage

to a specific value; actual output voltage will depend on load conditions. If the value exceeds the maximum for the model being programmed, error message -222,"Data out of range" is posted in output

queue. (See example, Figure B-1.)

B.68 [SOURce:]VOLTage[:LEVel][:IMMediate][:AMPlitude]? QUERY

Short Form: [SOUR:]VOLT[:LEV][:IMM][:AMP]? {MIN | MAX} Long Form: [SOURce:]VOLTage[:LEVel][:IMMediate][:AMPlitude]? {MIN | MAX}

Description: Identifies programmed voltage, maximum allowable voltage, or minimum voltage. The VOLT?

query returns the programmed value of voltage. Actual output voltage will depend on load conditions. The VOLT? MAX query returns the maximum voltage allowed for a particular model. VOLT? MIN returns minimum voltage allowed for power supply (always negative). Related Commands: VOLT.

(See example, Figure B-1.)

Syntax:

Syntax:

Syntax:

VOLT:LIM[:BOTH] B.69 .[SOURce:]VOLTage[:LEVel]:LIMit[:BOTH] COMMAND

Short Form: [SOUR:]VOLT[:LEV]:LIM[:BOTH] <value> Syntax:

> Long Form: [SOURce:]VOLTage[:LEVel]:LIMit[:BOTH] <value> where <value> is between zero and rated (nominal) output voltage

Description: Establishes the software limit <value> for output voltage, i.e., sets the maximum value of positive or

negative output voltage that the unit will be allowed to produce. Requires MEM:UPD (PAR. B.11) to

save for power up. See PAR. 3.5.2.2 and Figure 3-16 for special programming considerations.

B.70 [SOURce:]VOLTage[:LEVel]:LIMit[:BOTH]? QUERY

Short Form: [SOUR:]VOLT[:LEV]:LIM[:BOTH] ?

Long Form: [SOURce:]VOLTage[:LEVel]:LIMit:[:BOTH] ?

Returns <value>

Description: Identifies the software limit value for both positive and negative output voltage specified by the user.

B.71 [SOURce:]VOLTage[:LEVel]:LIMit:NEGative COMMAND Short Form: [SOUR:]VOLT[:LEV]:LIM:NEG <value>

Long Form: [SOURce:]VOLTage[:LEVel]:LIMit:NEGative <value>

where <value> is between zero and rated (nominal) output voltage

Description: Establishes the software limit <value> for negative output voltage, i.e., sets the maximum value of

negative output voltage that the unit will be allowed to produce. Requires MEM:UPD (PAR. B.11) to save for power up. See PAR. 3.5.2.2 and Figure 3-16 for special programming considerations.

B-16 BOP-1K 022108

### B.72 [SOURce:]VOLTage[:LEVel]:LIMit:NEGative? QUERY

VOLT:LIM:NEG?

Svntax: Short Form: [SOUR:]VOLT[:LEV]:LIM:NEG? <value>

Long Form: [SOURce:]VOLTage[:LEVel]:LIMit:NEGative? <value>

Description: Identifies the software limit value for negative output voltage specified by the user.

### B.73 [SOURce:]VOLTage[:LEVel]:LIMit:POSitive COMMAND

**VOLT:LIM:POS** 

Short Form: [SOUR:]VOLT[:LEV]:LIM:POS <value> Syntax:

> Long Form: [SOURce:]VOLTage[:LEVel]:LIMit:POSitive <value> where <value> is between zero and rated (nominal) output voltage

Description: Establishes the software limit <value> for positive output voltage, i.e., sets the maximum value of pos-

itive output voltage that the unit will be allowed to produce. Requires MEM:UPD (PAR. B.11) to save

for power up. See PAR. 3.5.2.2 and Figure 3-16 for special programming considerations.

### B.74 [SOURce:]VOLTage[:LEVel]:LIMit:POSitive? QUERY

VOLT:LIM:POS?

Short Form: [SOUR:]VOLT[:LEV]:LIM:POS? <value> Syntax:

Long Form: [SOURce:]VOLTage[:LEVel]:LIMit:POSitive? <value>

Description: Identifies the software limit value for positive output voltage specified by the user.

### B.75 [SOURce:]VOLTage:MODE COMMAND

VOLT: MODE

Short Form: [SOUR:]VOLT:MODE (FIX | LIST | TRAN <nn> | EXT | GAIN) Syntax:

Long Form: [SOURce:]VOLTage:MODE (FIXed | LIST | TRANsient <nn> | EXTernal | GAIN)

nn = <value> = time in seconds for transient (from 0.035 to 1)

Description: Allows the user to execute or stop a list, to execute a transient, or to use an external reference.

The default mode is FIXed: the power supply executes commands normally, and LIST commands can be issued to establish the parameters and sequence of a list. This command affects the main channel,

whether voltage or current.

When VOLT:MODE LIST is issued, a list is executed (See LIST commands and Figure B-2). While the list is being executed, LIST commands are not accepted and will produce a command error. Issuing VOLT:MODE FIX while the list is running will stop the execution of the list and return power supply to settings in effect prior to running the list. If the list runs to completion, the settings of the last step of the list will be in effect.

VOLT: MODE TRAN nn causes the next VOLT: or CURR: command to produce a transient pulse of nn seconds duration, after which the voltage goes to zero. E.g., VOLT:25 sets the output to 25 volts, and VOLT:MODE TRAN 0.1 primes the unit for a transient of 0.1 seconds. When VOLT:10 is issued, the power supply output goes to 10V for 0.1 seconds. Similarly, sending VOLT:TRIG 14, VOLT:MODE TRAN .05 and \*TRG causes the output to go to 14V for 0.05 seconds. If the time nn exceeds 1 second, error message -222 "dwell or frequency out range" is posted to the error queue.

VOLT:MODE EXT Configures the unit to use an external reference to change the output voltage;  $\pm 10V$  reference produces output =  $\pm Eo$  (rated) (Fixed gain = Eo (rated).

VOLT:MODE GAIN Configures the unit to use an external reference to provide a proportional output

Related Commands: LIST commands. (See example, Figure B-2.)

### B.76 [SOURce:]VOLTage:MODE? QUERY

VOLT: MODE?

Short Form: [SOUR:]VOLT[:LEV]:MODE? Syntax:

Long Form: [SOURce:]VOLTage[:LEVel]:MODE? Return value: FIX, LIST, TRANS, EXT, or GAIN

Description: Identifies active voltage mode. See PAR. B.75 for further details Related Commands: LIST com-

mands. (See example, Figure B-2.)

#### VOLT:PROT[:BOTH] B.77 [SOURce:]VOLTage[:LEVel]:PROTect:BOTH COMMAND

Syntax: Short Form: [SOUR:]VOLT[:LEV]:PROT[:BOTH] <value>

Long Form: [SOURce:]VOLTage[:LEVel]:PROTect:[BOTH] <value>

where <value> is bewteen minimum (box) value (Figure 1-2) and 1% above rated (nominal) output

voltage.

Description: Establishes the both the positive and negative protection limits for voltage.

B-17 BOP-1K 022108

### B.78 [SOURce:]VOLTage[:LEVel]:PROTect[:BOTH]? QUERY VOLT:PROT[:BOTH]?

Syntax: Short Form: [SOUR:]VOLT[:LEV]:PROT[:BOTH]?

Long Form: [SOURce:]VOLTage[:LEVel]:PROTect[:BOTH]?

Returns <exp\_value>,<exp\_value>

Description: Identifies the protection limits for voltage (positive, negative); maximum is 1% greater than rated out-

put voltage.

### B.79 [SOURce:]VOLTage[:LEVel]:PROTect:MODE COMMAND VOLT:PROT:MODE

Syntax: Short Form: [SOUR:]VOLT[:LEV]:PROT:MODE (EXT | FIX | LESS |)

Long Form: [SOURce:]VOLTage[:LEVel]:PROTect:MODE (EXTernal | FIXed | LESSer |)

Description: Determines how voltage protection limits are controlled.

FIXED - Allows the limits to be controlled by digital signals from either the keypad (if the unit is in local

mode) or SCPI command (if the unit is in remote mode).

EXTERNAL: Allows the limits to be controlled by analog signals applied to the analog port; limits set

from the keypad or SCPI command have no effect (see PAR. 3.3.6.1).

LESSER LIMIT: Allows protect limit to be automatically selected from either 1) the external analog voltage applied to the Analog I/O port or 2) the value set from the keypad or SCPI command). Which-

ever limit has a lower absolute value (closest to zero) has effect

### B.80 [SOURce:]VOLTage[:LEVel]:PROTect:MODE? QUERY VOLT:PROT:MODE?

Syntax: Short Form: [SOUR:]VOLT[:LEV]:PROT:MODE?

Long Form: [SOURce:]VOLTage[:LEVel]:PROTect:MODE?

Returns FIX, EXT or LESS

Description: Identifies how voltage protection limits are controlled: FIX for Fixed, EXT for external, LESS for the

lesser of the internal (fixed) and external protection limit values (See PAR. B.79 for details).

### B.81 [SOURce:]VOLTage[:LEVel]:PROTect:NEGative COMMAND VOLT:PROT:NEG

Syntax: Short Form: [SOUR:]VOLT[:LEV]:PROT:NEG <exp value>

Long Form: [SOURce:]VOLTage[:LEVel]:PROTect:NEGative <exp\_value>

where <value> is bewteen minimum (box) value (Figure 1-2) and 1% above rated (nominal) output

voltage.

Description: Establishes the negative protection limit for voltage; maximum is 1% greater than rated output voltage.

### B.82 [SOURce:]VOLTage[:LEVel]:PROTect:NEGative? QUERY

VOLT:PROT:NEG?

Syntax: Short Form: [SOUR:]VOLT[:LEV]:PROT:NEG?

Long Form: [SOURce:]VOLTage[:LEVel]:PROTect:NEGative?

Returns: <exp\_value>

Description: Identifies the negative protection limit for voltage.

### B.83 [SOURce:]VOLTage[:LEVel]:PROTect:POSitive COMMAND VOLT:PROT:POS

Syntax: Short Form: [SOUR:]VOLT[:LEV]:PROT:POS <exp value>

Long Form: [SOURce:]VOLTage[:LEVel]:PROTect:POSitive <exp\_value>

where <value> is bewteen minimum (box) value (Figure 1-2) and 1% above rated (nominal) output

voltage.

Description: Establishes the positive protection limit for voltage; maximum is 1% greater than rated output voltage.

### B.84 [SOURce:]VOLTage[:LEVel]:PROTect:POSitive? QUERY

VOLT:PROT:POS?

Syntax: Short Form: [SOUR:]VOLT[:LEV]:PROT:POS?

Long Form: [SOURce:]VOLTage[:LEVel]:PROTect:POSitive?

Returns: <exp value>

Description: Identifies the positive protection limit for voltage.

B-18 BOP-1K 022108

### B.85 [SOURce:]VOLTage[:LEVel]:PROTect:LIMit:BOTH COMMAND

VOLT:PROT:LIM[:BOTH]

Syntax: Short Form: [SOUR:]VOLT[:LEV]:PROT:LIMit[:BOTH] <value>

Long Form: [SOURce:]VOLTage[:LEVel]:PROTect:LIM[:BOTH <value>

where <value> is bewteen minimum (box) value (Figure 1-2) and 1% above rated (nominal) output

voltage.

Description: Establishes the maximum value possible for both the positive and negative protection limits for volt-

age. Requires MEM:UPD (PAR. B.11) to save for power up. See PAR. 3.5.2.2 and Figure 3-16 for spe-

cial programming considerations.

### B.86 [SOURce:]VOLTage[:LEVel]:PROTect:LIMit[:BOTH]? QUERY

VOLT:PROT:LIM[:BOTH]?

Syntax: Short Form: [SOUR:]VOLT[:LEV]:PROT:LIM[:BOTH]?

Long Form: [SOURce:]VOLTage[:LEVel]:PROTect:LIMit[:BOTH]?

Returns <exp value>,<exp value>

Description: Identifies the maximum value possible for protection limits for voltage (positive, negative); maximum is

1% greater than rated output voltage.

### B.87 [SOURce:]VOLTage[:LEVel]:PROTect:LIMit:NEGative COMMAND

VOLT:PROT:LIM:NEG

Syntax: Short Form: [SOUR:]VOLT[:LEV]:PROT:LIM:NEG <exp value>

Long Form: [SOURce:]VOLTage[:LEVel]:PROTect:LIMit:NEGative <exp value>

where <value> is between minimum (box) value (Figure 1-2) and 1% above rated (nominal) output

voltage.

Description:Establishes the minimum (maximum absolute) value possible for the negative protection limit for voltage. This may be set up to 1% greater than rated voltage. Requires MEM:UPD (PAR. B.11) to save for power up. See PAR. 3.5.2.2 and Figure 3-16 for special programming considerations.

### B.88 [SOURce:]VOLTage[:LEVel]:PROTect:LIMit:NEGative? QUERY

VOLT:PROT:LIM:NEG?

Syntax: Short Form: [SOUR:]VOLT[:LEV]:PROT:LIM:NEG?

Long Form: [SOURce:]VOLTage[:LEVel]:PROTect:LIMit:NEGative?

Returns: <exp\_value>

Description: Identifies the minimum (maximum absolute) value possible for the negative protection limit

for voltage.

#### V

**VOLT:PROT:LIM:POS** 

Syntax: Short Form: [SOUR:]VOLT[:LEV]:PROT:LIM:POS <exp value>

B.89 [SOURce:]VOLTage[:LEVel]:PROTect:LIMit:POSitive COMMAND

Long Form: [SOURce:]VOLTage[:LEVel]:PROTect:LIMit:POSitive <exp\_value>

where <value> is bewteen minimum (box) value (Figure 1-2) and 1% above rated (nominal) output

voltage.

Description:Establishes the maximum value possible for the positive protection limit for voltage. This may be set up to 1% greater than rated voltage. Requires MEM:UPD (PAR. B.11) to save for power

up. See PAR. 3.5.2.2 and Figure 3-16 for special programming considerations.

### B.90 [SOURce:]VOLTage[:LEVel]:PROTect:LIMit:POSitive? QUERY

VOLT:PROT:LIM:POS?

Syntax: Short Form: [SOUR:]VOLT[:LEV]:PROT:LIM:POS?

Long Form: [SOURce:]VOLTage[:LEVel]:PROTect:LIMit:POSitive?

Returns: <exp value>

Description: Identifies the maximum value possible for the positive protection limit for voltage.

### B.91 [SOURce:]VOLTage[:LEVel]:TRIGgered[:AMPlitude] COMMAND

**VOLT:TRIG** 

Syntax: Short Form: [SOUR:]VOLT[:LEV]:TRIG[:AMP] <exp\_value>

Long Form: [SOURce:]VOLTage[:LEVel]:TRIGgered[:AMPlitude] <exp\_value> <exp\_value> = digits with decimal point and Exponent, e.g., 2.71E1 for 27.1

Description: Programs voltage value to be transferred to output by \*TRG command. Actual output voltage will

depend on load conditions. If the value exceeds the maximum for the model being programmed, error message -222,"Data out of range" is posted in output queue. If value exceeds VOLT:LIM:HIGH value,

a value corresponding to the voltage limit will be programmed.

### B.92 [SOURce:]VOLTage[:LEVel]:TRIGgered[:AMPlitude]? QUERY

**VOLT:TRIG?** 

Syntax: Short Form: [SOUR:]VOLT[:LEV]:TRIG[:AMP]?

Long Form: [SOURce:]VOLTage[:LEVel]:TRIGgered[:AMPlitude]?

Return Value: <exp\_value> = digits with decimal point and Exponent, e.g., 2.71E1 for 27.1

Description: Returns value representing voltage value to be programmed by \*TRG command established by

VOLT:TRIG command).

#### B.93 STATus: OPERation: CONDition? QUERY

STAT:OPER:COND?

Syntax: Short Form: STAT:OPER:COND? Long Form: STATus:OPERation:CONDition?

**Return Value:** <int value> 0 to 1313 (1 + 32 + 256 + 1024).

Description: Returns the value of the Operation Condition Register (see Table B-3). The Operation Condition

Register contains unlatched real-time information about the operating conditions of the power supply. Bit set to 1 = function enabled (active, true); bit reset to 0 = function disabled (inactive, false). (See

example, Figure B-4.)

## TABLE B-3. OPERATION CONDITION REGISTER, OPERATION ENABLE REGISTER, AND OPERATION EVENT REGISTER BITS

CONDITION	NU	CC	NU	CV	NU	NU	NU	NU
BIT	15-11	10	9	8	7 - 6	5	4 - 1	0
VALUE	32,768 - 2048	1024	512	256	128 - 64	32	16 -2	1

CC - POWER SUPPLY IN CONSTANT CURRENT MODE
CV - POWER SUPPLY IN CONSTANT VOLTAGE MODE
NU NOT USED

### B.94 STATus: OPERation: ENABle COMMAND

STAT: OPER: ENAB

Syntax: Short Form: STAT:OPER:ENAB <int value> 0 to 1313 (1 + 32 + 256 + 1024)

Long Form: STATus:OPERation:ENABle <int value> 0 to 1313 (1 + 32 + 256 + 1024)

Description: Sets Operation Enable Register. The Operation Enable Register is a mask for enabling specific bits

in the Operation Event Register which will cause the operation summary bit (bit 7) of the Status Byte register to be set Bit set to 1 = function enabled (active, true); bit reset to 0 = function disabled (inactive, false). The operation summary bit is the logical OR of all the enabled bits in the Operation Event

register. (See example, Figure B-4.)

#### B.95 STATus: OPERation: ENABle? QUERY

STAT:OPER:ENAB?

Syntax: Short Form: STAT:OPER:ENAB? Long Form: STATus:OPERation:ENABle?

Return Value: <int\_value>

Description: Reads Operation Enable Register (see Table B-3). Returns value of Operation Enable Register bits.

Bit set to 1 = function enabled (active, true); bit reset to 0 = function disabled (inactive, false). (See

example, Figure B-4.)

### B.96 STATus:OPERation[:EVENt] QUERY

STAT: OPER?

Syntax: Short Form: STAT:OPER[:EVEN]? Long Form: STATus:OPERation[:EVENt]?

Return Value: <int value>

Description: Indicates changes in conditions monitored by Operational Event Register (see Table B-3).

Returns the value of the Operation Event register. The Operation Event register is a read-only register which holds (latches) all events that occur. Reading the Operation Event register clears it. (See exam-

ple, Figure B-4.)

B-20 BOP-1K 022108

### **B.97 STATus:PRESet COMMAND**

STAT:PRES

Syntax: Short Form: STAT:PRES Long Form: STATus:PRESet

Description: Disables reporting of all status events. This command sets all bits of the Operation Condition (Table

B-3) and Questionable Condition Registers to 0, preventing all status events from being reported.

(See example, Figure B-4.)

### B.98 STATus:QUEStionable[:EVENt]? QUERY

STAT:QUES?

Syntax: Short Form: STAT:QUES[EVEN]? Long Form: STATus:QUEStionable[EVENT]?

Return Value: <int value> actual register value

Description: Indicates the latched condition of the Questionable Event register. Returns the value of the

Questionable Event register (see Table B-4). The Questionable Event register is a read-only register which holds (latches) all events. Only bits 13 and 12 are latched in the Status Questionable Event register. Bits 0 and 1 of the Status Questionable Condition Register are not latched in the power supply.

Reading the Questionable Event register clears it. (See example, Figure B-4.)

### TABLE B-4. QUESTIONABLE EVENT REGISTER. QUESTIONABLE CONDITION REGISTER. AND QUESTIONABLE CONDITION ENABLE REGISTER BITS

CONDITION	NU	CE	VE	NU	TE	NU	СМ	VM
BIT	15-14	13	12	11 - 4	3	2	1	0
VALUE	32,768 -16,359	8192	4096	2048 - 16	8	4	2	1

CE **CURRENT ERROR** VΕ **VOLTAGE ERROR CURRENT MODE** CM THERMAL ERROR TF **VOLTAGE MODE** VM NU NOT USED

#### B.99 STATus: QUEStionable: CONDition? QUERY

### STAT:QUES:COND?

Short Form: STAT:QUES:COND? Long Form: STATus:QUEStionable:CONDition? Syntax:

Return Value: <int\_value> actual register value

Description: Returns the value of the Questionable Condition Register (see Table B-4). The Questionable Condition Register contains unlatched real-time information about questionable conditions of the power supply. Bit set to 1 = condition (active, true); bit reset to 0 = condition (inactive, false). Bits 1 or

0 may be both be set, indicating the power supply is settling after a voltage change. (See example,

Figure B-4.)

#### B.100 STATus: QUEStionable: ENABle COMMAND

STAT: QUES: ENAB

Syntax: Short Form: STAT:QUES:ENAB <int value> Long Form: STATus:QUESionable:ENABle <int value>

Description: Programs Questionable Condition Enable Register (see Table B-4). The Questionable Condition

Enable Register determines which conditions are allowed to set the Questionable Condition Register; it is a mask for enabling specific bits in the Questionable Event register that can cause the questionable summary bit (bit 3) of the Status Byte register to be set. The questionable summary bit is the logical OR of all the enabled bits in the Questionable Event register. Bit set to 1 = function enabled (active, true); bit reset to 0 = function disabled (inactive, false). (See example, Figure B-4.)

#### B.101 STATus: questionable: ENABle? QUERY

STAT:QUES:ENAB?

Short Form: STAT:QUES:ENAB? Long Form: STATus:QUESionable:ENABle? Syntax:

Return Value: <int value> actual register value

Description: Reads Questionable Condition Enable Register (see Table B-4). Power supply returns value of Questionable Condition Enable Register, indicating which conditions are being monitored. Bit set to 1 = function enabled (active, true); bit reset to 0 = function disabled (inactive, false). Related Com-

mands: STAT:QUES?. (See example, Figure B-4.)

#### SYST:COMM:GPIB:ADDR B.102 SYSTem:COMMunication:GPIB:ADDRess COMMAND

Short Form: SYST:COMM:GPIB:ADDR<INT VAL> 0 to 30 Syntax:

Long Form: SYSTem:COMMunication:GPIB:ADDRess<INT VAL> 0 to 30

Description: Sets selected power supply GPIB address. NOTE: After executing this command, subsequent commands must be directed to the new GPIB address. Requires MEM:UPD (PAR. B.11) to save for power up. See PAR. 3.5.2.2 and Figure 3-16 for special programming considerations.

B-21 BOP-1K 022108

### B.103 SYSTem:COMMunication:GPIB:ADDRess? QUERY SYST:COMM:GPIB:ADDR?

Syntax: Short Form: SYST:COMM:GPIB:ADDR?

Long Form: SYSTem:COMMunication:GPIB:ADDRess?

Return Value: <int\_value> 0 to 30

Description: Identifies selected power supply GPIB address.

### **B.104 SYSTem:ERRor? QUERY**

Svntax:

Syntax:

Short Form: SYST:ERR? Long Form: SYSTem:ERRor?

Return Value: <int value, string>

Description: Posts error messages to the output queue. Returns the next error number followed by its corre-

sponding error message string from the instrument error queue. The error queue is a FIFO (first in first out) buffer that stores errors as they occur. As it is read, each error is removed from the queue and the next error message is made available. When all errors have been read, the query returns 0,"No error". If more errors are accumulated than the queue can hold, it will overflow. The oldest errors stay in the queue but the most recent errors are discarded. The last error in the queue will be -350,"Too many

errors." Error messages are defined in Table B-5.

#### FIGURE B-4. USING STATUS COMMANDS AND QUERIES

#### B.105 SYSTem:ERRor:CODE? QUERY

Short Form: SYST:ERR:CODE?] Long Form: SYSTem:ERRor:CODE?

Description: Returns the three character error code without the ASCII definition string. The error codes are defined

in table B-5 (See example, Figure B-6.)

### B.106 SYSTem:ERRor:CODE:ALL? QUERY

SYST:ERR:CODE:ALL?

SYST:ERR:CODE?

Syntax: Short Form: SYST:ERR:CODE:ALL?] Long Form: SYSTem:ERRor:CODE:ALL?

Return Value:

Description: Returns a comma-separated list of all error codes. A maximum of 31 codes will be returned; if the

queue is empty, the power supply returns 0.

### **B.107 SYSTem:KEYBoard COMMAND**

SYST:KEYB

SYST:ERR?

Syntax: Short Form: SYST:KEYB [DIS | ENAB] Long Form: SYSTem:KEYBoard [DISable | ENABle]

Description: Locks (DIS) or unlocks (ENAB) the front panel keypad. .

### **B.108 SYSTem:KEYBoard? QUERY**

SYST:KEYB?

Syntax: Short Form: SYST:KEYB? Long Form: SYSTem:KEYBoard?

Returns: DIS or ENAB

Description:Identifies the state of the keypad: locked (DIS) or unlocked (ENAB).

### **B.109 SYSTem:PASSword:CENable COMMAND**

SYST:PASS:CEN

Syntax: Short Form: SYST:PASS:CEN <val>

Long Form: SYSTem:PASSword:CENable <val>

Description: Sets the password enable state if the value matches the current Main password. This command

allows CALibrate commands to operate.

#### B.110 SYSTem:PASSword:CDISable COMMAND

SYST:PASS:CDIS

Syntax: Short Form: SYST:PASS:CDIS <val> Long Form: SYSTem:PASSword:CDISable <val>

Description: Clears the password enable state if the value matches the current Main password.

### **B.111 SYSTem:PASSword:NEW COMMAND**

SYST:PASS:NEW

Syntax: Short Form: SYST:PASS:NEW <old password>,<new password>

Long Form: SYSTem:PASSword:NEW <old password>,<new password>

Description: Establishes new password. The old (current) Mian password is checked, then replaced by the new

password. Admin 1 and 2 passwords (PAR. 3.2.4.3) are not available. (See example, Figure B-6.) See

PAR. 3.5.2.2 and Figure 3-16 for special programming considerations.

B-22 BOP-1K 022108

### B.112 SYSTem:PASSword:STATe? QUERY

SYST:PASS:STAT?

Syntax: Short Form: SYST:PASS:STAT? Long Form: SYSTem:PASSword:STATe?

Return Value: <int value> 0 or 1

Description: Returns a 1 if the password state is enabled or a 0 if it is disabled.

NOTES: 1. The power supply is assumed to be operating in constant voltage (CV) mode.

2 Examples below are intended only to illustrate command functions. Refer to PAR. 3.5.2 for

programming techniques to optimize performance.

STAT:PRES Operation Condition and Questionable Condition registers are

reset.

STAT:QUES:ENAB 12228 Allows latching of CE and VE bits STAT:OPER:ENAB 1280 Mask enabled for CC and CV bits.

STAT: OPER: ENAB? Returns 1280 (256 + 1024) (CC and CV bits set).

INIT: CONT ON Continuous triggers enabled.

STAT:OPER:COND? Power supply returns 256 to indicate that power

supply is in constant voltage mode.

STAT:OPER? Returns 256, indicating that since the last reading

of the Operation Event Register the power supply has entered

Constant Voltage mode.

STAT:OPER? Returns 0 indicating no changes since previous reading of the

Operation Event register.

STAT:QUES? Returns 0 (no questionable conditions occurred since previous

reading

--- OVERCURRENT CONDITION OCCURS

SYST:ERR? Power supply returns 0, "No error" message.
\*RST;:VOLT 5;CURR 1;OUTP ON The BOP is in Voltage mode and delivering 5 Volts

\*ESR? Bop returns a 0 - all functions are normal

FUNC:MODE CURR BOP is in Current mode

\*ESR?;STAT:QUES:COND? BOP returns 8;4097 - Current error.

\*ESR?;STAT:QUES? BOP returns 0;4096 - no new errors, Current Error

\*ESR?;STAT:QUES? BOP returns 0;0 - no new errors

MEAS:CURR?;VOLT? BOP returns 1.0E-4;5.00003E0 - Voltage is 5 volts

STAT:QUES:COND? BOP returns 4097 - error still in effect

Short is applied to the BOP

\*ESR?:STAT:QUES:COND? BOP returns 0;1 - Current mode is selected

MEAS:VOLT?;CURR? BOP returns.1E-4;1.00003E0 - Current is 1 amperes

FUNC:MODE VOLT;\*ESR? BOP switches mode, returns 3 - settling

\*ESR?:;STAT:QUES? BOP returns 8;8194

Short is removed from the BOP output

STAT:QUES:COND? BOP returns 2, voltage mode operation OK.

### **B.113 SYSTem:REMote COMMAND**

SYST:REM

Syntax: Short Form: SYST:REM {ON | OFF} or {1 | 0}

Long Form: SYSTem:REMote {ON | OFF} or {1 | 0}

Description: Used during serial (RS 232) communication to set the unit to remote (1 or ON) or local (0 or

**OFF) mode.** This command must be issued prior to commands that affect the power supply output (e.g., VOLT 10;:OUTP ON) to ensure the unit is in remote mode. See PAR. 3.5.6.3 and Figure B-5.

**B.114 SYSTem:REMote? QUERY** 

SYST:REM?

Syntax: Short Form: SYST:REM? Long Form: SYSTem:REMote?

Return Value: {1 | 0}

Description: Identifies whether unit it in remote mode (1) or local mode (0) during serial (RS 232) communi-

cation. See PAR. 3.5.6.3 and Figure B-5.

\*IDN? Unit responds with KEPCO,BOP 50-20,E1234,1.66 (typical).

outp? Unit responds with 0 indicating output is off

syst:rem? Unit responds with 0 indicating unit is in local mode.

syst:rem 1 Puts unit in remote mode.

outp on Enables output

outp? Unit responds with 1 (output on).

syst:rem 0 Unit set to local mode.

#### FIGURE B-5. SETTING THE UNIT TO REMOTE MODE VIA SERIAL (RS 232) PORT

### **B.115 SYSTem:SECurity:IMMediate COMMAND**

SYST:SEC:IMM

Syntax: Short Form: SYST:SEC:IMM Long Form: SYSTem:SECurity:IMMediate

Description: Initializes all NVRAM variable to factory defaults. Empties all memory locations. See PAR. 3.5.2.2

and Figure 3-16 for special programming considerations.

#### **B.116 SYSTem:SET COMMAND**

SYST:SET

SYST:SET?

Syntax: Short Form: SYSTem:SET {CM0 | CM1 | DCL0 | DCL1 | LF0 | LF1 | RO0 | RO1 | OUT0 | OUT1} Long Form: SYSTem:SET {CM0 | CM1 | DCL0 | DCL1 | LF0 | LF1 | RO0 | RO1 | OUT0 | OUT1}

Description: Establishes Device Clear, Line Feed, OUTP command and Reset functions. Sending SYST:SEC:IMM sets LF1, DC0, and RO0 (as if CM0 was sent). Requires MEM:UPD (PAR. B.11) to save for power up. See PAR. 3.5.2.2 and Figure 3-16 for special programming considerations.

DCL0 Device Clear functions per IEEE 488.2 Standard. (No effect on the device (power supply),

only clears internal status registers.)

DCL1 Device Clear functions identical to \*RST (Output set to 0V, voltage mode and output set to

OFF except if RO1 (see below) is set.)

LF0 Line Feed not provided upon empty buffer condition

LF1 Line Feed provided if buffer is empty and a read is performed.

RO0 \*RST and power up set output to OFF, 0V, 0A, voltage mode.

\*RST sets output to ON, 0V, 0A, voltage mode. Subsequent VOLT and CURR commands are immediately present at the output without sending OUTP ON (OUTP OFF and OUTP

ON function normally to turn the output off or on.)

OUT0 OUTP command functions per PAR. B.12

OUT1 OUTP command functions as described in PAR. B.12, however sending VOLT or CURR

command also turns the output on.

CM0 Establishes DCL0, LF0, RO0 conditions described above. (SCPI 1997 Standard compli-

ance)

CM1 Establishes DCL1, LF1, RO1 conditions described above. (Compatible with software ver-

sions 1.2 and earlier) (See example, Figure B-6.)

### **B.117 SYSTem:SET? QUERY**

Syntax: Short Form: SYST:SET? Long Form: SYSTem:SET?

Return Value: DCL<n>,LF<n>,RO<n>,OUT<n> where n = 0 or 1

Description: Identifies functions established by SYST:SET command. (See example, Figure B-6.)

B-24 BOP-1K 022108

### **B.118 SYSTem: VERSion? QUERY**

SYST:VERS?

Syntax: Short Form: SYST:VERS? Long Form: SYSTem:VERSion?

Return Value: <int value>.<int value> (YYYY.V)

Description: Identifies SCPI Version implemented. Returns SCPI Version number:

YYYY = year, V = Revision number for specified year. (See example, Figure B-6.)

SYST:VERS? Unit returns 1997

SYST:SET? Unit returns DC0,LF0,RL0,OUT0
SYST:PASS:NEW DEFAULT,OKAY Unit changes password to be OKAY

SYST:SET LF1,RL1,DC1 Configures Device Clear, Line Feed and Reset

(see PAR. B.116).

DIAG:SAV;:SYST:ERR:CODE?

BOP returns -231 indicating command is protected Password enabled commands are accepted Unit saves the LF1 state for next power on cycle.

#### FIGURE B-6. USING SYSTEM COMMANDS AND QUERIES

### **B.119 TRIGger:SOURce COMMAND**

TRIG:SOUR

Syntax: Short Form: TRIG:SOUR {EXT | BUS} Long Form: TRIGger:SOURce {EXT | BUS}

Description: Sending TRIG:SOUR activates either internal (BUS) or external (EXT) trigger. When the external trig-

ger (ground) is applied to J2 pin 3, output voltage and current are set to previously stored values for

VOLT:TRIG and CURR:TRIG.

NOTE: If INIT:CONT 1 was sent prior to sending TRIG:SOUR EXT, continuous mode is disabled and

unit will wait for INIT:IMM

### B.120 TRIGger:SOURce? QUERY

TRIG:SOUR?

Syntax: Short Form: TRIG:SOUR? Long Form: TRIGger:SOURce?

Returns: EXT or BUS

Description: Identifies whether internal (BUS) or external (EXT) trigger is activated.

### TABLE B-5. ERROR MESSAGES

ERROR MESSAGE	ESR ERROR BIT SET (SEE PAR. A.5)	EXPLANATION
0,"No error"	None	No error
1,"Interprocessor communications error"	Device Error bit 3 (1)	Interprocessor communications error
2,"Configuration error"	Device Error bit 3 (1)	Configuration error
10,"Program Error"	Device Error bit 3 (1)	Program error
1xx01,"A3 Output Temperature Error" 1xx02,"A2 Output Temperature Error" 1xx03,"Output Overcurrent" 1xx04,"Output Overvoltage" 1xx05," A2 Instant Overcurrent" 1xx06,"A2 (+)15V BUS Missing" 1xx07,"A3 Overcurrent" 1xx08,"A4 Module Temperature Error" 1xx09,"A4 Output Voltage Error" 1xx10,"A4 Input Section Error" 1xx11,"A2 Input Over Current Error " 1xx12,"A4 (-)15VS Missing"	Device Error bit 3 <sup>(1)</sup>	Indicates the power supply or one of the connected power supplies has detected an error. These errors are an indication of a hardware problem in either the BOP or the BOP system consisting of a master and up to four slave BOPs to create additional current or voltage. The last two digits of the error code indicate the type of error and its source; xx indicates the position of the unit on the BITBUS:  xx = 1: Device 1 (Master)  xx = 2: Device 1 (Slave 1)  xx = 3: Device 1 (Slave 2)  xx = 4: Device 1 (Slave 3)  xx = 5: Device 1 (Slave 4)

(1) The Device error bit may be set when the status monitoring functions of the power supply detect an overvoltage/under-voltage condition.

BOP-1K 022108 B-25/(B-26 Blank)

### **TABLE B-5. ERROR MESSAGES (CONTINUED)**

TABLE B-5. ERROR MESSAGES (CONTINUED)						
ERROR MESSAGE	ESR ERROR BIT SET (SEE PAR. A.5)	EXPLANATION				
2yy01,"OVER TEMPERATURE" 2yy02,"CROWBAR ACTIVE" 2yy03,"DEVICE TURNED OFF" 2yy04,\"CURRENT FAULT" 2yy05,"POWER LOSS" 2yy06,"VOLTAGE FAULT" 2yy07,"RELAY OPEN", 2yy08,"POLARITY ERROR" 2yy09,"OVERLOAD"	Device Error bit 3 <sup>(1)</sup>	Indicates a hardware problem has been detected in either the BOP power supply or an auxiliary power supply, such as Kepco's MST, MAT, MBT or low power (under 1KW) BOP, connected to the BITBUS. The last two digits of the error code indicate the type of error detected,; yy indicates the position of the unit on the BITBUS yy = 2: Device 2 through yy = 15: Device 15				
-100,"Command error"	Command Error bit 5	Command and data understood, but more information included which is not recognized.				
-120,"Numeric data error"	Command Error bit 5	Expected number but other characters were detected				
-203,"Command Protected"	Execution error bit 4	Password must be CENAbled				
-221,"Settings Conflict"	Execution error bit 4	Calibration state not enabled but CALibrate command received				
-222,"Current, Voltage or Data out of range"	Execution error bit 4	Value (current or voltage) exceeds power supply rating or (data) exceeds acceptable command parameters				
-223,"Too Much Data"	Execution error bit 4	During a LIST command, the list became full, preventing all the data from being added to the list				
-226,"Lists not same length"	Execution error bit 4	During a LIST command, number of DWEL list entries was not equal to 1 and did not match number of LIST:VOLT or LIST:CURR entries.				
-240,"Hardware error"	Execution error bit 4	Power supply did not respond to command.				
-249,"Master Not Found"	Execution error bit 4	The slave controller for a multiple unit configuration has not detected a master unit this is an operator error as the slave should not be operated over the GPIB interface.				
-311,"Memory Error"	Device Error bit 3 (1)	*SAV (save), *RCL (recall), MEMory:SAVE, MEMory:UPDAte or CALibrate:STORe error				
-314,"Save/recall Memory Lost"	Device Error bit 3 (1)	A memory location that was saved earlier was lost due to a flash error in Analog processor memory.				
-340,"Calibration Failed"	Device Error bit 3 <sup>(1)</sup>	The calibration results were invalid. This normally indicates an incorrect calibration caused by operator error such as performing a current calibration without a load,8 or a voltage calibration with a load.				
-350,"Queue Overflow"	Device Error bit 3 (1)	Error queue was full, error events have been lost.				
-363,"Input buffer overrun"	Device Error bit 3 (1)	The input from the controlling computer was longer than 253 characters in length.				
-400,"QueryError"	Query Error bit 2	Data requested was lost due to 253 character limit or BIT 4886 output buffer				
-420,"Query Unterminated"	Query Error bit 2	Controller sent query but did not accept data from power supply. See VOLT? (PAR. B.68), CAL:SAVE (PAR. B.68) commands				


<sup>(1)</sup> The Device error bit may be set when the status monitoring functions of the power supply detect an overvoltage/under-voltage condition.



### **BOP 1000W QUICK REFERENCE GUIDE**

Once the power supply is installed (see full Technical Manual), this guide is an aid that briefly outlines a simple approach to accomplishing common tasks, with the appropriate Technical Manual paragraph references for more details. All instructions start from the power-up screen (press from most submenus to return to power-up screen). Many setup functions can be password protected - see UTILITY below for instructions.

### UTILITY



KEPCO, INC. ● 131-38 SANFORD AVENUE ● FLUSHING, NY. 11352 U.S.A. ● TEL (718) 461-7000 ● FAX (718) 767-1102 http://www.kepcopower.com ● email: hq@kepcopower.com

228-1530-R8A

CONTROLLING THE OUTPUT USING EXTERNAL (ANALOG) SIGNALS (REMOTE) How do I control the mode using an external signal? [4], highlight External Mode, [7], highlight Enable, [4], then [5] to apply changes and exit. This setting is not saved for power-up (PAR. 3.4.2). Select mode by applying either logic 1 or open circuit for voltage, or logic 0 or short circuit for current, to pin 2 referenced to pin 9 of the Analog I/O port (PAR. 3.4.2). How do I use an analog voltage to control the output (main channel)? [A], highlight Reference input, [A], highlight External then [4], then [5] to apply changes and exit. This setting is not saved for power-up. Apply ±10V signal to pin 11 referenced to pin 4 of the Analog I/O port to control active channel (voltage or current) (PAR. 3.4.3). How do I use an analog voltage to control the protection channel? [4], highlight Protection Limit, [4], highlight External then [4], then [5] to apply changes and exit (not saved for power-up). Apply +1V to +10V signal to the following pins referenced to pin 12 of the Analog I/O port to control limit channel from 10% to full scale: -Current Protect: pin 5, +Current Protect: pin 13, -Voltage Protect: pin 6, +Voltage Protect: pin 14 (PAR. 3.4.4). How do I choose between local, digital and analog control of the output? The unit normally powers up in Local mode. Sending a command via RS 232 or GPIB interfaces automatically puts the unit into Remote mode. Press [7] to restore Local mode. If an analog voltage is controlling the output (see above), local control of the main channel is disabled and digital commands are not accepted. How do I use the BOP as an amplifier? See above to control the main channel and/or protection channel using analog signals. The nominal (inherent) voltage gain of each model is calculated by  $(G_{NOM-V}) = E_{Onom} / E_{REF}$  and nominal (inherent) current gain is  $(G_{NOM-I}) = E_{Onom} / E_{REF}$  $I_{Onom}$  /  $E_{REF}$  where  $E_{REF}$  = 10V (see PAR. 3.4.3.1). How do I control the gain of the BOP when used as an amplifier? [4], highlight Reference input, [5], highlight ExtlRefLevI then [4], then [5] to apply changes and exit (not saved for power-up). Apply ±10V signal to pin 11 referenced to pin 4 of the Analog I/O port. Main channel setting (SET) determines gain (G) by G = SET/10 (PAR. 3.4.3.2). CONTROLLING THE OUTPUT USING DIGITAL INTERFACE (REMOTE) How do I use the GPIB interface to control the power supply? [5], [1] to view current GPBI address. To change GPIB address, highlight GPIB address, [1], use keypad to enter new address then [4]. Press [5] to exit or [4] to save for power-up (see PAR. 3.5.3.1). How do I use the RS 232 interface to control the power supply? [5], [1] to view. To change Baud Rate, XON/XOFF or Prompt if needed: highlight Baud Rate, XON/XOFF or Prompt setting, [1], highlight desired selection, then [4]. When complete, [5] to exit or [4] to save for power-up (see PAR. 3.5.3.2). How do I change between SCPI and CIIL Data Format? [5], [1], to view. To change, highlight Data Format setting, [1], highlight SCPI or CIIL then  $\mathbb{F}^4$ .  $\mathbb{F}^5$  to exit or  $\mathbb{F}^4$  to save for power-up. (PAR. 3.5.3.1.2) How do I change the Device Clear from SCPI to MATE compliant? [5], [1], to view. To change, highlight Device Clear setting, [1], highlight SCPI or MATE then [4]. [5] to exit or [4] to save for power-up. (PAR. 3.5.3.1.2) **FEATURES** How do I save the power supply settings for future use? [1], highlight Empty location, [1]. The power supply settings (Mode, type and values for Main Channel Reference and Protection, and output on/off) are displayed. To save a different setting than that displayed, highlight the parameter, [1] highlight the selection or enter value using keypad, then [4]. [5] to exit or [4] to save for power-up. (PAR. 3.3.8) How do I modify saved power supply settings for future use? [1], highlight desired location, [1]. The power supply settings (Mode, Main Channel Reference and value, Protection type and values and output on/off) are displayed. To change a setting, highlight the parameter, [1] highlight the selection or enter value using keypad, then [4]. [5] to exit or [4] to save for power-up. (PAR. 3.3.8) How do I recall previously saved power supply settings? [1], highlight desired location. [2] to execute stored settings or [1] to see details, then to program settings. (PAR. 3.3.8) How do I view or execute a waveform? [2] highlight Waveform name, [1] to view, press STANDBY to turn output on, [4] to execute. [F5] to stop waveform execution. (PAR. 3.3.9) How do I create a waveform? Use arrow keys to highlight Empty, [2], [1]. Enter name using ADJUST or keypad (multiple presses for letters) and then 4. To change Mode highlight selection, inight selection, highlight Voltage or Current, to save for power-up. To change protection, highlight setting, renter new setting using keypad, rel. To change count, highlight setting, renter new setting using keypad, rel. To change count, highlight setting, renter new setting using keypad, rel. Define first segment (Type, Frequency, Amplitude (p-p) and Offset) by highlighting parameter, rel., highlight desired setting or use keypad to enter value, then rel. Highlight segment or End of Segments, rel. to insert next segment prior to highlight or rease segment. Define new segment or re-edit existing segment in the same way (including start/stop angle for sine or triangle), then [4]. (PAR. 3.3.9.8) See above to execute waveform. How do I calibrate the unit? [5], highlight Calibration, [1], then proceed per screen prompts.

How do I configure unipolar operation? Set either + or – Maximum to zero as follows: [55], highlight Max/Min Settings, [51]. Higlight +Voltage Max, -Voltage Min, +Current Max or -Current Min as desired, 🔼 press CLEAR to set to zero, then 🔼 😥 to exit or 🚮 to save

Can I further customize the configuration? Yes, contact Kepco for further information.

for power-up (see PAR. 3.3.4).

You must register your product to comply with the terms of the warranty. Either fill out the form below and mail or fax to Kepco, or for rapid on-line registration go to:

### http://www.kepcopower.com/warranty.htm

PRODUCT PURCHASED:	REGISTER TO:
Model Number)	Registered by:
Serial Number	Company Name:
PURCHASE INFORMATION:	Street:
Date Purchased:	City:
Date Received:	State:
	Country:
REQUEST ADDITIONAL INFORMATION	Zip:
☐ Send complete Catalog	E-mail:
☐ Have Sales Engineer Call	FAX:
Contact via:	Phone:
WHAT INFLUENCED YOUR CHOICE OF THIS PO	OWER SUPPLY?
☐ Previous Experience (which Kepco Models do you have?)	☐ Kepco Catalog or Brochure?
	☐ Sales Representative?
	☐ Web Site
	Other (please explain):
☐ Magazines (which ones?)	What products would you like to see Kepco make?
☐ Trade Shows (which ones?)	
☐ Directory?	

# Kepco 5 Year Warranty

This is to certify that we, KEPCO, INC., (hereinafter called "Company"), Flushing, NY 11355 USA, warrants for a period of FIVE YEARS, this instrument known as:

MODEL:

SERIAL NO.

The Company's products are warranted for a period of five years from date of delivery to be free from defects in materials and workmanship and to conform to the specifications furnished or approved by the Company. Liability under this warranty shall be limited to the repair or replacement of any defective product at Company's option.

If any defect within this warranty appears within the warranty period, the Purchaser shall promptly notify the Company in writing. No material will be accepted for repair or replacement without written authorization of the Company.

Upon such authorization, and in accordance with instructions of the Company, parts or materials for which replacement is requested shall be returned to the Company for examination, with shipping charges prepaid by the Purchaser. Final determination as to whether a product is actually defective rests with the Company.

This warranty does not extend to any product which has been subjected to misuse, neglect, accident, improper installation, or use in violation of instructions furnished by the Company. The warranty does not extend to, or apply to, any unit which has been repaired or altered outside of the Company's factory by persons not expressly approved by the Company.

THE WARRANTY HEREIN CONTAINED IS IN LIEU OF AND EXCLUDES ALL OTHER WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, INCLUDING WITHOUT LIMITATION THE WARRANTY OF MERCHANTABILITY.

### THIS KEPCO PRODUCT IS WARRANTED FOR FIVE YEARS!

KEPCO, INC. • 131-38 SANFORD AVENUE, FLUSHING, NY 11355 USA • Tel. 718-461-7000 • Fax. 718-767-1102 E-mail: hq@kepcopower.com • URL: http://www.kepcopower.com



FOLD HERE

Please place stamp here

# KEPCO, INC.

131-38 SANFORD AVE. FLUSHING, NY 11355 USA

CUT HERE